

HP xw9400 Workstation Service and Technical Reference Guide

User Guide



Copyright Information

© 2006 Copyright Hewlett-Packard Development Company, L.P.

Warranty

Hewlett-Packard Company shall not be liable for technical or editorial errors or omissions contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material. The information in this document is provided "as is" without warranty of any kind, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, and is subject to change without notice. The warranties for HP products are set forth in the express limited warranty statements accompanying such products.

Nothing herein should be construed as constituting and additional warranty.

This document contains proprietary information that is protected by copyright. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Hewlett-Packard Company.

Trademark Credits

The HP Invent logo is a trademark of Hewlett-Packard Company in the U.S. and other countries.

Microsoft and Windows are trademarks of Microsoft Corporation.

UNIX is a registered trademark of The Open Group..

Intel and Xeon are registered trademarks of Intel Corporation in the U.S. and other countries.

Energy Star is U.S. registered mark of the United States Environmental Protection Agency.

434615-001

First Edition, September 2006

Table of contents

1 Product overview

Product features	2
Exploded view	2
Front panel components	3
Rear panel components	4
Serial number and COA label location	5
Product specifications	6
Power supply and cooling	6
Power supply specifications	7
Power consumption and cooling	8
System fans and airflow	9
Resetting the power supply	9
Power cord requirements	9
Environmental specifications	9
PCI card slot power specification	10
Chipkill support	12
Energy Star®	13
Energy Star compliance	13

2 Installing or restoring the operating system

Installing the operating system and software	16
Microsoft Windows XP Professional	16
Installing or upgrading device drivers	16
Linux-preinstalled workstations	16
Starting the Linux operating system	16
Upgrading device drivers	16
Linux-enabled workstations	17
Verifying hardware compatibility	17
Installing the Linux operating system	17
Red Hat Activation	17
HP software	18
Restoring the operating system	19
Restoring the Windows operating system	19
The RestorePlus! process	19
Creating a RestorePlus! CD	19
Restoring from RestorePlus! CDs	19
Restoring from RestorePlus! on the Recovery Partition	19
HP Backup and Recovery Manager restore points	20

Restoring from the HP Backup and Recovery Manager restore point CD/DVDs	20
Restoring from the HP Backup and Recovery Manager restore point on the Recovery Partition	20
Reclaiming hard disk space from the recovery partition	20
Ordering backup software	20
Restoring the Linux operating system	21
Downloading the latest HP driver CD contents	21
Installing the operating system with the HP driver CD contents	21
Protecting the software	22

3 System management

Computer Setup (F10) Utility	24
BIOS ROM	25
Using Computer Setup (F10) Utility	25
Computer Setup (F10) Utility menu	26
Desktop management	34
Initial configuration and deployment	34
Remote system installation	34
Managing and updating software	35
HP Client Manager software	35
Altiris Client Management solutions	35
System Software Manager	36
Proactive Change Notification	36
Subscriber's Choice	36
ROM flash	37
Remote ROM flash	37
HPQFlash	37
FailSafe Boot Block ROM	37
Replicating the setup	38
Copying to a single workstation	39
Copying to multiple workstations	39
Dual-state power button	40
Worldwide web site	40
Building blocks and partners	41
Asset tracking and security	41
Password security	42
Establishing a setup password in the Computer Setup (F10) Utility	43
Establishing a power-on password in the Computer Setup (F10) Utility	43
Entering a power-on password	44
Entering a setup password	44
Changing a power-on or setup password	44
Deleting a power-on or setup password	45
National keyboard delimiter characters	45
Clearing passwords	46
Hood sensor (Smart Cover Sensor)	46
Setting the hood sensor protection level	46
Cable lock provision (optional)	47

Security lock (optional)	47
Universal chassis clamp lock (optional)	47
Access panel key lock	47
Fault notification and recovery	47
Drive Protection System	47
ECC fault prediction and pre-failure warranty	47
Thermal sensors	48

4 Removal and replacement procedures

Service considerations	50
Read cautions, warnings, and safety precautions	50
Electrostatic discharge information	50
Generating static	50
Preventing electrostatic damage to equipment	51
Personal grounding methods and equipment	51
Grounding the work area	51
Recommended materials and equipment	52
Required tools and software	52
Screws	52
Special handling of components	52
Cables and connectors	53
Hard drives	53
Lithium coin cell battery	53
Customer Self Repair	54
Pre-disassembly procedures	55
System board components	56
System board architecture	58
Removing and replacing components	59
Disassembly order	59
Security lock (optional)	61
Cable lock (optional)	61
Access panel	61
Front bezel	62
Bezel blanks	63
Hood sensor (Smart cover sensor)	64
Front panel I/O device assembly	64
Power button assembly and system speaker	65
Power supply	67
System fan	67
Memory fan	68
Memory	69
Memory module features	69
Memory module requirements	69
Removing memory module	70
Installing a memory module	71
PCI slots	73
PCI retainer	73
Removing the PCI retainer	74
Installing the PCI retainer	74
PCI retention clamp	75

PCI Express	75
Removing PCI or PCI Express cards	76
PCI or PCI Express installation	77
Front fan removal	78
Battery	80
Power connections to drives	81
Optical drive	83
Replacing the SATA optical drive data cable	84
Diskette drive (optional)	84
Hard drive	87
Replacing a hard drive	87
Removing a hard drive	87
Installing a hard drive	88
Installing a hard drive In the fifth hard drive bay	90
Processor heatsink	91
Removing the CPU heatsink	91
Replacing the CPU heatsink	92
Processor	94
Removing the processor	94
Replacing the processor	96
System board	96
Removing the system board	96
Replacing the System Board	97

5 System diagnostics and troubleshooting

E-Support	100
Help and support center and E-Support	100
Troubleshooting checklist	101
LED color definitions	102
HP Insight Diagnostics Offline Edition	103
Key features and benefits	103
Theory of operation	103
Download the ISO image	103
User interface	104
Navigation	104
Survey tab	104
Test tab	104
Status tab	105
Log tab	105
Help tab	106
Starting the diagnostic utility from CD	106
Diagnostic error codes	107
Diagnostic light codes	107
Troubleshooting scenarios and solutions	110
Solving minor problems	110
Solving power supply problems	111
Testing power supply	111
Solving diskette problems	113
Solving hard drive problems	115
Solving display problems	116

Solving audio problems	119
Solving printer problems	120
Solving keyboard and mouse problems	121
Solving front panel component problems	121
Solving hardware installation problems	122
Solving network problems	124
Solving memory problems	126
Solving processor problems	127
Solving CD-ROM and DVD problems	127
Solving Internet access problems	129
POST error messages	131

Appendix A SAS devices

Supported SAS RAID configurations	140
SAS RAID 0 (IS) configuration	141
SAS RAID 1 (IM) configuration	142
SAS RAID 1E (IME) configuration	143
Changing boot order	144

Appendix B SATA devices

Enable SATA RAID option in BIOS	146
Configuring a SATA RAID array	147
Changing boot order	148
Deleting RAID volumes	149

Appendix C Connector pins

Connector pin descriptions	152
----------------------------------	-----

Appendix D System board designators

Appendix E Power cord set requirements

Appendix F Routine care

General cleaning safety precautions	168
Maximizing the airflow	169
Cleaning the workstation case	170
Cleaning the keyboard	171
Cleaning the monitor	172
Cleaning the mouse	173

Appendix G Additional password security and resetting CMOS

Resetting the password jumper	176
Clearing and resetting the CMOS	177
Using the CMOS button	177
Using the Computer Setup Utility to reset CMOS	178

Appendix H Quick troubleshooting flowcharts

Initial troubleshooting	180
No power	181
No power, part 1	181
No power, part 2	182
No power, part 3	182
No video	184
No video, part 1	184
No video, part 2	185
No video, part 3	185
Error messages	187
Error messages, part 1	187
Error messages, part 2	188
Error messages, part 3	188
No operating system loading	190
No operating system loading from hard drive	191
No operating loading from hard drive, part 1	191
No operating system loading from hard drive, part 2	192
No operating system loading from hard drive, part 3	192
No operating system loading from diskette drive	194
No operating system loading from optical drive	195
No operating system loading from network	196
Non-functioning device	197

Appendix I PCI bus layout

PCI bus layout and device list	200
--------------------------------------	-----

1 Product overview

This chapter presents an overview of the hardware components of the HP Workstation.

- [Product features on page 2](#)
- [Product specifications on page 6](#)
- [Chipkill support on page 12](#)
- [Energy Star® on page 13](#)

Product features

Exploded view

The following image shows a typical HP xw9400 Workstation (drive configurations can vary).

For complete and current information on supported accessories and components, see <http://partsurfer.hp.com>.




Figure 1-1 Exploded view

Table 1-1 Exploded view

Item	Description	Item	Description
1	PCI card support	10	Memory modules
2	Power supply	11	Card guide/Front fan
3	CPU heatsinks	12	Graphics card
4	Processors	13	Optical drive*
5	System fan	14	PCIe card
6	Access panel	15	Diskette drive
7	System board	16	PCI card
8	Chassis	17	Hard drive
9	Front bezel	18	Memory fan

* A CD-ROM is an example of an optical drive.

Front panel components

The following image shows a typical HP xw9400 Workstation. Drive configurations can vary.




Figure 1-2 Front panel components

Table 1-2 Front panel components

Item	Symbol	Description	Item	Symbol	Description
1		Optical drive	6		Headphone connector
2		5.25-inch drive bay	7		USB 2.0 ports
3		Diskette drive (optional)	8		Hard drive activity light
4		IEEE-1394a connector	9		Power button
5		Microphone connector	10		Power on light

Rear panel components




Figure 1-3 Rear panel components

Table 1-3 Rear panel components

Item	Symbol*	Description	Item	Symbol	Description
1		Power cord connector	10		Graphics adapter
2		Built In Self Test (BIST) LED	11		Audio line-in connector
3		Serial connector	12		RJ-45 network connectors
4	SPDIF	SPDIF OUT**	13		IEEE-1394a connector
5		Keyboard connector	14		Mouse connector
6		USB 2.0 ports	15		Cable lock slot
7		Microphone connector	16		Padlock loop
8		Audio line-out connector	17		Universal chassis clamp opening
9		MiniSAS 4-port connector (optional)	18		Access panel key

* The rear panel connectors are labeled with industry-standard icons and colors to assist you in connecting your peripheral devices.

** SPDIF OUT is a single RCA jack to support SPDIF digital audio output via coax cable.

Serial number and COA label location

Each workstation has two unique serial number labels. Systems preinstalled with Microsoft® Windows® XP also have a certificate of authentication (COA) label (2). The serial number labels (1) are located on the side panel of the unit and on the rear panel. Keep the serial number available when contacting customer service for assistance.



Figure 1-4 Serial number and COA label location

Product specifications

The following table lists the physical dimensions.

Table 1-4 Physical characteristics

Weight (depending on configuration)	18-27.7 kg (39.6-61.1 lb.)
Tower dimensions	455 mm (17.9 in.) tall, 210 mm (8.3 in.) wide, 525 mm (20.7 in.) deep
Rack mount dimensions (top cover and foot removed)	210 mm (8.3 in.) tall, 440 mm (17.3 in.) wide, 525 mm (20.7 in.) deep

Power supply and cooling

This section describes power supply specifications.

Table 1-5 Voltage specification

Voltage	Minimum	Maximum	Description
3.3 V	3.17 V	3.47 V	Used with PCI, onboard logic, SAS controller, IEEE 1394, and chipset
5 V	4.90 V	5.35 V	Used with storage (disk, optical, diskette), PCI, Audio, USB, input to onboard regulator, and onboard logic
12 V CPU0	11.52 V	12.6 V	Input to onboard regulator that supplies power for CPU 0
12 V CPU1	11.52 V	12.6 V	Input to onboard regulators that supply power for CPU1 and the chipset
12 V-M	11.52 V	12.6 V	Input to onboard regulators that supply power for memory
12 V-B	11.52 V	12.6 V	Used with PCI, fans, onboard logic, and audio regulator
12 V-D	11.52 V	12.6 V	Used with storage (disk, optical, floppy)
12 V-G	11.52 V	12.6 V	Used with PCI Express x16 auxiliary connectors
V12N	-11.4 V	-12.6 V	Used by PCI
5 VSB	4.85 V	5.25 V	Used for sleep circuitry and input to onboard regulators

Table 1-6 Current specification

Current	Continuous	Description
3.3 V	22.0 A	Used with PCI, onboard logic, SAS controller, IEEE 1394, and chipset
5 V	18.0 A	Used with storage (disk, optical, diskette), PCI, Audio, USB, input to onboard regulator, and onboard logic
12 V CPU0	13.7 A	Input to onboard regulator that supplies power for CPU 0

Table 1-6 Current specification (continued)

Current	Continuous	Description
12 V CPU1	16.7 A	Input to onboard regulators that supply power for CPU1 and the chipset
12 V-M	18.6 A	Input to onboard regulators that supply power for memory
12 V-B	15.7 A	Used with PCI, fans, onboard logic, and audio regulators
12 V-D	10.0 A	Used with storage (disk, optical, floppy)
12 V-G	12.5 A	Used with PCI Express x16 auxiliary connectors
V12N	0.3 A	Used by PC
5 VSB	2.5 A	Used for sleep circuitry and input to onboard regulators



WARNING! Do not exceed 135 W of a 5-V and 3.3-V power combination.

Do not exceed 64 A (768 W) of a 12-V (CPU0/CPU1/M/B/D/G) power combination.

Do not exceed 800 W of total continuous output power.

Power supply specifications

The integrated, surge-tolerant power supply is rated to withstand a power surge of up to 2,000 V (line-to-PE or neutral-to-PE) and 1,000 V (line-to-line) without any data loss or system downtime. The following specifications describe the power supply:

Table 1-7 Power supply specifications

Parameter	Specification
Power supply	800 watt power supply (Wide Ranging, Active PFC)
Operating voltage range	90-269 VAC
Rated voltage range	100-240 VAC/118 VAC 118 VAC
Rated line frequency	50-60 Hz 400 Hz
Operating line frequency range	47-66 Hz 393-407 Hz
Rated input current	13.2 A @ 100-120 VAC 11.2 A @ 118 VAC 6.6 A @ 200-240 VAC
Heat dissipation	Typical: 1,950 BTU/hr. (491 kg-cal/hr.) Maximum: 3793 BTU/hr. (956 kg-cal/hr.)
Power supply fan	92 mm x 32 mm variable speed
Energy Star®-compliant	Yes
Blue Angel compliant	N/A

Table 1-7 Power supply specifications (continued)

FEMP standby power compliant @ 115 V (<2W @ 115 V in S5–Power Off)	No
Power consumption in ES mode	<10 W
Suspend to RAM (S3) (Instantly Available PC)	

Power consumption and cooling

The following table shows the primary power consumption for an example configuration:

- Two Opteron 2216 processors, 2.4-GHz, 1-MB
- Four 1-GB, 667-MHz memory modules
- One 80-GB SATA hard drive
- Two optical drives (48x DVD-ROM, CD-RW)
- One PCI Express graphics card (nVidia FX1500, 256MB)
- One diskette drive
- One monitor, powered separately

Table 1-8 Example Energy consumption*

	115 VAC	230 VAC	100 VAC
Windows Idle (S0)	226 W	224 W	228 W
Windows Busy (S0)	330 W	329 W	336 W
Sleep (S3)	6.3 W	8.8 W	6.0 W
Off(S5)	2.3 W	5.8 W	2.3 W

* Energy Star low energy mode.

Table 1-9 Example heat dissipation*

	115 VAC	230 VAC	100 VAC
Windows Idle (S0)	772 BTU/hr.	765 BTU/hr.	779 BTU/hr.
Windows Busy (S0)	1127 BTU/hr.	1123 BTU/hr.	1147 BTU/hr.
Sleep (S3)	21.5 BTU/hr	30 BTU/hr.	20.5 BTU/hr.
Off(S5)	7.8 BTU/hr.	19.8 BTU/hr.	7.8 BTU/hr.

* Heat dissipation calculation is based on measured watts, assuming the service level is attained for one hour.



NOTE When you power down your workstation with the power button on the front panel, the power consumption falls below 10 W. To reach zero power consumption, unplug the workstation from the power outlet or use a power strip with a switch.

For additional information on power-saving features, see your operating system documentation.

System fans and airflow

The workstation includes one rear system fan, one memory fan, one processor (CPU) heatsink fan for each processor, and one power supply fan, plus a front system fan.

Resetting the power supply

If an overload triggers the power supply overload protection, all power is immediately shut off. To reset the power supply unit:

1. Disconnect the power cord.
2. Determine what caused the overload and fix the problem.
3. Reconnect the power cord and reboot the workstation.

When you power down the workstation through the operating system, power consumption falls below the low power consumption rate but does not reach zero. This on/off feature extends the life of the power supply.

Power cord requirements

The power cord set (flexible cord or wall plug) received with this product meets the requirements for use in the country where you purchased the equipment.

If you must obtain a power cord for a different country, you should purchase a power cord that is approved for use in that country.

The power cord must be rated for the product and for the voltage and current marked on the product's electrical ratings label. The voltage and current rating of the cord should be greater than the voltage and current rating marked on the product. The length of the cord must be between 6 feet (1.8 m) and 12 feet (3.6 m). If you have questions about the type of power cord to use, contact the HP authorized service provider.

A power cord should be routed so that it is not likely to be walked on or pinched by items placed on it or against it. Particular attention should be paid to the plug, electrical outlet, and the point where the cord exits from the product.



NOTE A 15AMP-capable (minimum) power cord must be used in with a 110-V power source. A 10AMP-capable (minimum) power cord should be used with a 220-V power source.

Environmental specifications

This section describes environmental specifications of your workstation.

Table 1-10 Environmental Specifications

Temperature (operating)	40° to 95° F (5° to 35° C)*
--------------------------------	-----------------------------

Table 1-10 Environmental Specifications (continued)

Temperature (non-operating)	-40° to 140° F (-40° to 60° C)
Humidity (operating)	8% to 85% RH, non-condensing
Humidity (non-operating)	8% to 90% RH, non-condensing
Maximum Altitude (operating)	0 to 10,000 ft. (3,048 m)
Maximum Altitude (non-operating)	0 to 30,000 ft. (9,144 m)
Shock (operating)	1/2-sine: 40 G, 2–3 ms
Shock (non-operating)	1/2-sine: 160 cm/s, 2–3 ms, (approximately 100 G) square: 605 cm/s, 30 G
	 NOTE Values represent individual shock events and are not indicative of repetitive shock events.
Vibration (operating)	Operating random: 0.5 G (rms), 5–300 Hz
Vibration (non-operating)	Random: 2.0 G (rms), 10–500 Hz
	 NOTE Values are not indicative of continuous vibration.

* Operating temperature is specified at 5° to 35° C from sea level to 5000 ft. with an altitude derating of 1.0° C per every 300 m (1000 ft.) above 5000 ft. to a maximum of 3000 m (10,000 ft.), no direct sustained sunlight. Maximum rate of change is 10° C/Hr. The upper limit may be limited by the type and number of options installed.

PCI card slot power specification

Table 1-11 PCI and PCI Express slot power specifications

Slot#	Slot Type	Slot Power (Maximum)
1	PCI Express x16 (x8)	25 W*
2	PCI Express x16 graphics	150 W**
3	PCI 32 bit, 33 MHz	25 W*
4	PCI Express x16 (x8)	25 W*
5	PCI Express x16 graphics	150 W**
6	PCI-X 100	25 W*
7	PCI-X 100/133	25 W*

* In addition to these slot power specifications, the overall power consumption of the system (including I/O cards, processor, and memory) must not exceed the maximum ratings of the system power supply. See [Power supply specifications on page 7](#) for details.

** Includes 75 W maximum from the system board connector, and 75 W maximum from the auxiliary graphics power connector.



NOTE If a graphics card requiring more than 75W is installed in Slot 2, HP recommends not using slot 3, which is the PCI slot below the graphics slot. If a graphics card requiring more than 75W is installed in slot 5, HP recommends not using slot 6, which is the PCI-X 100 slot below the graphics slot. In addition to these slot power specifications, the overall power consumption of the system (including I/O cards, processors, memory, and drives) must not exceed the maximum ratings of the system power supply. Also, there are broad restrictions on using dual 150W graphics cards.

For hardware specifications of other system components, such as graphics cards or optical drives, see the website of the specific manufacturer.

Chipkill support

Chipkill is a form of advanced Error Checking and Correcting (ECC) computer memory technology. The HP xw9400 Workstation supports 128-bit Chipkill ECC memory functionality. Standard ECC functionality detects and corrects single bit data errors in memory systems. But Chipkill offers greater memory error protection by providing error correction for up to 4-bit errors within the same symbol (nibble boundary). Chipkill cannot correct any random four bits across 128 bits.

Chipkill on the xw9400 functions within these parameters:

- The workstation enables Chipkill functionality on paired ECC memory DIMMs only.
- The use of single memory DIMM—not supported on the xw9400 workstation—allows standard single bit ECC only.
- Chipkill can detect and correct up to four bit errors if the four bits are in the same symbol. That is, multiple bit errors in bits 0–3 or 4–7 of a byte can be detected and corrected. Multi-bit error that overlap or span symbol boundaries (bits 2–5 or 3–6, for example) cannot be corrected. For DIMMs that are based on x4 parts, this means that a single DRAM chip can fail and the system will continue to operate. For x8 and x16 parts, a complete DRAM chip cannot fail, but symbol errors will be corrected as described.

Energy Star®

The Energy Star program, a government-backed initiative, promotes energy efficiency by identifying ways to reduce energy consumption. Select HP workstations participate in the Energy Star program.



NOTE Energy Star is not supported on Linux-based workstations.

For those workstations that support Energy Star and have it enabled, the power management features are set as follows:

- The monitor goes into power savings mode after 20 minutes of inactivity.
- The system goes into standby mode after 20 minutes of inactivity



NOTE If you have to restore the operating system, reset the Energy Star settings (if applicable) after the restore.

To verify the factory default power settings for your product, select **Start>Control Panel** and double-click **Power Options**.

Energy Star compliance

HP products purchased with the Energy Star configuration are compliant with U.S. Environmental Protection Agency (EPA) Computers Program. The EPA Energy Star configuration does not imply endorsement by the EPA. As an Energy Star partner, HP offers products with the Energy Star configuration to meet the Energy Star guidelines for energy efficiency.

EPA created the Energy Star Computers Program to promote energy efficiency and reduce air pollution through more energy-efficient equipment in homes, offices, and factories. HP products achieve this result by reducing the power consumption when not being used.

Energy Star on HP workstations uses Advanced Configuration and Power Interface (ACPI) power management. The system can wake as a result of a user action (keyboard or mouse) or from the network or a modem.

The Power Management feature, when used in conjunction with an Energy Star-compliant monitor, will support the power-down features of the monitor. The Power Management feature allows a monitor to go into low-power mode when the Energy Save timeout occurs.



NOTE Using the Energy Star Save Monitor feature with non-Energy Star-compliant monitors might cause video distortion when the Energy Save timeout occurs.

2 Installing or restoring the operating system

This chapter describes the installation and restoration of the operating system.

- [Installing the operating system and software on page 16](#)
- [HP software on page 18](#)
- [Restoring the operating system on page 19](#)
- [Protecting the software on page 22](#)

If your workstation was shipped with a preinstalled operating system, it is configured automatically the first time your workstation is powered on. This process may take a few minutes.

Adding optional hardware devices to your workstation before the operating system successfully installs can cause errors and prevent the operating system from installing properly.



CAUTION After the automatic installation has begun, do not power off your workstation until this process completes. Powering off your workstation during the installation process might damage the software that runs the system.

Installing the operating system and software

The following sections discuss operating system and HP software installation procedures.

Microsoft Windows XP Professional

The first time you power on your workstation, you are prompted to select a language for the operating system. After selecting the language, read and follow the instructions on the screen to complete the installation of the operating system. This process takes approximately 10 minutes, depending on the system hardware configuration. During the process, do not power off your workstation unless you are directed to do so.

Installing or upgrading device drivers

To install hardware devices, such as a printer, a display adapter, or network adapter after the operating system installation is completed, the operating system needs access to the appropriate software drivers for the devices. Device drivers are usually provided on a CD supplied with the peripheral device.

Some existing peripheral devices might not have been shipped with drivers developed for Windows XP. To locate the most current device drivers, see <http://www.hp.com/go/workstationsupport>.

Linux-preinstalled workstations

If you have a Linux-preinstalled workstation, follow the instructions in this section to set up your operating system and software.

After the boot process completes, you can view additional HP Linux documentation by opening your Internet browser (the browser is automatically set to use the local HP documentation page as its default). You can also access Linux Web links for Red Hat (Internet access required) by using your Internet browser.

For additional information about setting up Linux-preinstalled or Linux-enabled workstations, refer to the *HP User Manual for Linux* at http://www.hp.com/support/linux_user_manual.

For more information about HP and Linux, see <http://www.hp.com/linux>.

Starting the Linux operating system

The first time your workstation is booted, the Red Hat First Boot utility displays. This program enables you to enter your password, network, graphics, time, and keyboard settings for your workstation.



CAUTION After the automatic installation has begun, do not power down your workstation until the process is complete. Powering down your workstation during the installation process might damage the software that runs your workstation or prevent its proper installation.

When you enable the YPBind feature in the Network tab of the Linux Setup Tool, you might get a blank screen for about 15–30 seconds after you have selected and saved all of your settings and exited the utility. This behavior is normal. The boot process continues its execution after the screen returns.

Upgrading device drivers

Once your workstation is up and running, visit <http://www.hp.com/go/workstationsupport> to see if there are newer device drivers available for your workstation and/or components.

Linux-enabled workstations

Linux-enabled workstations are not preinstalled with Linux. They require the HP Installer Kit for Linux and the purchase of a Red Hat box set. The Installer kit includes the HP CDs necessary to complete the installation of all versions of the Red Hat box set that have been verified to work on HP workstation hardware.

Verifying hardware compatibility

To determine which Linux versions have been verified to work on HP workstation hardware:

1. Go to http://www.hp.com/support/linux_hardware_matrix.
2. Select your HP workstation model.

Installing the Linux operating system

To install the Linux operating system on your Linux-enabled system, follow the instructions for [Restoring the Linux operating system on page 21](#) in this chapter.

For more information concerning the setup of Linux-preinstalled or Linux-enabled workstations, refer to the *HP User Manual for Linux* located at http://www.hp.com/support/linux_user_manual.

For more information about HP and Linux, see <http://www.hp.com/linux>.

Red Hat Activation

An activation card called *Activate Your Subscription* is shipped with your workstation. This card is necessary to activate your Linux subscription with Red Hat Network. Until activation, your Red Hat Linux is not fully enabled.

To activate Red Hat Linux, click the **Activate Your Subscription** icon on your desktop. This takes you to www.redhat.com/activate. Follow the instructions at this website to activate your subscription using the information on the card.

HP recommends that you activate your subscription as soon as you connect to the web.



NOTE Keep the Red Hat activation card with your workstation registration card for future reference.

HP software

The following HP software may be installed on your workstation depending on the operating system and options:

- Computer Setup (F10) Utilities and diagnostic features
- HP Support Software including device drivers
- Security Management tools
- Software Support Management tools

Additional software is available for download:

- HP Client Manager Software is available at <http://www.hp.com/go/easydeploy>.
- System Software Manager is available at <http://www.hp.com/go/ssm>.



NOTE Additional HP software might be required in certain situations.

Restoring the operating system

This section describes how to restore the Windows and Linux operating systems.

Restoring the Windows operating system

Your workstation has a several methods to restore your Windows XP operating system to a near-factory state, or to the state of the system at a predefined snapshot in time. Your system has a recovery partition on the system hard drive that contains software and data required for the restore process as described in the following sections.



NOTE If you received restore media with your system, use the media to restore your operating system. Refer to the instructions on the media for restoring your operating system.

The RestorePlus! process

The Windows operating system and device drivers (for devices shipped with the system) are reinstalled using this process. Some application software may not be restored using the RestorePlus! process. In this case you must install the application software from the appropriate application CD. The RestorePlus! process can be executed from CD or from the recovery partition contained on your system hard drive.



CAUTION Backup your data before you attempt any operating system restore. All data on the Windows partition will be deleted when you restore using the RestorePlus! process. However, the recovery partition on the system drive and other partitions should not be affected.

Creating a RestorePlus! CD

You can create a set of the CDs from your system if you have a CD burner. When you first boot your system, you will be prompted to make CDs for RestorePlus!, the Windows operating system, and a supplemental HP Backup and Recovery Manager CD. (There may be additional CDs you can create depending on the options you purchased.) You also have the option to move images of the CDs to another location, such as a network share, to be burned to CD at a later time or from another system.

Restoring from RestorePlus! CDs

The RestorePlus! process can be started by booting from the RestorePlus! CD.

Restoring from RestorePlus! on the Recovery Partition

Follow these steps to start the RestorePlus! process from the Emergency Recovery menu:

1. Boot the workstation.
2. Press the **F11** key when prompted during the boot process to enter the Emergency Recovery menu. The F11 prompt appears briefly during the boot process.
3. Select **Recover PC's factory installed operating system, drivers, utilities, and applications** from the Emergency Recovery menu.



NOTE Some applications may not be restored using this method.

HP Backup and Recovery Manager restore points

HP Backup and Recovery Manager is preinstalled on your workstation. This software allows you to backup and restore your system and data. You will be prompted to make RestorePlus! CDs at the first boot of the system. An Initial Restore Point (IRP) will be created automatically. This restore point is a complete snapshot of the system partition at the time the IRP was created. The IRP is stored in the recovery partition on the system hard drive, but you can also burn the IRP to CDs, DVDs, or copy it to another location. The restore point can be used to return the system partition back to the state the system was when captured.

Restoring from the HP Backup and Recovery Manager restore point CD/DVDs

The HP Backup and Recovery Manager (HPBR) restore point can be burned to CD or DVD and used to restore the system. Typically you would use the CD/DVD set if the hard drive has been replaced or all partitions have been corrupted. Boot the system from the HPBR restore point CD/DVD and follow the online instructions.

Restoring from the HP Backup and Recovery Manager restore point on the Recovery Partition

The HP Backup and Recovery Manager (HPBR) Initial Restore Point is stored in the system recovery partition and can be restored using the Emergency Recovery menu. Boot your system and press the **F11** key when prompted to enter the Emergency Recovery menu. The F11 prompt appears briefly during the boot process. From the Emergency Recovery menu, choose **Recover PC to a specific point in time** and follow the instructions.

Reclaiming hard disk space from the recovery partition

The recovery partition can be removed to reclaim the hard drive space. If the recovery partition is removed, the **F11** Emergency Recovery function is not available. The ability to recover the system from data on the recovery partition will be lost. Any RestorePlus! media contained in the recovery partition will be deleted. The ability to create the RestorePlus! CD set will be lost.

To free up disk space, you can remove just the recovery partition, or you can completely uninstall the HP Backup and Recovery Manager application.

- The recovery partition can be removed using **Remove HP Recovery Partition** in the HP Backup & Recovery program folder. The recovery partition is deleted, the user partition is extended to reclaim the unused hard drive space, and the F11 boot prompt is removed. The HP Backup and Recovery Manager application remains and can be used for data backup and restore.
- The HP Backup and Recovery Manager application can be uninstalled using the Windows **Control Panel>Add/Remove Programs** utility. The application is uninstalled, the recovery partition is deleted, the user partition is extended to reclaim the unused space, and the F11 boot prompt is removed. Emergency recovery as well as data backup and recovery is not possible after the application is uninstalled.



CAUTION Deleting the recovery partition or uninstalling the HP Backup and Recovery Manager application reduces or eliminates the ability to recover the system.

Ordering backup software

If you are unable to create system recovery CDs or DVDs, the HP Restore Plus CD set can be obtained through product support on <http://www.hp.com/support>.



NOTE Before calling HP to order the software, be sure to have the serial number of your workstation available. See [Serial number and COA label location on page 5](#) for details.

Restoring the Linux operating system



NOTE To restore the Linux operating system, the HP Driver CD and Red Hat box set are required. Download the latest HP Driver CD to get any new enhancements.

For preloaded Linux systems, an icon called **Red Hat ISO's** is available on the desktop. Click this icon to go to the `/iso` directory. This directory contains the binary and source ISO files. This directory also contains the driver CD ISO which is the same as the CD that is shipped with the workstation. Follow the instructions in the **Readme** file in the `/iso` directory to burn the ISOs to CD.

HP recommends that you burn the ISOs to CD so you have a backup.



NOTE Linux does not support mixed drive types for a manufacturing preload. However, Linux supports mixed drives and you may restore the operating system with mixed drives from the RHEL box set.

Downloading the latest HP driver CD contents

See <http://www.hp.com> and select **Software and Drive Downloads**. Find your workstation and operating system. Select your driver CD under **Software**, and follow the directions under **Release Notes**.

Installing the operating system with the HP driver CD contents

1. Boot your workstation from the Red Hat box set Binary CD 1.
2. Insert the Linux operating system CDs from the Red Hat box set as prompted.
3. Continue following the prompts until the operating system is successfully installed.
4. Configure the X server to start on reboot.
5. Reboot your workstation.
6. Follow the prompts to set up your system with the Red Hat First Boot utility.
7. When prompted in First Boot to add additional CDs, insert the HP Driver CD into the CD-ROM tray of your workstation.
8. Click **Install** next to “Additional CDs.” The HP Driver CD window opens.
9. Click **Press** to begin install.

When the install is done, you will have two options— **Reboot now...** on the left side and **Press to continue, reboot later...** on the right side.

10. Click **Reboot now...**

Protecting the software

To protect software from loss or damage, keep a backup copy of all system software, applications, and related files stored on the hard drive. See the operating system or backup utility documentation for instructions on making backup copies of data files.

3 System management

This section describes the various tools and utilities that allow for the system management of the workstation.

- [Computer Setup \(F10\) Utility on page 24](#)
- [Desktop management on page 34](#)

Computer Setup (F10) Utility

The Computer Setup Utility enables you to:

- Change current settings from the factory default settings.
- Modify or restore factory default settings.
- Determine if all of the devices installed on the workstation are recognized by the system and functioning properly.
- Determine information about the operating environment of the workstation.
- Solve system configuration errors detected but not automatically fixed during the Power-On Self-Test (POST).
- Establish and manage security features and password prompting during system reset and during power-on.
- Establish and manage energy-saving time-outs (not supported for Linux platforms).
- Set the system date and time.
- Set, view, and change the system configuration, including settings for processor, graphics, memory, audio, storage, communications, and input devices.
- Modify the boot order of installed mass storage devices such as hard drives, diskette drives, optical drives, and network drives.
- Enable or disable Network Server Mode, which enables the workstation to boot the operating system when the power-on password is enabled with or without a keyboard or mouse attached. When attached to the system, the keyboard and mouse remain locked until the power-on password is entered.
- Enable/disable POST Messages to change the display status of POST messages. POST messages disabled suppresses most POST messages, such as memory count, product name, and other non-error text messages. If a POST error occurs, the error is displayed regardless of the mode selected. To temporarily switch to POST messages enabled, press any key (except F1 through F12) during POST.
- Establish an Ownership Tag, the text of which is displayed each time the system is turned on or restarted.
- Enter the Asset Tag or property identification number assigned by your company to this workstation.
- Secure the integrated I/O functionality, including the serial and USB ports, audio, embedded NIC, SAS, or IEEE 1394 so that the I/O functionality cannot be used until they are unsecured.
- Enable or disable removable media boot ability.
- Enable or disable removable media write ability (when supported by hardware). Used commonly for legacy diskettes.
- Replicate your system setup by saving system configuration information onto diskette or USB, or restoring it onto one or more workstations.

BIOS ROM

The BIOS of the computer is a collection of programs stored as firmware in ROM. The BIOS ROM includes such functions as POST, PCI device initialization, Plug 'n' Play support, power management activities, and the Computer Setup Utility. BIOS supports the following systems and specifications:

- Dual AMD Opteron 2xxx series processors
- Up to DDR2-667 memory
- HyperTransport setup and initialization
- Chipset (includes NVIDIA nForce Professional 3600 and 3050 with NEC μ PD720404 PCIe to PCI-X bridge)
- ACPI 1.0b with ACPI 2.0 extensions for 64-bit support, according to Microsoft Logo Requirements. S1, S3, S4, and S5 with Remote Power On by way of LAN wake packet.
- SMBIOS Spec 2.5 implementation and field definitions that accurately represent hardware configurations and OEM ID
- BBS 1.01
- DOS and Windows based BIOS flash tools
- Microsoft SDG 3.0 compliant as applicable
- PMM 1.01 as applicable
- MPS 1.4 as applicable
- PXE 2.1
- USB 1.1/USB 2.0
- PCI 2.2 or later
- "El Torito" Bootable CD 1.0

The BIOS ROM is a 1-MB FLASH unit. The runtime portion of the BIOS resides in a 96-KB block from E8000h to FFFFh (approximately). ACPI code and data take about 128 KB below TOLM (top of low memory, the last RAM address below 4 GB).

Using Computer Setup (F10) Utility

You can call up the Computer Setup Utility during workstation restart or power on. To access the Computer Setup Utility menu:

1. Power on or restart the workstation.
2. Press the **F10** key as soon as your display is active and the message **Setup** appears in the lower right corner of the screen.



NOTE If you miss the opportunity to press F10, restart the workstation and press **F10** again. Or, you can press **Ctrl+Alt+Delete** prior to boot .

3. At first boot, select your language from the list, and press the **Enter** key. In the Computer Setup Utility menu, five headings are displayed: **File**, **Storage**, **Security**, **Advanced**, and **I/O**.

4. Use the left and right arrow keys to select the appropriate heading. Use the up and down arrow keys to select the option you want, and press **Enter**.
5. To apply and save changes, select **File>Save Changes and Exit**.
 - If you have made changes that you do not want applied, select **File>Ignore Changes and Exit**.
 - To reset to factory settings, select **File>Default Setup>Restore Factory Settings as Default**. Press **F10** to accept the changes. Click **File>Apply Defaults and Exit**. This option restores the original factory system defaults.



CAUTION Do **not** turn the workstation power off while the ROM is saving your Computer Setup Utility changes because the CMOS could become corrupted. After you exit the F10 Setup screen, it is safe to remove all power from the workstation.

Computer Setup (F10) Utility menu



NOTE The following content is subject to change with new BIOS releases, so your menu may be different than shown in Table 1–1.

Table 3-1 Computer Setup Utility menu descriptions

Heading	Option	Description
File	System Information	Lists product name, SKU number, processor type/speed/stepping, cache size (L1/L2), memory type and size, integrated Media Access Control (MAC) IDs for Network Interface, system BIOS type, chassis serial number, and asset tracking number.
	About	Displays copyright information.
	System Temperatures	Displays temperature graph.
	Set Time and Date	Enables you to set system time and date.
Replicated Setup	Save to Removable Media	Saves the current F10 Setup configuration to a text file called <code>cpqsetup.txt</code> .
	Restore from Removable Media	Restores previous F10 Setup configuration from a text file called <code>cpqsetup.txt</code> .
	Default Setup	Save Current Settings as Default Stores the current F10 Setup configuration as the default.
Default Setup	Restore Factory Settings as Default	Restores the original factory settings to the F10 Setup configuration information as the default.
	Apply Defaults and Exit	Saves the selected default settings (previously-saved user or factory settings) and exits the Computer Setup Utility.
	Ignore Changes and Exit	Exits the Computer Setup Utility without applying or saving any changes.
	Save Changes and Exit	Saves changes to system configuration and exits the Computer Setup Utility.

Table 3-1 Computer Setup Utility menu descriptions (continued)

Heading	Option	Description
Storage	Device Configuration	<p>Lists all installed non-SAS and non-SATA storage devices.</p> <p>When a device is selected, detailed information and options are displayed.</p> <hr/> <p>CD-ROM</p> <p>Identifies the optical drives on the system.</p> <hr/> <p>Diskette (for legacy diskette drives only)</p> <p>Identifies the highest capacity media type accepted by the diskette drive. Options are 3.5" 1.44 MB, 5.25" 1.2 MB, and Not Installed.</p> <hr/> <p>Default Values</p> <p>Enables you to set the default values for IDE and SATA devices such as the following:</p> <ul style="list-style-type: none">• Multisector Transfers (IDE devices only)—Specifies how many sectors are transferred per multi-sector Programmed Input/Output (PIO) operation. Options (subject to device capabilities) are Disabled, 8, and 16.• Transfer Mode (IDE devices only)—Specifies the active data transfer mode. Options (subject to device capabilities) are PIO 0, Max PIO, Enhanced DMA, Ultra DMA 0, and Max UDMA.• Translation Mode (IDE/SATA disks only)—Enables you to select the translation mode to be used for the device, which enables the BIOS to access disks partitioned and formatted on other systems and may be necessary for users of older versions of UNIX (for example, SCO UNIX version 3.2). Options are Bit-Shift, LBA Assisted, Off, User, and Automatic. <hr/> <p> NOTE The Automatic option allows BIOS to automatically determine the translation mode used to configure a previously-formatted IDE, SATA, or USB mass storage device. Hence, you do not have to know how the mass storage device was previously formatted.</p> <hr/> <p>Ordinarily, the translation mode selected automatically by the BIOS should not be changed. If the selected translation mode is not compatible with the translation mode that was active when the disk was partitioned and formatted, the data on the disk will be inaccessible.</p>

Table 3-1 Computer Setup Utility menu descriptions (continued)

Heading	Option	Description
Storage Options	Removable Media Boot	Enables/disables ability to boot the system from removable media.
	Legacy Diskette Write	Enables/disables ability to write data to legacy media.
	BIOS DMA Data Transfers	Enables/disables DMA transfers for IDE and SATA devices when possible during POST to increase transfer speed.
	SATA Controller #0	Enables/disables SATA controller 0.
	SATA Controller #1	Enables/disables SATA controller 1.
	SATA Controller #2	Enables/disables SATA controller 2.
	IDE Controller	Enables/disables IDE controller.
	Boot Order	Enables you to configure the boot, diskette drive, and hard drive orders by physically reordering the menu entries. Each device on the list can be individually excluded from or included for consideration as a bootable operating system source. Boot Order presents these selections: <ul style="list-style-type: none"> • Optical drive • Diskette drive • USB device • Hard drive • Network controllers (2) <p>Boot devices can be disabled from participating in the boot order process. Boot order changes are stored when the F10 Setup changes are confirmed by selecting File>Save Changes and Exit.</p> <p> NOTE MS-DOS drive lettering assignments might not apply after a non-MS-DOS operating system has started.</p> <p>Shortcut to Temporarily Override Boot Order</p> <p>To boot one time from a device other than the default device specified in Boot Order, restart the workstation and press the F9 key when the F9=Boot Menu message appears on the screen. After POST is completed, a list of bootable devices is displayed. Use the arrow keys to select the preferred bootable device and press Enter. The workstation then boots from the selected device for this one time.</p>

Table 3-1 Computer Setup Utility menu descriptions (continued)

Heading	Option	Description
Security	Setup Password	<p>Enables you to set and enable setup (administrator) password.</p> <p> NOTE If the setup password is set, you must enter Computer Setup Utility to change it, flash the ROM, and make changes to certain plug-and-play settings under Windows.</p>
	Power-On Password	<p>Enables you to set and enable the power-on password.</p> <p> NOTE If a power on-password is set, or the workstation cover removal sensor is activated, entries for these items will appear in this list.</p>
Device Security		<p>Makes the following devices available or hidden to the system:</p> <ul style="list-style-type: none"> • Serial Port • All USB Ports • External USB ports • Front USB Ports • System Audio • IEEE 1394 Controller • Network Controller 1 • Network Controller 2 • Onboard SAS Controller • Embedded Security Device <p>For each device, Device available is the default setting and allows the operating system access to the device. Device hidden makes the device unavailable; it is disabled by the BIOS and cannot be enabled by the OS.</p>
Network	Service Boot	<p>Enables/disables a Network Service Boot which boots using the NIC PXE option ROM. In this case, the actual boot image resides on a remote server. When enabled, you can set the boot order of the NIC PXE option ROM and you can force a network boot by pressing F12 during POST.</p>
System IDs	Asset Tag	<p>A 16–byte string identifying the system.</p>
	Ownership Tag	<p>An 80–byte string identifying ownership of the system. This tag is displayed on the screen during POST.</p>
	UUID (Universal Unique Identifier)	<p>Can only be updated if the current chassis serial number is invalid. (These ID numbers are normally set in the factory and are used to uniquely identify the system.)</p>
	Keyboard	<p>Enables you to set the keyboard locale for System ID entry.</p>
OS Security		<p>Enables/disables Data Execution Prevention mode in the processors. This mode prohibits code from running in pages that were set up as data pages, and prevents attacks such as buffer overflows. Operating system support is required for this feature.</p>

Table 3-1 Computer Setup Utility menu descriptions (continued)

Heading	Option	Description
Advanced **	Power-On Options	POST Mode (QuickBoot, FullBoot, or FullBoot every 1–30 days)
		Quick boot is faster by skipping some steps such as the full memory test.
		POST Messages (Enable/Disable).
		When enabled, POST displays non-error messages to the screen.
		F9 Prompt (Displayed/Hidden)
		Displays F9=Boot Menu during POST. Hiding this feature prevents the text from being displayed, but pressing F9 still calls up the boot menu.
		F10 prompt (Displayed/Hidden)
		Displays F10=Setup during POST. Hiding this feature prevents the text from being displayed but pressing F10 still accesses the Setup screen.
		F12 prompt (Displayed/Hidden)
		Displays F12=Network Service Boot during POST. Hiding this feature prevents the text from being displayed, but pressing F12 still forces the system to attempt booting from the network.
		Option ROM* Prompt (Enable/Disable)
		When enabled, causes the system to display a message before loading options ROMs.
		Remote Wakeup Boot Source
Enables you to specify which boot device to use after a remote wake event.		
After Power Loss (Off/On/Previous State)		
In the event of an AC power loss, determines system behavior when power is restored. Options are Off (stay off), On (turn on immediately), and Previous State (if the computer was on when power was lost, power on immediately; if it was off, stay off).		
POST Delay (in seconds) (None, 5, 10, 15, 20)		
Specifies a delay during POST. This setting may be necessary for certain add-in peripherals that respond slowly or violate specifications. For instance, disk drives should spin up within 15 seconds, but some older drives might take longer.		
Setup Browse Mode (Enable/Disable)		
Enables viewing Setup Options without entering Setup password. Enable allows you to view Setup in read-only mode if you do not enter the Setup password. Disable blocks Setup entirely if you do not enter the Setup password. This option is only valid if a Setup password is set.		
Thermal	Fan Idle Mode	This setting changes the minimum fan speed. The fans are still automatically controlled.
		The internal fans of the system are controlled automatically to guarantee proper operation of any configuration shipped from the factory. However, some customers with cards and configurations with special thermal/cooling needs may need to increase the minimum spinning speed of the fans in the system. They can do so by using this menu and selecting a higher minimal fan speed.
BIOS Power-On		Enables you to disable or specify a day and time for BIOS power-on.
OS Power Management	ACPI S3 Support (Enable/Disable)	Enables/disables ACPI S3 suspend-to-RAM (Standby) from OS.
		ACPI S3 Hard Disk Reset (Enable/Disable)

Table 3-1 Computer Setup Utility menu descriptions (continued)

Heading	Option	Description
		When awakening from the ACPI S3 state, reset IDE hard drive before returning to the OS.
		ACPI S3 PS2 Mouse Wake Up (Enable/Disable) Allow the mouse to awaken the system from the ACPI S3 state.
		USB Wake on Device Insertion (Enable/Disable) Awaken the system from ACPI S3 state on USB device insertion.
	Execute Memory Test	System re-boots and executes the memory test.
	Chipset/ Memory	ECC Support (Enable/Disable) Enables/disables memory Error Correcting Code (ECC). Memory Scrubbing (Enable/Disable) Enables/disables memory ECC scrubbing. If ECC Support is enabled, the scrubbing feature walks through memory in the background to avoid accumulation of ECC errors in memory. Upon detection of an ECC error, either during the scrubbing walk-through or during normal processor-to-memory operation, the scrubbing mechanism corrects the data and writes it back into the corresponding memory DIMM module. Memory Node Interleave (Enable/Disable) This option is valid for dual-processor systems only. If enabled, BIOS interleaves the memory on CPU0 and CPU1 together. This option requires the total memory installed on CPU0 (slots 1a/1b/3a/3b) and on CPU1 (slots 2a/2b/4a/4b) to be the same. If disabled, BIOS maps the memory connected to CPU0, then the memory connected to CPU1. The system is then effectively in NUMA mode. PCI SERR# Generation (Enable/Disable) Disables PCI SERR# generation for ill-behaved PCI add-in cards that can generate spurious SERRs. NET Watchdog Timer (Enable/Disable) Enables/disables the watchdog timer. ACPI Bus Segmentation (Enable/Disable) Enables/disables PCI bus segmentation. Disabling this option may prevent installation issues with some Linux implementations. HPET (Enable/Disable) Enables/disables the High Precision Event Timer. This feature must be enabled to use low power settings (PowerNow!). Some Linux implementations may require disabling this feature.

Table 3-1 Computer Setup Utility menu descriptions (continued)

Heading	Option	Description
I/O**	APIC Interrupts	<p>APIC</p> <p>Allow manual configuration of system IRQs.</p> <p>For more details on using this feature and on maximizing interrupt performance, refer to the <i>Optimizing APIC Interrupt Assignments on the xw9400</i> white paper available at http://tclperf.fc.hp.com/performance_briefs/index.htm.</p>
	Onboard Devices	<p>Disable or set IRQ, DMA, and I/O Range values for legacy devices.</p>
	PCI Devices	<p>Disable or select IRQ values for PCI devices.</p>
	Device Options	<p>NIC PXE Option ROM Download (Enable/Disable)</p> <p>Disable means you cannot boot from this device, but more option ROM space is available for other devices.</p> <p>Onboard SAS Option ROM Download (Enable/Disable)</p> <p>Disable means you cannot boot from SAS drives, but more option ROM space is available for other devices.</p> <p>SATA Option ROM Download (Enable/Disable)</p> <p>Enables or disables downloading embedded SATA option ROM. Disable means you cannot boot from SATA devices, but more option ROM space is available for other devices.</p> <p>SATA RAID (Enable/Disable)</p> <p>Enables or disables SATA drives for a RAID. If disabled, a single line is displayed. If enabled, the menu expands to allow enabling/disabling each SATA port.</p> <p>Num Lock State at Power-On (Off/On)</p> <p>Sets the keyboard Num Lock state after POST. The Operating System can change this state, also.</p> <p>S5 Wake on LAN (Enable/Disable)</p> <p>Allows the network to wake the system from shutdown (ACPI S5). When set to Disable, system power consumption is reduced to match Federal Energy Management Program (FEMP) guidelines.</p> <p>Unique Sleep State Blink Rates (Enable/Disable)</p> <p>Assigns different LED blink patterns for S1 and S3. (The system LED is off for S4 and S5.)</p> <p>Monitor Tracking (Enable/Disable)</p> <p>Enabling this option allows the ROM to save the monitor asset tracking information such as the serial number and model.</p>
	Slot Options	<p>Modifies options for:</p> <ul style="list-style-type: none"> • Slot 1—PCI Express x8 • Slot 2—PCI Express x16 graphics • Slot 3—PCI 32 bit, 33 MHz • Slot 4—PCI Express x16 (x8) • Slot 5—PCI Express x16 graphics • Slot 6—PCI-X 100 • Slot 7—PCI-X 100/133

Table 3-1 Computer Setup Utility menu descriptions (continued)

Heading	Option	Description
		For PCI Express slots, the available option is Option ROM Download .
		For PCI and PCI-X slots, the available options are Option ROM Download and Latency Timer .

* Available on select models.

** These options should be used by advanced users only.

Desktop management

HP Client Management Solutions (available for download from <http://www.hp.com/go/easydeploy>) provides standards-based solutions for managing and controlling workstations in a networked environment. This section summarizes the capabilities and features of desktop management key components:

- [Initial configuration and deployment on page 34](#)
- [Remote system installation on page 34](#)
- [Managing and updating software on page 35](#)
- [ROM flash on page 37](#)
- [Asset tracking and security on page 41](#)
- [Fault notification and recovery on page 47](#)



NOTE Support for specific features described in this guide might vary by model or software version.

Initial configuration and deployment

The workstation comes with a preinstalled system software image. After a brief software unbundling process, the workstation is ready to use.

You might prefer to replace the preinstalled software image with a customized set of system and application software. There are several methods for deploying a customized software image, including:

- Installing additional software applications after unbundling the preinstalled software image.
- Using software deployment tools, such as Altiris® Deployment Solutions™, to replace the preinstalled software with a customized software image.
- Using a disk cloning process to copy the contents from one hard drive to another.

The best deployment method depends on your information technology environment and processes. The PC Deployment section of the HP Lifecycle Solutions website (<http://whp-sp-orig.extweb.hp.com/country/us/en/solutions.html>) provides information to help you select the best deployment method.

The Restore Plus! CD, ROM-based setup, and ACPI hardware provide further assistance with recovery of system software, configuration management and troubleshooting, and power management.

Remote system installation

Remote System Installation enables you to start and set up your system using the software and configuration information located on a network server. This feature is usually used as a system setup and configuration tool, and can be used for the following tasks:

- Deploying a software image on one or more new PCs
- Formatting a hard drive
- Installing application software or drivers
- Updating the operating system, application software, or drivers

To initiate Remote System Installation, press **F12** when **F12=Network Service Boot** appears in the lower-right corner of the HP logo screen. Follow the on-screen instructions to continue the process. The default boot order is a BIOS configuration setting that can be changed to always attempt to PXE boot.

HP and Altiris have partnered to provide tools designed to make the task of corporate PC deployment and management easier and less time-consuming, ultimately lowering the total cost of ownership and making HP PCs the most manageable client PCs in the enterprise environment.

Managing and updating software

HP provides several tools for managing and updating software on desktops and workstations—HP Client Manager Software, Altiris Client Management Solutions, System Software Manager, Proactive Change Notification, and Subscriber's Choice.

HP Client Manager software

HP Client Manager Software (HP CMS) assists you in managing the hardware aspects of your client workstations with features that include:

- Detailed views of hardware inventory for asset management
- PC health check monitoring and diagnostics
- Proactive notification of changes in the hardware environment
- Web-accessible reporting of business-critical details such as machines with thermal warnings, memory alerts, and more
- Remote updating of system software such as device drivers and ROM BIOS
- Remote changing of boot order
- Configuring the system BIOS settings

For more information on the HP Client Manager, see <http://h18000.www1.hp.com/im/prodinfo.html>.

Altiris Client Management solutions

HP and Altiris have partnered to provide comprehensive, tightly integrated systems management solutions to reduce the cost of owning HP client PCs. HP Client Manager Software is the foundation for additional Altiris Client Management Solutions that address:

- Inventory and asset management
 - Software license compliance
 - PC tracking and reporting
 - Lease contract and fixed asset tracking
- Deployment and migration
 - System deployment
 - Personality migrations

- Help desk and problem resolution
 - Managing help desk tickets
 - Remote troubleshooting
 - Remote problem resolution
 - Client disaster recovery
- Software and operations management
 - Ongoing desktop management
 - HP system software deployment
 - Application self-healing

See <http://h18000.www1.hp.com/im/prodinfo.html> for more information about:

- How HP Client Manager Software works
- Which solutions are compatible with your operating system
- How to download a fully-functional, 30-day evaluation version of the Altiris solutions

System Software Manager

System Software Manager (SSM) is a utility that enables you to update system-level software on multiple systems simultaneously. When executed on a PC client system, SSM detects both hardware and software versions and then updates the appropriate software from a central repository, also known as a file store. Driver versions that are supported by SSM are denoted with a special icon on the software, the driver download website, and the Support Software CD. To download the utility or to obtain more information on SSM, see <http://www.hp.com/go/ssm>.

Proactive Change Notification

The Proactive Change Notification program uses the Subscriber's Choice website to proactively and automatically send you:

- Proactive Change Notification (PCN) e-mails informing you of hardware and software changes to most commercial workstations and servers, up to 60 days in advance.
- E-mails containing Customer Bulletins, customer advisories, customer notes, security bulletins, and driver alerts for most commercial workstations and servers.

You create your own profile to ensure that you only receive the information relevant to a specific IT environment. To learn more about the Proactive Change Notification program and create a custom profile, see <http://www.hp.com/go/pcn>.

Subscriber's Choice

Subscriber's Choice is a client-based service from HP. Based on your profile, HP supplies you with personalized product tips, feature articles, and driver and support alerts and notifications. Subscriber's Choice Driver and Support Alerts/Notifications deliver e-mails notifying you that the information you subscribed to in your profile is available for review and retrieval. To learn more about Subscriber's Choice and create a custom profile, see <http://www.hp.com/go/pcn>.

ROM flash

The workstation comes with a programmable flash ROM. By establishing a setup password in the Computer Setup Utility, you can protect the ROM from being unintentionally updated or overwritten, which is important to ensure the operating integrity of the workstation. Should you need or want to upgrade the ROM, you can:

- Order an upgraded ROMPaq diskette from HP.
- Download the latest ROMPaq images from HP driver and support page, <http://www.hp.com/support/files>.



NOTE For maximum ROM protection, be sure to establish a setup password. The setup password prevents unauthorized ROM upgrades. System Software Manager enables you to set the setup password on one or more PCs simultaneously. For more information, see <http://www.hp.com/go/ssm>.

Remote ROM flash

Remote ROM Flash enables you to safely upgrade the ROM on remote HP workstations directly from the centralized network management console. Performing this task remotely on multiple workstations and personal computers results in a consistent deployment of and greater control over HP ROM images over the network. It also results in greater productivity and lower total cost of ownership.

The workstation must be powered on to use Remote ROM Flash.

For more information on Remote ROM Flash, see the HP Client Manager Software or System Software Manager at <http://h18000.www1.hp.com/im/prodinfo.html>.

HPQFlash

The HPQFlash utility is used to locally update or restore the system ROM on individual workstations through a Windows operating system.

For more information on HPQFlash, see <http://www.hp.com/support/files> and enter the name of your workstation when prompted.

FailSafe Boot Block ROM

The FailSafe Boot Block ROM allows for system recovery in the unlikely event of a ROM flash failure, for example, if a power failure occurs during a ROM upgrade. The Boot Block is a protected section of the ROM that checks for a valid system ROM flash when the system is powered on.



NOTE System recovery can use a removable medium such as a diskette, CD, or USB.

- If the system ROM is valid, the system starts normally.
- If the system ROM fails the validation check, the FailSafe Boot Block ROM provides enough support to start the system from a ROMPaq removable medium which will program the system ROM with a valid image.



NOTE Workstation models that support recovery from a ROMPaq CD provide ISO ROMPaq images in the downloadable ROM SoftPaq.

When the Boot Block detects an invalid system ROM, the System Power LED blinks red eight times, once every second, followed by a two-second pause. Also, you will hear eight beeps that correspond to the blinks. A Boot Block recovery mode message is displayed on the screen (some models).

To recover the system after it enters Boot Block recovery mode:

1. If a removable medium is loaded in the workstation, remove it and power down the workstation.
2. Insert the appropriate ROMPaq removable medium in the workstation.
3. Power on the workstation.

If no ROMPaq removable medium is found, you are prompted to insert one and restart the workstation.

If a setup password has been established, the Caps Lock light illuminates and you are prompted to enter the password.

4. Enter the setup password.

If the system successfully starts from the removable medium and successfully reprograms the ROM, the three keyboard lights illuminate.

5. Remove the removable medium and restart the system.

The following table lists the various keyboard light combinations used by the Boot Block ROM (when a PS/2 keyboard is attached to the workstation) and explains the meaning and action associated with each combination.

Table 3-2 PS/2 keyboard light combinations used by Boot Block ROM

Light	State	Description
FailSafe Boot Block Mode	Keyboard LED Activity	State/Message
Num Lock	On	ROMPaq diskette or ROMPaq CD not present, is bad, or drive not ready
Caps Lock	On	Enter password
Num, Caps, Scroll Lock	Blink On in sequence, one at a time—N,C, SL	Keyboard locked in network mode
Num, Caps, Scroll Lock	On	Boot Block ROM Flash successful.

Diagnostic lights do not flash on USB keyboards.

Replicating the setup

The following procedures enable you to easily copy one setup configuration to other workstations of the same model to provide faster, more consistent configuration of multiple workstations.



NOTE Setup configuration procedures require a diskette or a USB such as an HP DriveKey.

To collect and replicate BIOS settings on multiple computers, use System Software Manager or HP Client Manager Software. For more information, see <http://www.hp.com/go/easydeploy>.

Copying to a single workstation



CAUTION A setup configuration is model-specific. File system corruption can result if the source and target workstations are not the same model. For example, do not copy the setup configuration from an HP xw6200 Workstation to an HP xw9400 Workstation.

1. Select a setup configuration to copy, then shut down the workstation.
2. Reboot the workstation.
3. As soon as the screen illuminates, press and hold the **F10** key until you enter the Computer Setup Utility. Press **Enter** to bypass the title screen, if necessary.



NOTE If you do not press the F10 key at the appropriate time, you must restart the workstation and press and hold the **F10** key again to access the utility.

If you are using a PS/2 keyboard, disregard the keyboard error message that might appear.

4. Insert the configuration diskette or USB.
5. Click **File>Replicated Setup>Save to Removable Media**. Follow the instructions on the screen to create the configuration diskette or USB.
6. Power off the workstation to be configured and insert the diskette or USB.
7. Power on the workstation to be configured.
8. As soon as the screen illuminates, press and hold the **F10** key until you enter the Computer Setup Utility. Press **Enter** to bypass the title screen, if necessary.
9. Click **File>Replicated Setup>Restore from Removable Media**, and follow the instructions on the screen.
10. Restart the workstation when the configuration is complete.

Copying to multiple workstations



CAUTION A setup configuration is model-specific. File system corruption can result if the source and target workstations are not the same model. For example, do not copy the setup configuration from an HP xw6200 Workstation to an HP xw9400 Workstation.

This method takes a little longer to prepare the configuration diskette or USB, but copying the configuration to target workstations is significantly faster.



NOTE A bootable diskette or USB is required for this procedure. If Windows XP is not available to create a bootable diskette or USB, use the method for copying to a single workstation instead (see [Copying to a single workstation on page 39](#)).

1. Create a bootable diskette or USB.
2. Select a setup configuration to copy, then shut down the workstation.
3. Power on the workstation.
4. As soon as the screen illuminates, press and hold the **F10** key until you enter the Computer Setup Utility. Press **Enter** to bypass the title screen, if necessary.



NOTE If you do not press the F10 key at the appropriate time, you must restart the workstation and press and hold the **F10** key again to access the utility.

If you are using a PS/2 keyboard, disregard the keyboard error message that might appear.

5. Insert the diskette or USB.
6. Click **File>Replicated Setup>Save to Removable Media**. Follow the instructions on the screen to create the configuration diskette or USB.
7. Download a BIOS utility for replicating setup (repset.exe), and copy it onto the configuration diskette or USB. To obtain this utility, go to <http://www.hp.com/support/files> and enter the model number of the workstation.
8. On the configuration diskette or USB, create an autoexec.bat file containing the following command: **repset.exe cpqsetup.txt**.
9. Power off the workstation to be configured. Insert the configuration diskette or USB and power on the workstation. The configuration utility runs automatically.
10. Restart the workstation when the configuration is complete.

Dual-state power button

With ACPI enabled, the power button can function either as an on/off switch or as a sleep button. The feature does not completely remove the power, but instead causes the workstation to enter a low-power standby state. This feature enables you to power off without closing applications and to return to the same operational state without any data loss.

To change the power button configuration:

1. Click **Start**, and select **Control Panel>Power Options**.
2. In **Power Options Properties**, click the **Advanced** tab.
3. In the **Power Button** section, select **Hibernate** or **Standby**. (Hibernate must be enabled in the **Hibernate** tab to use this option.)

After configuring the power button to function as a Hibernate/Standby button, press the power button to put the system in a very low power state. Press the button again to bring the system to full power status.

To completely remove all power to the system, press and hold the power button for four seconds.



CAUTION Do not use the power button to power off the workstation unless the system is not responding. Powering off the power without operating system interaction can cause damage to or loss of data on the hard drive.

Worldwide web site

HP engineers rigorously test and debug software developed by HP and third-party suppliers, and develop operating system specific support software, to ensure performance, compatibility, and reliability for HP workstations.

When making the transition to new or revised operating systems, it is important to implement the support software designed for that operating system. If you plan to run a version of Microsoft Windows that is

different from the version included with the workstation, you must install corresponding device drivers and utilities to ensure that all features are supported and functioning properly.

HP has made the task of locating, accessing, evaluating, and installing the latest support software easier. You can download the software from <http://www.hp.com/support>. The Web site contains the latest device drivers, utilities, and flashable ROM images needed to run the latest Microsoft Windows operating system on the HP workstation.

Building blocks and partners

HP management solutions integrate with other systems management applications, and are based on industry standards, such as:

- Web-Based Enterprise Management (WBEM)
- Windows Management Interface (WMI)
- Wake on LAN technology
- ACPI
- SMBIOS
- Pre-boot Execution Environment (PXE) support
- Alert Standard Format

Asset tracking and security

Asset tracking features incorporated into the workstation provide key asset tracking data that can be managed using HP Systems Insight Manager, HP Client Manager Software, or other system management applications. Seamless, automatic integration between asset tracking features and these products enables you to choose the management tool that is best suited to the environment and to leverage the investment in existing tools.

HP also offers several solutions for controlling access to valuable components and information. ProtectTools Embedded Security, if installed, prevents unauthorized access to data, checks system integrity, and authenticates third-party users attempting system access. Security features such as ProtectTools and the Hood Sensor (Smart Cover Sensor) help to prevent unauthorized access to the internal components of the workstation. By disabling parallel, serial, or USB ports, or by disabling removable media boot capability, you can protect valuable data assets. Memory Change and Hood Sensor (Smart Cover Sensor) alerts can be automatically forwarded to system management applications to deliver proactive notification of tampering with a workstation's internal components.



NOTE ProtectTools, the Hood Sensor (Smart Cover Sensor), and the Hood Lock (Smart Cover Lock) are available as options on select systems.

Use the following utilities to manage security settings on the HP workstation:

- Computer Setup (F10) Utility (local).
- HP Client Manager Software or System Software Manager (remote). This software enables the secure, consistent deployment and control of security settings from a simple command line utility.

The following table and sections refer to managing security features of the workstation locally through the Computer Setup Utility.

Table 3-3 Security features overview

Feature	Purpose	How It Is Established
Removable Media Boot Control	Prevents booting from the removable media drives.	Computer Setup Utility Menu.
Serial, Parallel, USB, or Infrared Interface Control	Prevents transfer of data through the integrated serial or USB interfaces.	Computer Setup Utility menu.
Power-On Password	Prevents use of the workstation until the password is entered. This can apply to both initial system startup and restarts.	Computer Setup Utility menu.
Setup Password	Prevents reconfiguration of the workstation (use of the Setup Utilities) until the password is entered.	Computer Setup Utility menu.
Network Server Mode	Provides unique security features for workstations being used as servers.	Computer Setup Utility menu.
Ownership Tag	Displays ownership information, as defined by the system administrator, during system startup (protected by setup password).	Computer Setup Utility menu.
Kensington Cable Lock Provision	Prevents entire system theft only.	Install a Kensington cable lock to secure the workstation to a fixed object.
Padlock Loop	Prevents access panel from being removed. This loop can also be used to secure the unit to a fixed object.	Install a padlock.
Access Panel Key Lock (Standard)	Prevents removal of the access panel and all internal components including optical and floppy drives	Lock the access panel.
Universal Chassis Clamp Lock (Optional)	The version without a cable discourages access panel removal and prevents the theft of I/O devices. The version with a cable additionally prevents entire system theft and allows multiple systems to be secured with a single cable.	Install a chassis clamp lock.
Hood Sensor	Notifies a local or remote user when the chassis access panel has been opened.	Install an intrusion sensor.

NOTE: For more information about the Computer Setup Utility, see [Computer Setup \(F10\) Utility menu on page 26](#).

Password security

The power-on password prevents unauthorized use of the workstation by requiring entry of a password to access applications or data each time the workstation is turned on or restarted. The setup password specifically prevents unauthorized access to the Computer Setup Utility and can also be used as an override to the power-on password. That is, when prompted for the power-on password, entering the setup password instead will allow access to the workstation.

A network-wide setup password can be established to enable the system administrator to log in to all network systems to perform maintenance without having to know the power-on password.



NOTE System Software Manager and HP Client Manager Software allow remote management of setup passwords and other BIOS settings in a networked environment. For more information, see <http://www.hp.com/go/easydeploy>.

Establishing a setup password in the Computer Setup (F10) Utility

Establishing a setup password through the Computer Setup Utility prevents reconfiguration of the workstation (through use of the Computer Setup Utility) until the password is entered.

To establish a setup password using workstation setup:

1. Power on or restart the workstation.
2. As soon as the screen illuminates, press and hold **F10** until you enter the Computer Setup Utility. Press **Enter** to bypass the title screen, if necessary.



NOTE If you do not press the F10 key at the appropriate time, you must restart the workstation and press and hold the **F10** key again to access the utility.

If you are using a PS/2 keyboard, disregard the keyboard error message that might appear.

3. Select **Security>Setup Password**, and follow the onscreen instructions.
4. Before exiting, select **File>Save Changes and Exit**.

Establishing a power-on password in the Computer Setup (F10) Utility

Establishing a power-on password through the Computer Setup Utility prevents access to the workstation when power is on, unless the password is entered. When a power-on password is set, the Computer Setup Utility presents Password Options under the Security menu. The password options include Network Server Mode and Password Prompt on Warm Boot.

When Network Server Mode is disabled, the password must be entered each time the workstation is powered on when the key icon appears on the monitor. When Password Prompt on Warm Boot is enabled, the password must also be entered each time the workstation is rebooted. When Network Server Mode is enabled, the password prompt is not presented during POST, but any attached PS/2 keyboard remains locked until the power-on password is entered.

To enable Network Server Mode, a power-on password must be set. The option then shows up under **Advanced>Password Options**. This feature allows the system to boot without asking for the power-on password, but the keyboard and mouse are locked until you enter it. The keyboard LEDs rotate constantly when the system is in locked mode.

To establish a power-on password through workstation setup:

1. Power on or restart the workstation.
2. As soon as the screen illuminates, press and hold the **F10** until you enter the Computer Setup Utility. Press **Enter** to bypass the title screen, if necessary.



NOTE If you do not press the F10 key at the appropriate time, you must restart the workstation and press and hold the **F10** key again to access the utility.

If you are using a PS/2 keyboard, disregard the keyboard error message that might appear.

3. Select **Security>Power-On Password**, and follow the on-screen instructions.
4. Before exiting, select **File>Save Changes and Exit**.

Entering a power-on password

To enter a power-on password:

1. Power on or restart the workstation.
2. When the key icon appears on the monitor, enter the current password, and press **Enter**.



NOTE Type carefully. For security reasons, the characters you enter do not appear on the screen.

If you enter the password incorrectly, a broken key icon appears. Try again. After three unsuccessful tries, you must restart the workstation before you can continue.

Entering a setup password

If a setup password has been established on the workstation, you will be prompted to enter it each time you run the Computer Setup Utility.

To enter a setup password:

1. Power on or restart the workstation.
2. As soon as the screen illuminates, press and hold the **F10** key until you enter the Computer Setup Utility. Press **Enter** to bypass the title screen, if necessary.



NOTE If you do not press the F10 key at the appropriate time, you must restart the workstation and press and hold the **F10** key again to access the utility.

If you are using a PS/2 keyboard, disregard the keyboard error message that might appear.

3. When the key icon appears on the monitor, enter the setup password, and press **Enter**.



NOTE Type carefully. For security reasons, the characters you enter do not appear on the screen.

If you enter the password incorrectly, a broken key icon appears. Try again. After three unsuccessful tries, you must restart the workstation, before you can continue.

Changing a power-on or setup password

To change a power-on or setup password:

1. Power on or restart the workstation.
2. As soon as the screen illuminates, press and hold the **F10** key until you enter the Computer Setup Utility. Press **Enter** to bypass the title screen, if necessary.



NOTE If you do not press F10 at the appropriate time, you must restart the workstation and press and hold the **F10** key again to access the utility.

If you are using a PS/2 keyboard, disregard the keyboard error message that might appear.

- When the key icon appears, enter the current password, a slash (/) or alternate delimiter character, your new password, another slash (/) or alternate delimiter character, and your new password again as shown: **current password/new password/new password**



NOTE Type carefully. For security reasons, the characters you enter do not appear on the screen.

- Press **Enter**.

The new password takes effect the next time you power on the workstation.



NOTE See the table of [National keyboard delimiter characters on page 45](#) for information about the alternate delimiter characters. The power-on password and setup password can also be changed using the Security menu in the Computer Setup Utility.

Deleting a power-on or setup password

To delete a power-on or setup password:

- Power on or restart the workstation.
- To delete the power-on password, go to step 3.

To delete the setup password, as soon as the screen illuminates, press and hold the **F10** key until you enter the Computer Setup Utility. Press **Enter** to bypass the title screen, if necessary.



NOTE If you do not press the F10 key at the appropriate time, you must restart the computer and press and hold the **F10** key again to access the utility.

Use the appropriate operating system shutdown process.

- When the key icon appears, enter your current password followed by a slash (/) or alternate delimiter character as shown: *current password/*.
- Press **Enter**.



NOTE See the [National keyboard delimiter characters on page 45](#) for information about the alternate delimiter characters. The power-on password and setup password can also be changed using the Security menu in the Computer Setup Utility.

National keyboard delimiter characters

Each keyboard is designed to meet country-specific requirements. The syntax and keys that you use for changing or deleting your password depend on the keyboard that came with your workstation.

Table 3-4 National keyboard delimiter characters

Arabic	/	Greek	-	Russian	/
Belgian	=	Hebrew	.	Slovakian	-
BHCSY*	-	Hungarian	-	Spanish	-
Brazilian	/	Italian	-	Swedish/Finnish	/
Chinese	/	Japanese	/	Swiss	-

Table 3-4 National keyboard delimiter characters (continued)

Arabic	/	Greek	-	Russian	/
Czech	-	Korean	/	Taiwanese	/
Danish	-	Latin American	-	Thai	/
French	!	Norwegian	-	Turkish	.
French Canadian	é	Polish	-	U.K. English	/
German	-	Portuguese	-	U.S. English	/

* For Bosnia-Herzegovina, Croatia, Slovenia, and Yugoslavia.

Clearing passwords

If you forget your password, you cannot access the workstation. See [Resetting the password jumper on page 176](#) for instructions on clearing passwords.

Hood sensor (Smart Cover Sensor)

The optional hood sensor is a combination of hardware and software technology that can alert you when the workstation side access panel has been removed. There are three levels of protection, as described in the following table.

Table 3-5 Hood sensor protection levels

Level	Setting	Description
Level 0	Disabled	Hood sensor is disabled (default).
Level 1	Notify User	When the workstation is restarted, the screen displays a message indicating that the workstation side access panel has been removed.
Level 2	Setup Password	When the workstation is restarted, the screen displays a message indicating that the workstation side access panel has been removed. You must enter the setup password to continue.

These settings can be changed using the Computer Setup Utility.

Setting the hood sensor protection level

To set the hood sensor protection level:

1. Power on or restart the workstation.
2. As soon as the screen illuminates, press and hold the **F10** key until you enter the Computer Setup Utility. Press **Enter** to bypass the title screen, if necessary.



NOTE If you do not press the F10 key at the appropriate time, you must restart the computer and press and hold the **F10** key again to access the utility.

If you are using a PS/2 keyboard, disregard the keyboard error message that might appear.

3. Select **Security>Smart Cover>Cover Removal Sensor**, then side access panel, and follow the on-screen instructions.
4. Select **File>Save Changes and Exit**.

Cable lock provision (optional)

The rear panel of the chassis can accommodate a cable lock accessory that allows the workstation to be physically secured to a work area.

Security lock (optional)

This optional feature prevents entire system theft and discourages access panel removal.

Universal chassis clamp lock (optional)

The version without a cable discourages access panel removal and prevents theft of I/O devices. The version with a cable also prevents entire system theft and allows multiple systems to be secured with a single cable.

Access panel key lock

This lock prevents removal of the access panel and all internal components. The key is shipped on the rear of the workstation.

Fault notification and recovery

Fault notification and recovery features combine innovative hardware and software technology to prevent the loss of critical data and minimize unplanned downtime.

If the workstation is connected to a network managed by HP Client Manager software, the computer sends a fault notice to the network management application. With HP Client Manager software, you can also remotely schedule diagnostics to automatically run on all managed PCs and create a summary report of failed tests.

Drive Protection System

The Drive Protection System (DPS) is a diagnostic tool built into the hard drives installed in select HP workstations. DPS is designed to help diagnose problems that might result in unwarranted hard drive replacement.

When HP workstations are built, each installed hard drive is tested using DPS, and a permanent record of key information is written onto the drive. Each time DPS is run, test results are written to the hard drive. The service provider can use this information to help diagnose conditions that caused you to run the DPS software.

ECC fault prediction and pre-failure warranty

When the workstation encounters an excessive number of error checking and correcting (ECC) memory errors, it displays a Local Alert message. This message contains detailed information about the errant memory module, enabling you to take action before you experience un-correctable memory errors. The pre-failure warranty for ECC memory modules enables you to replace these modules, free of charge, before the modules actually fail. ECC memory modules are supported on current HP workstations.

Thermal sensors

A thermal sensor is a hardware and software feature that tracks temperature. When combined with HP Client Manager Software, a thermal sensor notifies the network administrator when a normal temperature range is exceeded. For example, a thermal sensor monitors processor temperature. If processor temperature remains too high, the system eventually shuts down.

4 Removal and replacement procedures

This chapter describes removal and replacement procedures of most internal components.

- [Service considerations on page 50](#)
- [Customer Self Repair on page 54](#)
- [Pre-disassembly procedures on page 55](#)
- [System board components on page 56](#)
- [System board architecture on page 58](#)
- [Removing and replacing components on page 59](#)

Service considerations

The following sections discuss service considerations that should be reviewed and practiced before removing and replacing any system components.



WARNING! When lifting or moving the workstation, do not use the front bezel as a handle or lifting point. Lifting the workstation from the front bezel or lifting it incorrectly can cause the unit to fall and harm the user and damage the workstation. To properly and safely lift the workstation, lift it from the bottom of the unit.

Read cautions, warnings, and safety precautions

For your safety, you must review [Service considerations on page 50](#) before accessing the components of the workstation. Also, review the *Safety and Regulatory Guide* that came with your workstation for more information.



WARNING! Some parts inside the computer will be hot. Power off and unplug the system, and wait three to five minutes for them to cool before opening the system access panels or touching internal components.

Electrostatic discharge information

A sudden discharge of static electricity from your finger or other conductor can destroy static-sensitive devices or microcircuitry. Often the spark is neither felt nor heard, but damage occurs. An electronic device exposed to electrostatic discharge (ESD) might not appear to be affected at all and can work perfectly throughout a normal cycle. The device can function normally for a while, but it has been degraded in the internal layers, reducing its life expectancy.

Networks built into many integrated circuits provide some protection, but in many cases, the discharge contains enough power to alter device parameters or melt silicon junctions.

Generating static

The following table shows that different activities generate different amounts of static electricity. Static electricity increases as humidity decreases.

Table 4-1 Static electricity

Event	Relative Humidity		
	5%	4%	1%
Walking across carpet	7,500 V	15,000 V	35,000 V
Walking across vinyl floor	3,000 V	5,000 V	12,000 V
Motions of bench worker	400 V	800 V	6,000 V
Removing bubble pack from PCB	7,000 V	20,000 V	26,500 V
Packing PCBs in foam-lined box	5,000 V	11,000 V	21,000 V



CAUTION 700 volts can degrade a product.

Preventing electrostatic damage to equipment

Many electronic components are sensitive to ESD. Circuitry design and structure determine the degree of sensitivity. The following packaging and grounding precautions are necessary to prevent damage to electric components and accessories.

- Transport products in static-safe containers, such as tubes, bags, or boxes, to avoid hand contact.
- Protect all electrostatic parts and assemblies with conductive or approved containers or packaging.
- Keep electrostatic-sensitive parts in their containers until they arrive at static-free stations.
- Place items on a grounded surface before removing them from their containers.
- When handling or touching a sensitive component or assembly, ground yourself by touching the chassis.
- Avoid contact with pins, leads, or circuitry.
- Place reusable electrostatic-sensitive parts from assemblies in protective packaging or conductive foam.

Personal grounding methods and equipment

Use the following equipment to prevent static electricity damage to equipment:

- Wrist straps are flexible straps with a maximum of one megohm \pm 10% resistance in the ground cords. To provide a proper ground, wear the strap against bare skin. The ground cord must be connected and fit snugly into the banana plug connector on the grounding mat or workstation.
- Heel straps, toe straps, and boot straps can be used at standing workstations and are compatible with most types of shoes or boots. On conductive floors or dissipative floor mats, use them on both feet with a maximum of one-megohm \pm 10% resistance between the operator and ground.

Table 4-2 Static shielding protection levels

Method	Voltage
Antistatic plastic	1,500
Carbon-loaded plastic	7,500
Metallized laminate	15,000

Grounding the work area

To prevent static damage at the work area:

- Cover the work surface with approved static-dissipative material. Provide a wrist strap connected to the work surface and properly grounded tools and equipment.
- Use static-dissipative mats, foot straps, or air ionizers to give added protection.
- Handle electrostatic sensitive components, parts, and assemblies by the case or PCB laminate. Handle them only at static-free work areas.
- Turn off power and input signals before inserting and removing connectors or test equipment
- Use fixtures made of static-safe materials when fixtures must directly contact dissipative surfaces.

- Keep work area free of nonconductive materials, such as ordinary plastic assembly aids and Styrofoam.
- Use field service tools, such as cutters, screwdrivers, and vacuums, that are conductive.

Recommended materials and equipment

It is recommended that the following materials and equipment be used to prevent static electricity:

- Antistatic tape
- Antistatic smocks, aprons, or sleeve protectors
- Conductive bins and other assembly or soldering aids
- Conductive foam
- Conductive tabletop workstations with ground cord of one-megohm \pm 10% resistance
- Static-dissipative table or floor mats with hard tie to ground
- Field service kits
- Static awareness labels
- Wrist straps and footwear straps providing one-megohm \pm 10% resistance
- Material handling packages
- Conductive plastic bags and tubes
- Conductive tote boxes
- Opaque and transparent metallized shielded bags
- Transparent shielding tubes

Required tools and software

The following tools and software are required to service your workstation:

- Torx T-15 screwdriver or flathead screwdriver
- Diagnostics software

Screws

The screws used in the workstation are not interchangeable. They might have standard or metric threads and might be of different lengths. If an incorrect screw is used during the reassembly process, it can damage the unit. HP strongly recommends that all screws removed during disassembly be kept with the removed part and then returned to their proper locations.

Special handling of components

The following components require special handling when servicing the workstation.

Cables and connectors

Cables must be handled with care to avoid damage. Apply only the tension required to seat or unseat the cables during insertion or removal from the connector. Handle cables by the connector or pull strap whenever possible. In all cases, avoid bending or twisting the cables, and be sure that the cables are routed in such a way that they cannot be caught or snagged by parts being removed or replaced.



CAUTION When servicing this workstation, be sure that cables are placed in their proper location during the reassembly process. Improper cable placement can damage the workstation.

Hard drives

Handle hard drives as delicate, precision components, avoiding all physical shock and vibration. This guideline applies to failed drives and replacement spares. Keep the following guidelines in mind as well:

- If a drive must be mailed, place the drive in a bubble-pack mailer or other suitable protective packaging and label the package “Fragile: Handle With Care.”
- Do not remove hard drives from the shipping package for storage. Keep hard drives in their protective packaging until they are actually mounted in the workstation.
- Avoid dropping drives from any height onto any surface.
- If you are inserting or removing a hard drive, power off the workstation. Do not remove a hard drive while the workstation is on.
- Before handling a drive, be sure that you are discharged of static electricity. While handling a drive, avoid touching the connector. For more information about preventing electrostatic damage, see [Electrostatic discharge information on page 50](#).
- Do not use excessive force when inserting a drive.
- Avoid exposing a hard drive to liquids, temperature extremes, or products that have magnetic fields such as monitors or speakers.

Lithium coin cell battery

The battery that comes with the workstation provides power to the real-time clock and has a minimum lifetime of about three years.

For instructions on battery removal and replacement, see [Battery on page 80](#).



WARNING! This workstation contains a lithium battery. A risk of fire and chemical burn exists if the battery is handled improperly. Do not disassemble, crush, puncture, short external contacts, dispose of in water or fire, or expose it to temperatures higher than 140 degrees F (60 degrees C).



NOTE Batteries, battery packs, and accumulators should not be disposed of with general household waste.

Customer Self Repair

Customer Self Repair (CSR) enables you to obtain replacement parts and install them yourself on your workstation. See <http://www.hp.com/go/selfrepair/> for more information.

Pre-disassembly procedures

After shutdown, perform the following steps before servicing the workstation:

1. Remove or disengage any security devices that prohibit opening the workstation.
2. Close any open software applications.
3. Remove any diskettes or CDs from the workstation.
4. Exit the operating system.
5. Shut down the workstation and any peripheral devices that are connected to it.
6. Disconnect the power cord from the electrical outlet and then from the workstation.
7. Disconnect all peripheral device cables from the workstation.

System board components

The following image shows the system board connectors and sockets on the HP xw9400 Workstation.




Figure 4-1 System board identification

Table 4-3 System board components

Item	Description	Item	Description	Item	Description	Item	Description
1	Main power	13	Memory fan	25	Front control panel	37	Primary IDE**
2	Memory module pairs	14	PCI Express x16 (x8 performance)*	26	Front USB	38	Diskette drive
3	Liquid cooling fan	15	PCI Express x16 graphics	27	Internal USB 0	39	Clear CMOS button
4	CPU1	16	PCI 32 bit, 33 MHz	28	Serial SCSI (SAS)	40	Internal USB 1
5	Serial	17	PCI Express x16 (x8 performance)*	29	PCI-X speed jumper	41	Processor power
6	SPDIF Out	18	PCI Express x16	30	Spare 12V fan	42	CPU0 fan
7	PS/2 keyboard/mouse	19	PCI-X 100	31	Spare 12V fan	43	Fan detection jumper

Table 4-3 System board components (continued)

Item	Description	Item	Description	Item	Description	Item	Description
8	IEEE 1394/USB	20	PCI-X 100/133	32	Serial ATA (SATA)	44	Battery
9	LAN/USB	21	CD audio	33	Hard disk activity LED	45	CPU0
10	Chassis fan	22	Auxiliary audio	34	Password jumper	46	CPU1 fan
11	LAN/USB	23	Front audio	35	Crisis recovery jumper	47	Memory power
12	Audio	24	Front IEEE 1394	36	PCI fan		

* The PCI Express x16 is a PCI Express x16 connector that has x8 bandwidth.

** The Primary IDE connector is generally used for optical drives.

System board architecture

The following image shows the HP xw9400 Workstation block diagram.




Figure 4-2 System board block diagram

Removing and replacing components

This section discusses the procedures necessary to remove and install various hardware components on your workstation.

Before servicing or upgrading your workstation:

1. Review the safety precautions and the [Service considerations on page 50](#), as well as the *Safety and Regulatory Information*.
2. Locate and clear a suitable work area.
3. Shut down the system and remove power from the unit.
4. Gather your tools.
5. Remove all security devices.
6. Service your unit.
7. Restore power to your unit.



NOTE Prior to removing and replacing a component, make sure you remove all installed components that obstruct or prevent the removal of the component.

If you are unsure how to remove a particular component, please do one of the following:

1. Refer to the appropriate section in this chapter.
2. If the content you desire is not referenced in this chapter, see www.hp.com/support/xw9400_manuals and look under “Setup and Install – General” for instructions.
3. See the manufacturer’s web site for instructions for a third party (non-HP) component.

Disassembly order

Use the following table to determine the sequence in which to remove the major components.

Pre-disassembly (Pre-disassembly procedures on page 55)
Locks (Security lock (optional) on page 61)
Access panel (Access panel on page 61)
Hood sensor (Hood sensor (Smart cover sensor) on page 64)
Front bezel (Front bezel on page 62)
Front panel I/O device assembly (Front panel I/O device assembly on page 64)

Power button and front speaker (Power button assembly and system speaker on page 65)
Optical drive (Optical drive on page 83)
Diskette drive (Diskette drive (optional) on page 84)
Bezel blanks (Bezel blanks on page 63)
Power supply (Power supply on page 67)
System fan (System fan on page 67)
Memory fan (Memory fan on page 68)
Memory (Memory on page 69)
Front fan removal (optional) (Front fan removal on page 78)
Battery (Battery on page 80)
Hard drive (Hard drive on page 87)
CPU heatsink (Removing the CPU heatsink on page 91)
Processor (Removing the processor on page 94)
PCI retainer (PCI retainer on page 73)
PCI retention clamp (PCI retention clamp on page 75)
PCI or PCI Express card (Removing PCI or PCI Express cards on page 76)
CPU heatsink (Removing the CPU heatsink on page 91)
Processor (Removing the processor on page 94)
System board (System board on page 96)

Security lock (optional)

If a security padlock is installed, remove it before servicing the unit. To remove the padlock, unlock it and slide it out of the padlock loop as shown in the following image.



Figure 4-3 Removing the security lock

Cable lock (optional)

If a cable lock is installed, remove it before servicing the unit. To remove the cable lock, unlock it and pull it out of the cable lock slot as shown in the following image.



Figure 4-4 Removing the cable lock

Access panel

Before accessing the internal components of the workstation, the access panel must be removed.

To remove the access panel:



WARNING! Before removing the workstation access panel, be sure that the workstation is powered off and that the power cord is disconnected from the electrical outlet.

1. Disconnect power from the system.
2. If a lock is present, unlock the access panel ([Access panel on page 61](#)). The keys are on the rear panel ([Rear panel components on page 4](#)). Also, unlock any other locks that are present (Kensington, or Padlock).
3. Pull up on the handle and lift off the cover.



Figure 4-5 Opening the access panel

To replace the access panel, align the bottom groove of the access panel with the bottom edge of the chassis. Rotate the access panel toward the chassis and press firmly until the latch engages.

Front bezel

To remove the front bezel:

1. Lift up on the three **(1)** tabs located on the front bezel.
2. Rotate the front bezel away **(2)** from the chassis, and remove the bezel.



Figure 4-6 Opening the front bezel

Bezel blanks

To remove the bezel blanks:

1. Disconnect power from the system, ([Pre-disassembly procedures on page 55](#)), remove the access panel, and remove the front bezel ([Front bezel on page 62](#))
2. Remove the bezel blanks by squeezing in on the tabs **(1)** and pulling in the bezel blanks **(2)**.




Figure 4-7 Removing the bezel blanks

Hood sensor (Smart cover sensor)

To remove the hood sensor:

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)) and remove the access panel ([Access panel on page 61](#)). Remove the front bezel. Lay the workstation on its side with the system board facing up.
2. Remove the two hood sensor bracket screws, and remove the bracket and sensor as a unit.




Figure 4-8 Removing the hood sensor

To replace the hood sensor, reverse the previous steps.

Front panel I/O device assembly

To remove the front panel I/O device assembly:

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)). Remove the access panel ([Access panel on page 61](#)) and the front bezel ([Front bezel on page 62](#)).
2. Unlatch the plastic snap that secures the cables inside the chassis and, disconnect the front panel I/O device assembly cables from the system board.
3. Remove the screws that hold the front panel I/O device assembly and bracket to the chassis, and remove the screws that hold the front panel I/O device assembly to the bracket.
4. Pull the front panel I/O device assembly out about two inches away from the chassis.

5. Pull the bracket away from the front panel I/O device assembly.



Figure 4-9 Removing the front panel I/O device assembly

6. Slide the front panel cables through the chassis and out the front of the unit.

To replace the front panel I/O device assembly, reverse the previous steps.

Power button assembly and system speaker

The power button and the system speaker are part of the same assembly.

To remove the power button:

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)) and remove the access panel ([Access panel on page 61](#)).
2. Remove the front bezel ([Front bezel on page 62](#)) and the front panel I/O device assembly ([Front panel I/O device assembly on page 64](#)).
3. Disconnect the power button assembly cable from the system board.
4. Disconnect the speaker wire and the hood sensor from the inline connectors on the power button assembly cable.
5. Remove the screw **(1)** that secures the power button assembly to the chassis.

6. Dislodge the metal clip from the chassis by rocking the power button back and forth. Then slide the power button assembly (2) out from the front of the chassis.




Figure 4-10 Removing the power button assembly

To remove the speaker:

1. Disconnect the speaker cable from the in-line front panel I/O device assembly cable, if you have not already done so.
2. Slide the speaker away from the three flanges and remove it from the chassis.




Figure 4-11 Removing the speaker

Power supply

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)), and remove the access panel ([Access panel on page 61](#)). Place the workstation on its side with the system board facing up.
2. Disconnect the three power supply cable connectors from the system board.



NOTE Cable ties and cable clips may be present.

3. Disconnect the power supply connections from the optical drives, diskette drive, hard drives, and graphics card (select models only).
4. Remove the four screws **(1)** from the back panel.
5. Slide the power supply toward the front, and lift up **(2)** to remove it from the chassis.




Figure 4-12 Removing the power supply

To install the power supply, reverse the previous steps.

System fan

To remove the system fan:

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)), and remove the access panel ([Access panel on page 61](#)). Place the workstation on its side with the system board facing up.
2. Disconnect the fan power plug from the system board **(1)**.

3. Press down on the ribbed portion of the system fan housing (2), rotate the fan housing down, and lift the unit out of the chassis.




Figure 4-13 Removing the system fan

To replace the system fan, reverse the previous steps.



CAUTION When installing the system fan, be sure that the fan is situated so that the airflow direction is going out of the chassis to avoid overheating.

Memory fan

To remove the memory fan:

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)), and remove the access panel ([Access panel on page 61](#)). Place the workstation on its side with the system board facing up.
2. Disconnect the memory fan power plug from the system board (1).



NOTE If the fan is simply being moved to access the DIMMs, it does not need to be disconnected from the system board.

3. Press the green tab in on the memory fan housing (2) and lift the unit out of the chassis (3).




Figure 4-14 Removing the memory fan

To replace the system fan, reverse the previous steps.

Memory

Memory module features

- Eight memory slots for DIMMs, four per CPU
- Accepts 512-MB, 1-GB , 2-GB, 4-GB DIMMs
- 32-GB maximum configuration with 4-GB DIMMs
- Standard ECC PC2-5300 DIMMs
- No support for mirroring
- No spare DIMM support

Memory module requirements

- Use only PC2-5300 ECC DIMMs. Certified and warranted HP memory is recommended.
- Match DIMM pairs by size and type.

Removing memory module

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)), and remove the access panel ([Access panel on page 61](#)). Place the workstation on its side with the system board facing up.

 **CAUTION** To ensure that memory modules are not damaged during removal or installation, power off the workstation and unplug the power cord from the AC power outlet. Wait until the LED on the back of the power supply turns off before removing memory. If you do not unplug the power cord while installing memory, your memory modules might be damaged and the system will not recognize the memory changes.

2. Press the green tab in on the memory fan housing (**1**) and lift the unit out of the chassis (**2**).




Figure 4-15 Removing memory fan



NOTE The system fan ([System fan on page 67](#)) must also be removed to access DIMMs in the rear slots.

3. Gently push out on the socket levers (**1**).

4. Lift the DIMM straight up, and remove it from the unit (2).




Figure 4-16 Removing DIMM



NOTE DIMMs and DIMM sockets are keyed for proper installation. Be sure these guides align when installing a DIMM.

Installing a memory module



NOTE HP only ships DIMMs that are electrically and thermally compatible with this product. Because third-party DIMMs might not be electrically or thermally compatible, they are not supported by HP.

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)) and remove the access panel ([Access panel on page 61](#)). Lay the workstation on its side with the system board facing up.

- Depress the green tabs on the memory fan housing (1) and lift the unit out of the chassis (2).




Figure 4-17 Removing the memory fan

- Gently push out on the socket levers.
- Prepare to load memory modules in valid configurations:
 - DIMMs must be loaded in matched pairs.
 - If loading two DIMMs, install them in slots 1a/1b.
 - If loading four DIMMs, install them in slots 1a/1b and 2a/2b for a dual CPU system, or in 1a/1b and 3a/3b for a single CPU system.
 - If loading six DIMMs, install them in slots 1a/1b, 2a/2b, and 3a/3b.
 - If loading eight DIMMs, install them in all slots.
 - Load the memory module pairs in order of size, from largest to smallest.




Figure 4-18 Identifying memory slots

- Lower the DIMM straight down, and be sure the socket levers secure the module into place.



NOTE DIMMs and DIMM sockets are keyed for proper installation. Be sure these guides align when installing a DIMM.

- Lower the memory fan until it snaps into place.



NOTE Ensure that all cables are clear of the fan housing when lowering the memory fan.

The BIOS generates warnings/errors on invalid memory configurations.

- If BIOS cannot obtain a valid memory configuration, it will halt the system with a diagnostics 2006 code for memory error (five beeps and blinks).
- If memory node interleave is enabled but the memory installed on the two CPUs is not equal, BIOS will report a warning during POST (“215-Cannot Interleave Unequal Memory Nodes”). The system can still boot in this condition.

PCI slots




Figure 4-19 Identifying PCI slots

Table 4-4 PCI slots

Slot	Type	Ref
1	PCI Express x16 (x8)	J31
2	PCI Express x16 graphics	J41
3	PCI 32 bit, 33 MHz	J20
4	PCI Express x16 (x8)	J33
5	PCI Express x16 graphics	J32
6	PCI-X 100	J25
7	PCI-X 100/133	J26

PCI retainer

For added protection, some cards have PCI retainers installed to prevent movement during shipping.

Removing the PCI retainer

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)), and remove the access panel ([Access panel on page 61](#)). Place the workstation on its side with the system board facing up.
2. For both short and tall cards, press in on the sides (1) of the retainer, and rotate it (2) out of the chassis.




Figure 4-20 Removing the short or tall card PCI retainer

Installing the PCI retainer

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)), and remove the access panel ([Access panel on page 61](#)). Place the workstation on its side with the system board facing up.

2. For both short and tall PCI cards, attach the hooks of the PCI retainer (1) under the slots on the rear of the chassis, and then rotate the retainer down until the retainer arm (2) supports the card.




Figure 4-21 Installing the short or tall card PCI retainer

PCI retention clamp

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)), and remove the access panel ([Access panel on page 61](#)). Place the workstation on its side with the system board facing up.
2. Open the PCI retention clamp by pressing down on the two green clips at the ends of the clamp and rotating the clamp toward the back of the system.




Figure 4-22 Opening the PCI retention clamp

PCI Express

PCI Express is a point-to-point architecture and uses a serial data transmission protocol. A single PCI Express lane consists of four wires and can transmit 250 MB/s in a single direction or 500 MB/s in both

directions simultaneously. This bandwidth is not affected by what is happening on other PCI Express buses or legacy PCI/PCI-X buses (provided that total bandwidth can be handled by the CPU and the memory subsystem.) The transmission protocol is somewhat similar to that used for a LAN connection and contains error correction and detection, packet addressing, and other network features.

PCI Express improves system attributes. PCI Express enables a low-power, scalable, high-bandwidth communication path with a small number of connections (wires) compared to traditional parallel interfaces (for example, PCI).

The PCI Express I/O slots can support other PCI Express cards with lesser bus bandwidth than what is physically defined for the slot. Use the following table to determine compatibility.

For example, a PCI Express x8 card does not work in a PCI Express x1 slot, but a PCI Express x1 card works in a PCI Express x8 slot.

Table 4-5 PCI Express compatibility matrix for xw9400

	Slot 1*	Slot 2	Slot 4	Slot 5
	x16 mechanical	x16 mechanical	x16 mechanical	x16 mechanical
	x8 electrical	x16 electrical	x8 electrical	x16 electrical
PCI Express x1 Card	Yes	Yes	Yes	Yes
PCI Express x4 Card	Yes	Yes	Yes	Yes
PCI Express x8 Card	Yes	Yes	Yes	Yes
PCI Express x16 Card	Yes	Yes	Yes	Yes

* Slot 1 is for short cards only.

Removing PCI or PCI Express cards

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)), and remove the access panel ([Access panel on page 61](#)). Place the workstation on its side with the system board facing up. Remove the PCI retainer ([PCI retainer on page 73](#)) if present.
2. Open the PCI retention clamp by pressing down on the two green clips at the ends of the clamp (1) and rotating the clamp toward the back of the system.

3. Lift the PCI card out of the chassis (2). If removing a PCI Express high-end graphics card, remove the auxiliary power supply cable (not illustrated) if required, and move the lever to release the card (3) and lift it out of the chassis. Store the card in an anti-static bag.




Figure 4-23 Removing PCI or PCIe card

4. For cards with extenders, release the PCI Express slot latch (1) and lift up slightly. Press the clip on the card guide (2) and lift the card out of the chassis (3).




Figure 4-24 Removing PCIe card with extender

5. Close the PCI retention clamp.

PCI or PCI Express installation

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)), and remove the access panel ([Access panel on page 61](#)). Place the workstation on its side with the system board facing up, and remove the PCI retainer ([PCI retention clamp on page 75](#)).
2. Open the PCI retention clamp by pressing down on the two green clips (1) at the ends of the clamp and rotating the clamp toward the back of the system.

3. Remove the PCI slot cover (2).
4. Lower the PCI (3) or PCI Express (3) card into the chassis. Verify that the keyed components of the card align with the socket.

If installing a card with an auxiliary power connector, plug in the power supply cable or adapter cable supplied with the card (4).
5. Ensure that all cards are properly seated, and close the PCI retention clamp.




Figure 4-25 Installing PCI or PCIe card

Front fan removal

To remove the front fan:

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)), and remove the access panel ([Access panel on page 61](#)). Place the workstation on its side with the system board facing up.
2. Disconnect optical and floppy drive cables from the system board. Remove full length PCI cards.
3. Disconnect the front fan cable from the connector on the system board.

4. Release the two card guide latches (1), pivot the card guide toward the system board (2), and lift it out of the chassis (3).




Figure 4-26 Removing card guide

5. Remove the fan from the card guide by releasing the two latches and applying outward pressure on the card guide while lifting the fan away.




Figure 4-27 Removing fan from card guide

To install the front fan:

1. Place the fan in the card guide with the fan label facing into the card guide, and the fan protector screen facing outward.



NOTE Ensure that the fan blows toward the rear of the chassis.

2. Thread the front fan cable through the slot in the card guide.

3. Set the front fan in the card guide and snap the fan into place.




Figure 4-28 Installing the fan in card guide

4. Lower the card guide with installed fan into the chassis. Place the card guide tabs into the chassis slots and snap the card guide into place.
5. Plug the front fan cable into its connector on the system board.

Battery



CAUTION Before removing the battery, be sure your CMOS settings are backed up because all CMOS settings are lost when the battery is removed. To back up the CMOS settings, use Computer Setup and run the Save to Diskette option from the File menu.

To remove the battery:

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)), and remove the access panel ([Access panel on page 61](#)). Place the workstation on its side with the system board facing up.
2. On the system board, press on the release tab of the battery holder.
3. Rotate the battery enough to get beyond the latch, and lift it straight up.




Figure 4-29 Removing the battery

To install the battery, slide the battery into the holder until it snaps into place.

Power connections to drives

For help in identifying power cables, refer to the following figure and table. Route or tie cables so that they cannot interfere with the CPU heatsink fans.




Figure 4-30 Identifying correct power connections

Table 4-6 Power connector descriptions

Connector	Description
P1	24-pin main power connector
P2	4-pin memory power connector
P3	8-pin processor power connector
P4–P8	SATA and IDE ODD/ accessory power connectors
P9	Diskette connector
P10–P14	HDD connector
P15	PCIe connector
P16	PCIe connector

Optical drive

Your workstation might have a SATA or an IDE optical drive. To remove the optical drive:

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)). Remove the access panel ([Access panel on page 61](#)) and the front bezel ([Front bezel on page 62](#)).
2. Disconnect the audio (1), data (2), and power (3) cables from the drive. The connector colors might be different than illustrated.



NOTE The audio cable is only required for Linux-based systems.




Figure 4-31 Disconnecting IDE (left) or SATA (right) cable from optical drive

3. Lift the green drivelock release lever, and gently slide the drive out of the chassis.



Figure 4-32 Removing optical drive from chassis

To replace an optical drive:

1. Lift the green drivelock release lever while sliding the optical drive into the bay. When the optical drive is partially inserted, release the drivelock release lever, and slide the drive completely into the bay until the drive is secured.

 **CAUTION** Ensure that the optical drive is secure. Failure to do so can cause damage to the drive when moving the workstation.

2. Connect the power, data, and audio (if required) cables to the drive and workstation.



NOTE The audio cable is only required for Linux-based systems.

3. If you are installing more than one optical drive, route the cable as in the following image.




Figure 4-33 Connecting IDE (left) or SATA (right) optical drive cable to system board

Replacing the SATA optical drive data cable

If your workstation has a SATA optical drive, replace the cable as follows:

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)), and remove the access panel ([Access panel on page 61](#)). Place the workstation on its side with the system board facing up.
2. Disconnect the SATA data cable from the system board and from the optical drive.
3. Replace the cable. Attach it to the optical drive and its system board connector as shown.

Diskette drive (optional)

To remove a diskette drive:

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)). Remove the access panel ([Access panel on page 61](#)) and the front bezel ([Front bezel on page 62](#)).

2. Disconnect the cables from the back of the diskette drive.



Figure 4-34 Disconnecting cables from the diskette drive

3. While lifting the green drivelock release tab, slide the drive forward out of the chassis.



Figure 4-35 Removing the diskette drive from the chassis

4. Remove the diskette drive from its bracket by removing the two M3 screws in the rear-most holes and pulling the diskette drive from the bracket.




Figure 4-36 Removing the diskette drive from the bracket

To replace a diskette drive:

1. Slide the diskette drive into the bracket, and secure it with two M3 screws.
2. While lifting the green drivelock release tab, slide the drive into the chassis.
3. Route the diskette drive data cable between the system board and the hard drive cage. Your cable might look different than the one shown.




Figure 4-37 Routing the diskette drive cable to the system board

4. Connect the cables to the back of the diskette drive.

Hard drive

Replacing a hard drive

For more information on SATA hard drives and the SATA RAID configuration, see [SATA devices on page 145](#).

Removing a hard drive

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)), and remove the access panel ([Access panel on page 61](#)).
2. Disconnect the cables from the hard drive.
3. Push in on the green drivelock release tabs, and pull the hard drive out of the chassis.




Figure 4-38 Removing the hard drive

Installing a hard drive

1. Select a drive bay in which to install the drive. If installing more than one hard drive, use the hard drive order shown in the following image.



Figure 4-39 Identifying hard drive installation order

2. Squeeze the green tabs, and slide the rails out of the empty bay.
3. Attach the rails to the hard drive. Align the pins on the rails with the hard drive holes, and snap the rails into place.




Figure 4-40 Attaching rails to the hard drive

4. Push the drive into the selected bay until it snaps into place.

5. Attach a data cable from a SATA connector on the system board to the hard drive, and attach a power cable to the drive.




Figure 4-41 Replacing the SATA hard drive

6. For a SAS hard drive, attach a SAS/SATA adapter to the connector on the hard drive. Attach a data cable from a SAS connector on the system board to the hard drive, and attach a power cable to the drive.



Figure 4-42 Installing the SAS/SATA adapter (left) and cable (right)

Installing a hard drive In the fifth hard drive bay

To install a hard drive into fifth HDD bay:

1. Place the workstation on its side, and remove the three drive screws that are located on the bottom of the chassis.




Figure 4-43 Installing screws for the hard drive in the fifth hard drive bay

2. Insert the drive into bay 5, and align the holes in the bottom of the hard drive with the screw holes at the base of the chassis.
3. Insert the screws through the base, and tighten them to secure the hard drive to the chassis.
4. Attach a data cable from a SATA connector on the system board to the hard drive, and attach the fifth drive power cable to the drive. It is attached to a clip in front of the power supply.




Figure 4-44 Attaching the data cable for the SATA hard drive in the fifth hard drive bay

Processor heatsink

Removing the CPU heatsink



NOTE The following illustrated CPU heatsink is typical of what you might have in your workstation. Be aware that different variations of the CPU heatsinks exist, but the overall procedures listed are sufficient to assist you in removing the CPU heatsink.

1. Shut down the workstation, and disconnect power from the system ([Pre-disassembly procedures on page 55](#)). Remove the access panel ([Access panel on page 61](#)), and place the workstation on its side with the system board facing up.
2. Remove the two processor screws slowly, being sure to loosen the screws evenly. Loosen one screw (**1**) until the screw shank disengages from the system board, then loosen the remaining screw (**2**). Do not fully loosen one screw, then move on to the next. Loosen both screws a little at a time, so that the processor remains level.



Figure 4-45 Identifying proper screw removal order

3. Disconnect the CPU heatsink fan connector (**1**) from the system board.

4. Before lifting the heatsink, carefully break the adhesive compound between the CPU heatsink and processor by moving the heatsink back and forth or twisting it (2).




Figure 4-46 Removing the CPU heatsink from the system board

5. Use alcohol and a soft cloth to clean all of the thermal interface material residue from the CPU heatsink and processor.



CAUTION Allow the alcohol on the processor and CPU heatsink to dry completely.

Replacing the CPU heatsink

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)). Remove the access panel ([Access panel on page 61](#)) and the CPU heatsink ([Removing the CPU heatsink on page 91](#)).
2. Use alcohol and a soft cloth to clean all of the thermal interface material residue from the CPU heatsink and processor.



CAUTION Allow the alcohol on the processor and CPU heatsink to dry completely.

3. Place the CPU heatsink on top of the processor, and align the two mounting screws with the holes (1) in the system board.



NOTE If both CPU heatsinks were removed, be sure that all system board standoffs engage with the keyholes in the chassis, and that the system board connectors engage correctly with the rear I/O panel, and push back on the system board while engaging the CPU heatsink screws with the chassis standoffs. You only need to push back when trying to engage the first sc rew.

4. Connect the CPU heatsink fan connector to the system board (2).




Figure 4-47 Replacing the CPU heatsink on the system board

5. Insert and tighten the two CPU heatsink screws. First, tighten both screws partially so that the CPU heatsink remains level. Next, fully tighten one screw (1), then fully tighten the remaining screw (2). Tighten to a torque setting of 6 in-lb.



Figure 4-48 Identifying proper screw removal order

Processor

Removing the processor

 **CAUTION** Use **extreme** care when installing or removing a processor. The exposed socket pins are **extremely** fragile. Damaged sockets will require a board replacement.

Lift the processor out of the socket— **do not slide** the processor on the socket.

When installing a processor, align the dimples on the side of the processor with the notches in the socket.

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)). Remove the access panel ([Access panel on page 61](#)) and the CPU heatsink ([Removing the CPU heatsink on page 91](#)).
2. Raise the processor socket handle fully **(1)** and lift the socket cover **(2)**.




Figure 4-49 Raising the processor socket handle

3. Lift the processor straight out of the socket.




Figure 4-50 Lift the processor from the socket



CAUTION To avoid bending the socket pins, keep the processor perfectly flat when removing or installing it.



NOTE Store the processor in a static-free, safe place where it will not be damaged.

4. In some workstation configurations, a bypass board may be installed in the socket instead of a processor. Remove the bypass board by lifting it straight out of the socket.




Figure 4-51 Lift the bypass board from the socket

Replacing the processor

CAUTION Use **extreme** care when installing or removing a processor. The exposed socket pins are **extremely** fragile. Damaged sockets will require a board replacement.

Lift the processor out of the socket— **do not slide** the processor on the socket.

When installing a processor, align the dimples on the side of the processor with the notches in the socket.

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)). Remove the access panel ([Access panel on page 61](#)), the CPU heatsink ([Removing the CPU heatsink on page 91](#)), and the processor ([Removing the processor on page 94](#)).
2. Raise the processor socket handle fully.
3. If necessary, remove the bypass board from the socket. Align the notches in the processor base with the tabs on the socket. Seat the processor into the socket. Ensure that the underside of the processor is level with the top of the processor socket. Close the processor cover plate. Lightly press down on the processor cover plate while closing the socket lever.




Figure 4-52 Seating the processor

System board

Removing the system board

1. Disconnect power from the system ([Pre-disassembly procedures on page 55](#)), and remove the access panel ([Access panel on page 61](#)). Place the workstation on its side with the system board facing up. Remove all expansion boards, external cables, graphics cards ([Removing PCI or PCI Express cards on page 76](#)), and the CPU heatsink ([Processor heatsink on page 91](#)). Remove the system and memory fan assemblies.
2. Disconnect all cables from the system board.



NOTE Make note of the cable connections before disconnecting them from the system board. See [Power connections to drives on page 81](#) for more information.

3. Rotate the system board latch lever 90 degrees (1) clockwise to unlock the system board.
4. Slide the system board forward (2) to disengage the metal mounting standoffs from the chassis.



CAUTION Do **not** attempt to remove the system board mounting screws. These screws are permanently secured and are not removable.

5. Lift the system board out (3) of the chassis, being careful not to damage the cables and rear panel connectors. You can lift the board by the rear audio connector and the 2 x 4 power connector (4).




Figure 4-53 Removing the system board

Replacing the System Board

1. Insert the system board straight down, and be sure that all system board standoffs engage with the keyholes in the chassis.



NOTE Be sure the system board connectors engage correctly with the rear I/O panel.

2. Push back on the board while maintaining downward pressure on the board, so all standoffs remain engaged.
3. Rotate the system board latch 90 degrees counter clockwise.
4. Install the heatsink ([Replacing the CPU heatsink on page 92](#)).
5. Install all removed components and cables.

5 System diagnostics and troubleshooting

This chapter discusses the tools available for diagnosing and troubleshooting system issues.

- [E-Support on page 100](#)
- [Troubleshooting checklist on page 101](#)
- [LED color definitions on page 102](#)
- [HP Insight Diagnostics Offline Edition on page 103](#)
- [Diagnostic error codes on page 107](#)
- [Troubleshooting scenarios and solutions on page 110](#)
- [POST error messages on page 131](#)

E-Support

Help and support center and E-Support

Help and Support Center (HSC) provides online access to technical support information, software updates and downloads, diagnostic tools, and HP support contact information.

To open HSC from your desktop, click **Start>Help and Support**.

HSC contains four sections:

- HP Product Information (requires Internet access)—Links to the HP Technical Support website for your product. You can access all related documentation, downloads and updates, tools, and more.
- HP Software and Driver Downloads (requires Internet access)—Links to HP specific software downloads and updates.
- HP Support Tools (requires Internet access)—Links to self-help tools and diagnostics offered by HP Instant Support Professional Edition.
- Contact HP for Support—Provides two different options:
 - Chat with an expert online (requires Internet access)—Provides a tool to communicate with a support specialist online through **Active Chat**.
 - Call a support agent—Provides hardware details about the workstation and HP support contact phone number worldwide.

Troubleshooting checklist

Before running any of the diagnostic utilities, use the following checklist to find possible solutions for workstation or software problems.

- Are the workstation and monitor connected to a working electrical outlet?
- Is the workstation powered on?
- Is the green power light illuminated?
- Is the monitor powered on?
- Is the green monitor light illuminated?
- Adjust the monitor brightness and contrast controls if the monitor is dim.
- Press and hold any key. If the system beeps, then the keyboard is operating correctly.
- Examine all cables for loose or incorrect connections.
- Reconfigure the workstation after installing a non-PnP (Plug 'n Play) expansion board or other option, such as a diskette drive.
- Are all of the necessary device drivers installed?
- Have all printer drivers been installed for each application?
- Remove all diskettes and CDs from the drives before you power on the system.
- Are you running the latest BIOS version, drivers, and/or software updates?

LED color definitions

The front panel LED indicates system status as described in Table 1.

Table 5-1 Front panel LED color definitions

LED State	LED Color	System Status
Solid	Green	System is on.
Blinking	Green	System is in Standby mode.
Solid or blinking	Red	System has an error. See Diagnostic light codes on page 107 .
None	No light	System is in Hibernate mode, or it is off.

HP Insight Diagnostics Offline Edition

The HP Insight Diagnostics utility enables you to perform testing and to view critical computer hardware and software configuration information from various sources. This utility enables you to:

- Run diagnostics.
- View the hardware configuration of the system.

Key features and benefits

HP Insight Diagnostics simplifies the process of effectively identifying, diagnosing, and isolating the hardware issues.

In addition to robust management tools, service tools can be invaluable in quickly resolving system problems. To streamline the service process and resolve problems quickly, you must have the right information available at the time you place a service call. The primary information requirement, which is also the one that provides the greatest insight into potential system issues, is the configuration of the system. Insight Diagnostics helps provide higher system availability. Typical uses of the Insight Diagnostics are:

- Testing and diagnosing apparent hardware failures
- Documenting system configurations for upgrade planning, standardization, inventory tracking, disaster recovery, and maintenance
- Sending configuration information to another location for more in-depth analysis

Theory of operation

HP Insight Diagnostics Offline Edition operates in offline mode only. Here, the operating system is not running, and software information from the system is not available to the diagnostics.

Offline Survey is available to display the current system configuration.

The Insight Diagnostics Test feature enables you to test functionality of all the major hardware components in the system. The Test feature is designed to be flexible to enable you to customize test selections by providing different modes and types of testing. It includes Quick, Complete, and Custom testing levels to give you control over testing depth and required user interaction.

Download the ISO image

1. Browse to <http://www.hp.com>.
2. Click **Software & Driver Downloads**.
3. Enter your product number (for example, xw9400) in the text box, and press the **Enter** key.
4. Select your operating system.
5. Click the **Diagnostic** link.
6. Locate HP Insight Diagnostics Offline on the display, and click **Download**.

User interface

Navigation

The Insight Diagnostics home page contains the following tabs: **Survey**, **Test**, **Status**, **Log**, and **Help**. These tabs separate the major functions of Insight Diagnostics.

Survey tab

When you click the Survey tab, the Survey menu displays and enables you to view important system configuration information. The **Summary** view limits the amount of data displayed, while the **Advanced** view shows all the data in the selected category. Regardless of whether you choose **Advanced** or **Summary**, the following categories of information are available on the **Survey** menu:

Overview—Lists general information about the computer.

All—Lists all information about the computer.

Architecture—Shows the type of bus the computer uses, and BIOS information. In addition, if the bus is PCI, information about the PCI configuration is displayed.

Asset Control—Shows the serial number of the computer, and provides processor information.

Communication—Shows information about the computer parallel (LPT) and serial (COM) port settings, USB, and network controller information.

Graphics—Shows information about the graphics subsystem of the computer.

Input Devices—Shows information about the type of keyboard and mouse.

Memory—Shows information about all memory in the computer, including memory on the board and any memory modules installed.

Miscellaneous—Shows information obtained from the computers configuration memory (CMOS), BIOS data area, Interrupt Vector table, and diagnostics component information.

Storage—Shows information about storage media connected to the computer, including all fixed disks, floppy drives, and CD-ROM drives.

System—Shows product type, processor type and speed, and coprocessor information, and information about all ROMs in the computer.

Test tab

The Insight Diagnostics utility enables you to test all the major pieces of hardware in the system. You can select from several types of tests:

Quick Test—Provides a predetermined script in which a sample of most hardware components is exercised and requires no user intervention.

Complete Test—Provides a predetermined script in which most hardware components are fully tested. You can select Interactive or Unattended tests, which will change the devices tested during the Complete Test. More tests are available in Interactive mode, but these require user intervention.

Custom Test—Provides the most flexibility in controlling the testing of a system. The Custom Test mode enables you to select which devices, tests, and test parameters are run. You can select tests that do not require any user interaction through the Interactive or Unattended test modes. More tests are available in Interactive mode, but these require user intervention.

To begin testing:

1. Click the **Test** tab.
2. Select **Type of Test** to perform, and select **Interactive** or **Unattended** as the test mode.
3. Determine how you want the test to be executed.
 - Select **Number of Loops** and enter the number of loops to perform.
 - Select **Total Test Times** and enter the amount of time in minutes that you want the diagnostic test to run.
4. When choosing to run the test over a specified number of loops, enter the number of loops to perform. If you desire to have the diagnostic test for a specified time period, enter the amount of time in minutes.
5. Click **Begin Testing** in the lower right corner of the display to start the test.

While tests are being performed, you can monitor the progress by clicking the **Status** tab. Any errors that are detected are summarized in the Error Log. Click **Save** to save the report to a floppy disk or a USB key drive if attached.

If the diagnostics utility detects an error during a test, you can mouse-over the failed text in the Status tab to display additional information for the type of error and the error code.

To view all test failure information, select **Error Log**. To view the status of all testing that has been performed, click the **Log** tab.

Status tab

The Status tab displays the status of the selected tests. The type of test executed (for example, **Quick, Complete, Custom**) is displayed. The main progress bar displays the percent complete of the current set of tests. While testing is in progress, a Cancel Testing button is activated. Clicking **Cancel Testing** cancels the test job.

After testing has completed the **Cancel Testing** button is replaced with two buttons, **Select New Tests** and **Retest**. Clicking the **Select New Tests** button enables you to go back to the previous test selection page to select a new set of tests. Clicking the **Retest** button runs the last set of tests executed without having to go back to the test selection page.

The Status page also shows the:

- Devices being tested
- Tests that are running
- Overall test time
- Individual test times
- Condition status of each test

Log tab

The Log tab consists of two views:

Test Log—Displays all tests that have been executed, the number of times the test executed, the number of times the test failed, and the time it took to complete the test. Clicking the **Clear Test Log** button clears the contents of the Test Log.

Error Log—Displays the tests that have failed during the diagnostic testing. Besides displaying the device and test, this section might also include error details. The description section describes the error that the diagnostic test found. Clicking the **Recommended Repair** button gives a recommended action that should be performed to resolve the failed hardware. The error count is the number of times the test has failed. Clicking the **Clear Error Log** button clears the contents of the Error Log.

Help tab

The Help tab has three views:

- **HP Insight Diagnostics**—Provides introductory and detailed information about Insight Field Diagnostics.
- **Error Codes**—Provides error code listings. It includes device tested, message, and recommended repair information.
- **Test Components**—Reloads and refreshes all components and display component details after the refresh.

The Help tab provides information option selections:

- **Reload**—Located in the upper-right corner of the display, this selection reloads all hardware components.
- **About**—Provides revision details of Insight Diagnostics.
- **Exit**—Located in the lower-left corner of the display, this selection provides the option to exit diagnostics.

Starting the diagnostic utility from CD

HP Insight Diagnostics is available on the *Documentation & Diagnostic* CD that was shipped with your workstation.

To start the diagnostic utility on the *Documentation & Diagnostic* CD:

1. Ensure that the diagnostic CD is inserted in the optical drive.
2. Power-on the workstation.
3. Press the **F9** key at boot up.
4. The workstation will boot from the diagnostic CD and automatically run the diagnostic program.

Diagnostic error codes

This sections provides an overview of the diagnostic lights and error codes that are related to your workstation.

Diagnostic light codes



NOTE The beeps are heard through the chassis speaker. The blinking LEDs and beeps repeat for five cycles. After that, only the blinking LEDs repeat.

Table 5-2 Diagnostic LED codes

Chassis Indicator LEDs	
Power LED and Sound Activity	Diagnosis and Service Action
None	<p> CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <p>System does not power on. Press power button. If HDD LED = GREEN, then:</p> <ol style="list-style-type: none"> 1. Remove expansion cards one at a time. 2. Replace the system board. <p>OR</p> <p>If HDD LED does not illuminate, then:</p> <ol style="list-style-type: none"> 1. Verify that the unit is plugged into a working AC outlet. 2. Open access panel, and verify that the power button harness is properly connected to the inline front panel I/O device assembly connector. 3. Verify that the power supply cables are properly connected to the system board. 4. Verify the power supply functionality. <ol style="list-style-type: none"> a. Disconnect AC power. b. Remove all internal power supply cables from the system board. c. Plug in AC power. <ul style="list-style-type: none"> • If the power supply fan spins and the BIST* LED lights, then the power supply is good. Replace the system board. • If the power supply fan does not spin or the BIST* LED does not light, replace the power supply.
Blinks red/beeps two times, once per second, then two-second pause	<p>Thermal shutdown.</p> <ol style="list-style-type: none"> 1. Ensure that the workstation system air vents are not blocked and the cooling fan is running. 2. Open the access panel, press power button, and see if the processor fan spins. Check both fans for a dual-processor workstation. If the processor fan is not spinning, make sure the fan's cable is plugged into the system board header. Ensure the fan is fully/properly seated or installed.

Table 5-2 Diagnostic LED codes (continued)

Chassis Indicator LEDs	
Power LED and Sound Activity	Diagnosis and Service Action
	<ol style="list-style-type: none"> 3. If fan is plugged in and seated properly, but is not spinning, the problem may be in the processor fan. Contact HP for assistance 4. Verify that the fan assembly is properly attached. If problems persist, there may be a problem with the processor heatsink. Contact HP for assistance.
Blinks red/beeps three times, once per second, then a two-second pause	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <p>CPU not installed.</p> <ol style="list-style-type: none"> 1. Check to see that the processor is present. 2. Reseat the processor.
Blinks red/beeps four times, once per second, then a two-second pause	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <p>Power supply failure.</p> <ol style="list-style-type: none"> 1. Open the access panel and ensure the following connections are secure on the system board: <ul style="list-style-type: none"> • 24-pin main power • 8-pin CPU • 4-pin memory 2. Locate faulty device by removing all devices and then reinstalling one at a time until workstation fails. Replace the device causing the failure. Continue adding devices to ensure all are functioning properly. 3. Verify power supply functionality. <ol style="list-style-type: none"> a. Disconnect AC power. b. Remove all internal power supply cables from the system board. c. Plug in AC power. <ul style="list-style-type: none"> • If the power supply fan spins and the BIST* LED lights, then the power supply is good. Replace the system board. • If the power supply fan does not spin or the BIST* LED does not light, replace the power supply.
Blinks red/beeps five times, once per second, then two-second pause	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <p>Pre-video memory error.</p> <ol style="list-style-type: none"> 1. Ensure DIMMs are loaded in correct slots. 2. Reseat DIMMs. 3. Replace DIMMs one at a time to isolate faulty module.

Table 5-2 Diagnostic LED codes (continued)

Chassis Indicator LEDs	
Power LED and Sound Activity	Diagnosis and Service Action
	<ol style="list-style-type: none"> 4. Replace third-party memory with HP memory. 5. Reseat CPUs. 6. Replace system board.
Blinks red/beeps six times, once per second, then a two-second pause	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <hr/> <p>Pre-video graphics card error.</p> <ol style="list-style-type: none"> 1. Ensure auxiliary power cable is connected if applicable (high power graphics cards only). 2. Reseat the graphics card. 3. Replace the graphics card. 4. Replace the system board.
Blinks red/beeps seven times, once per second, then a two-second pause	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <hr/> <p>System board failure (ROM detected failure before video).</p> <ol style="list-style-type: none"> 1. Clear CMOS by pressing the Clear CMOS button on the system board. 2. Replace system board.
Blinks red/beeps eight times, once per second, then a two-second pause	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <hr/> <p>Invalid ROM based on bad checksum.</p> <ol style="list-style-type: none"> 1. Clear CMOS by pressing the Clear CMOS button on the system board. 2. Upgrade the ROM using a ROMPaq diskette, CD, diskette, or USB removable device (e.g., HP Drive Key). See the <i>ROM Flash</i> section of the <i>Service and Technical Reference Guide</i> at http://www.hp.com/support/workstation_manuials. 3. Replace system board.
Blinks red/beeps nine times, once per second, then a two-second pause	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <hr/> <p>System powers on but is unable to boot.</p> <ol style="list-style-type: none"> 1. Replace the processor. 2. Replace the system board.

* Refer to the *Service and Technical Reference Guide* for your workstation for BIST information.

Troubleshooting scenarios and solutions

This section presents an extensive overview of various troubleshooting scenarios and includes possible solutions for each.

Solving minor problems

Table 5-3 Minor problems

Problem	Cause	Possible Solution
Workstation seems to be locked up.	Program in use has stopped responding to commands.	<ol style="list-style-type: none"> 1. Attempt the normal Windows shut down procedure. 2. Restart the workstation using the power button.
Workstation appears locked up and will not turn off when the power button is pressed.	Software control of the power switch is not functional.	<ol style="list-style-type: none"> 1. Press and hold the power button for at least four seconds until the workstation turns off. 2. Disconnect electrical plug from outlet.
Workstation date and time display is incorrect.	Real-time clock (RTC) battery might need to be replaced.	<ol style="list-style-type: none"> 1. Reset the date and time under Control Panel. 2. Replace the RTC battery.
Workstation appears to pause periodically.	Network driver is loaded and no network connection is established.	Establish a network connection, or use Computer Setup or Microsoft Windows Device Manager to disable the network controller.
Cursor will not move using the arrow keys on the keypad.	The Num Lock key might be on.	Press Num Lock . The Num Lock key can be disabled (or enabled) in Computer Setup.
Poor performance is experienced.	Processor is hot.	<ol style="list-style-type: none"> 1. Be sure airflow to the workstation is not blocked. 2. Be sure the fans are connected and working properly (some fans only operate when needed). 3. Be sure the CPU heatsink is installed properly.
	There is not enough memory.	 CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.
		Add more memory.
	Hard drive is full.	Delete data from the hard drive to create more space on the hard drive.
Workstation powered off automatically and the Power LED flashes red two times, once every second, followed by a two-second pause, and two simultaneous beeps are heard.	Processor thermal protection activated: A fan might be blocked or not turning. OR The CPU heatsink is not properly attached to the processor.	 CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down. <ol style="list-style-type: none"> 1. Check system and CPU fan cables. 2. Be sure workstation air vents are not blocked and the cooling fan is running. 3. Open the access panel, press the power button, and determine if the processor fan spins. If not spinning, be sure the fan's cable is plugged into the system board header. Be sure the fan is fully/properly seated or installed.

Table 5-3 Minor problems (continued)

Problem	Cause	Possible Solution
		<ol style="list-style-type: none">4. Replace the processor fan.5. Reseat CPU heatsink and verify that the fan assembly is properly attached.
Workstation does not power on and the LEDs on the front of the workstation are not flashing.	System unable to power on.	<p> CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <p>Press and hold the power button for less than four seconds. If the hard drive LED turns green, then:</p> <ol style="list-style-type: none">1. Remove the expansion cards.2. Replace the system board. <p>OR</p> <p>If the HDD LED does not illuminate, then:</p> <ol style="list-style-type: none">1. Verify that the unit is plugged into a working AC outlet.2. Open the access panel, and verify that the power button harness is properly connected to the inline front panel I/O device assembly connector.3. Verify that the power supply cables are properly connected to the system board.4. Verify power supply functionality:<ol style="list-style-type: none">a. Disconnect AC power.b. Remove all internal power supply cables from the system board.c. Plug in AC power.<ul style="list-style-type: none">• If the power supply fan spins and the BIST* LED lights, then the power supply is good. Replace the system board.• If the power supply fan does not spin or the BIST* LED does not light, replace the power supply.

Solving power supply problems

Testing power supply

Before reseating or replacing the power supply, use the BIST feature to determine if the power supply still works.

To test the power supply:

1. Disconnect AC power to the workstation.
2. Disconnect all internal power supply cables.
3. Plug in AC power.
 - a. If the green BIST LED on the rear of the workstation is lit **and** the fan is spinning, the power supply is functional.
 - b. If the green BIST LED is not lit **or** the fan is not spinning, replace the power supply.




Figure 5-1 BIST LED

Table 5-4 Power supply problems

Problem	Cause	Solution
Power supply shuts down intermittently.	Power supply fault.	Replace the power supply.
Workstation powered off automatically and the Power LED flashes red two times, once every second, followed by a two-second pause.	Processor thermal protection activated. A fan might be blocked or not turning. OR The CPU heatsink fan assembly is not properly attached to the processor.	<p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <ol style="list-style-type: none"> 1. Be sure that the workstation air vents are not blocked and the cooling fan is running. 2. Open the access panel, press the power button, and determine if the processor fan spins. If the processor fan is not spinning, be sure the fan's cable is plugged into the system board header. Be sure the fan is properly seated or installed. 3. Check processor fan cables.

Table 5-4 Power supply problems (continued)

Problem	Cause	Solution
		<ol style="list-style-type: none"> 4. Replace the processor fan. 5. Reseat the CPU heatsink, and verify that the fan assembly is properly attached.
Power LED flashes red, once every two seconds.	Power failure (power supply is overloaded).	<div style="display: flex; align-items: flex-start;"> <div style="margin-right: 10px;">  </div> <div> <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> </div> </div> <ol style="list-style-type: none"> 1. Determine whether a device is causing the problem by removing all attached devices. Power on the system. If the system enters the POST, then power off and replace one device at a time and repeat this procedure until failure occurs. Replace the device causing the failure. Continue adding devices one at a time to ensure all devices are functioning properly. 2. Verify power supply functionality. <ol style="list-style-type: none"> a. Disconnect AC power. b. Remove all internal power supply cables from the system board. c. Plug in AC power. <ul style="list-style-type: none"> • If the power supply fan spins and the BIST LED lights, then the power supply is good. Replace the system board. • If the power supply fan does not spin or the BIST LED does not light, replace the power supply.

Solving diskette problems

Table 5-5 Diskette problems

Problem	Cause	Solution
Diskette drive light stays on.	Diskette is damaged.	<ol style="list-style-type: none"> 1. Check power and data cables. 2. Click on My Computer. 3. Right-click on the desired hard drive and select Properties. 4. Click the Tools tab. 5. Click Check Now... to run error checking.
	Diskette is incorrectly inserted.	Remove diskette and reinsert.
	Files on diskette are damaged.	Check the program diskettes.
	Drive cable is not properly connected.	Reconnect power cable. Be sure that all four pins are connected.

Table 5-5 Diskette problems (continued)

Problem	Cause	Solution
Drive not found.	Cable is loose.	Reseat diskette drive data and power cables.
	Removable drive is not seated properly.	Reseat the drive.
Diskette drive cannot write to a diskette.	Diskette is not formatted.	Format the diskette.
	Diskette is write-protected.	Use another diskette or remove the write protection.
	Writing to the wrong drive.	Check the drive letter in the path statement.
	Not enough space is left on the diskette.	Use another diskette.
	Diskette write control is enabled.	Use Computer Setup to check the storage security feature disabled settings.
	Diskette is damaged.	Replace the damaged disk.
Cannot format diskette.	Invalid media reported.	Check to see if diskette is bad.
		When formatting a disk in MS-DOS, you might need to specify diskette capacity. For example, to format a 1.44-MB diskette, enter the following command at the command prompt: FORMAT A: /F:1440
A problem has occurred with a disk transaction.	The directory structure is bad, or there is a problem with a file.	Right-click Start , click Explore , and select a drive. Select File>Properties>Tools . Under Error-checking, click Check Now .
Diskette drive cannot read a diskette.	Diskette is not formatted.	Format the diskette.
	You are using the wrong diskette type for the drive type.	Be sure you use the correct diskette type for the type of drive you are using.
	You are reading the wrong drive.	Check the drive letter in the path statement.
	Diskette is damaged.	Replace the diskette with a new one.
Invalid system disk is displayed.	A diskette that does not contain the system files needed to start the workstation has been inserted in the drive.	When drive activity stops, remove the diskette and press the spacebar . The workstation should start up.
	Diskette error has occurred.	Restart the workstation by pressing the power button.
Cannot Boot from Diskette.	Diskette is not bootable.	Replace with a bootable diskette.
	Diskette boot has been disabled in Computer Setup.	Run Computer Setup and enable diskette boot in Storage>Boot Order .
	Removable media boot has been disabled in Computer Setup.	Run Computer Setup and enable Removable Media Boot in Storage>Storage Options .

Solving hard drive problems

Table 5-6 Hard drive problems

Problem	Cause	Solution
Hard drive error occurs.	Hard disk has bad sectors or has failed.	Use a disk analysis utility to locate and block usage of bad sectors. If necessary, reformat the hard disk.
Disk transaction problem.	Either the directory structure is bad or there is a problem with a file.	<ol style="list-style-type: none"> 1. Click on My Computer. 2. Right-click on the desired hard drive and select Properties. 3. Click the Tools tab. 4. Click Check Now... to run error checking.
Drive not found (identified).	Loose cable.	Check cable connections.
	The system might not have automatically recognized a newly installed device.	<ol style="list-style-type: none"> 1. Run Computer Setup. 2. If the system still does not recognize the new device, determine if the device is listed within Computer Setup. If it is listed, the probable cause is a driver problem. If it is not listed, the probable cause is a hardware problem. 3. If this is a newly installed drive, enter Setup and try adding a POST delay under Advanced>Power-On>Options.
	Drive's SATA controller is disabled in Computer Setup.	Run Computer Setup and enable the SATA controllers in Storage>Storage Options .
	Drive responds slowly immediately after power on.	Run Computer Setup, and increase the POST Delay in Advanced>Power-On Options .
Non-system disk/NTLDR missing message.	System is trying to start from a non-bootable diskette.	Remove the diskette from the diskette drive so the workstation boots from the hard disk.
Non-system disk/NTLDR missing message.	System is trying to start from a damaged hard drive.	<ul style="list-style-type: none"> • Insert a bootable diskette into the diskette drive or a CD into the optical drive and restart the workstation.
	System files missing or not properly installed.	<ol style="list-style-type: none"> 1. Insert a bootable system diskette and restart. 2. Verify that the hard drive is partitioned and formatted. 3. Install system files for the appropriate operating system if necessary.
	Hard drive boot disabled in Computer Setup.	Run Computer Setup and enable the hard drive entry from Storage Options , then reorder the hard drive in the Storage>Boot Order list.
	Both slow and fast UATA devices are on the same data cable.	Connect slower UATA devices to a separate data cable connected to the secondary IDE (ATA) controller.
Workstation will not start.	Hard drive is damaged.	Observe the beeps and LED lights on the front of the workstation. See POST error messages on page 131 .

Solving display problems

Table 5-7 Display problems

Problem	Cause	Solution
Blank screen (no video).	The cable connections are not correct.	Check the cable connections from the monitor to the workstation and to a working electrical outlet.
	The monitor is off.	Switch the monitor to on (LED is on). You might need to refer to the monitor manual for an explanation of the LED signals.
	Screen blanking utility installed or energy saver features enabled.	Press any key or click the mouse button and, if set, enter your password.
	System ROM is bad; system is running in FailSafe Boot Block mode (indicated by eight blinks/beeps).	Reflash the ROM using a ROMPaq diskette or a CD.
	Fixed-sync monitor will not sync at the resolution chosen.	Be sure that the monitor can accept the same horizontal scan rate as the resolution chosen.
	Computer is in Standby mode and the system LED is flashing	Press the power button to resume from mode.
	 CAUTION When attempting to resume from Standby mode, do not hold down the power button for more than four seconds. Otherwise, the workstation will shut down and you will lose your data.	
Monitor settings in the workstation are not compatible with the monitor.		<ol style="list-style-type: none"> Restart the workstation and press F8 during startup when you see Press F8 in the bottom-right corner of the screen. Using the keyboard arrow keys, select Enable VGA Mode and press Enter. In Windows Control Panel, double-click the Display icon and click the Settings tab. Use the sliding control to reset the resolution. Refer to your operating system and graphics card documentation for information on changing display settings.
The display works properly during the POST but goes blank when the OS starts.	The display settings in the operating system are incompatible with your graphics card and monitor.	<ol style="list-style-type: none"> Restart the workstation and press F8 during startup when you see Press F8 in the bottom-right corner of the screen. Using the keyboard arrow keys, select Enable VGA Mode and press Enter. In Windows Control Panel, double-click the Display icon and click the Settings tab. Use the available functions to set the display to the proper values. Refer to your operating system and graphics card documentation for information on changing display settings.

Table 5-7 Display problems (continued)

Problem	Cause	Solution
Power LED flashes red six times, once every second, followed by a two second pause, and the workstation beeps six times.	Pre-video graphics error.	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <ol style="list-style-type: none"> 1. Ensure that the auxiliary power cable (if applicable) is securely connected. 2. Reseat the graphics card. 3. Replace the graphics card. 4. Replace the system board.
Monitor does not function properly when used with energy saver features.	Monitor without energy saver capabilities is being used with energy saver features enabled.	Disable monitor energy saver feature.
Characters are dim.	The brightness and contrast controls are not set properly.	Adjust the monitor brightness and contrast controls.
	Cables are not properly connected.	Verify that the graphics cable is securely connected to the graphics card and the monitor.
Video is blurry or requested resolution cannot be set.	If the graphics controller was upgraded, the correct video drivers might not be loaded.	Install the video drivers included in the upgrade kit.
	Monitor is not capable of displaying requested resolution.	Change requested resolution.
The picture is broken up, rolls, jitters, or flashes.	The monitor connections might be incomplete or the monitor might be incorrectly adjusted.	<ol style="list-style-type: none"> 1. Be sure the monitor cable is securely connected to the workstation. 2. In a two-monitor system or if another monitor is in close proximity, be sure the monitors are not interfering with each other's electromagnetic field by moving them apart. 3. Be sure that fluorescent lights or fans are not too close to the monitor.
	Monitor needs to be degaussed.	Degauss the monitor.
Vibrating or rattling noise coming from inside a CRT monitor when powered on.	Monitor degaussing coil has been activated.	None. It is normal for the degaussing coil to be activated when the monitor is powered on.
Clicking noise coming from inside a CRT monitor.	Electronic relays have been activated inside the monitor.	None. It is normal for some monitors to make a clicking noise when turned on and off, when going in and out of Standby mode, and when changing resolutions.
High pitched noise coming from inside a flat panel monitor.	Brightness and contrast settings are too high.	Lower brightness and contrast settings.

Table 5-7 Display problems (continued)

Problem	Cause	Solution
Fuzzy focus; streaking, ghosting, or shadowing effects; horizontal scrolling lines; faint vertical bars; or unable to center the picture on the screen. (Flat panel monitors using an analog VGA input connection only.)	Flat panel monitor's internal digital conversion circuits might be unable to correctly interpret the output synchronization of the graphics card.	<ol style="list-style-type: none">1. Select the monitor's Auto-Adjustment option in the monitor's on-screen display menu.2. See the HP Support website and check for an updated display driver.3. Manually synchronize the Clock and Clock Phase on-screen display functions. Download the appropriate utility from the HP website to assist with the synchronization.
Certain typed symbols do not appear correct.	The font you are using does not support that particular symbol.	Use the Character Map to locate the and select the appropriate symbol. Click Start>All Programs>Accessories>System Tools>Character Map . You can copy the symbol from the Character Map into a document.

Solving audio problems

Table 5-8 Audio problems

Problem	Cause	Solution
Sound does not come out of the speaker or headphones.	Software volume control is turned down.	Double-click the Speaker icon on the taskbar and use the volume slider to adjust the volume.
	The external speakers are not turned on.	Turn on the external speakers.
	External speakers are plugged into the wrong audio jack.	See the sound card documentation for proper speaker connection.
	Audio cable not connected.	Connect audio cable between CD or DVD-ROM drive and the system board.
	Digital CD audio is not enabled.	Enable digital CD audio: <ol style="list-style-type: none"> 1. From the Control Panel, select System. 2. On the Hardware tab, click Device Manager. 3. Right-click the CD/DVD device and select Properties. 4. On the Properties tab, be sure Enable digital CD audio for this CD-ROM device is selected.
	Headphones or devices connected to the line-out connector mute the internal speaker.	Turn on and use headphones or external speakers, if connected, or disconnect headphones or external speakers.
	Volume is muted.	<ol style="list-style-type: none"> 1. From the Control Panel program, click Sound, Speech and Audio Devices, and then click Sounds and Audio Devices. 2. Clear the Mute check box.
Computer is in Standby mode and the system LED is flashing.	Press the power button to resume from Standby mode.  CAUTION When attempting to resume from Standby mode, do not hold down the power button for more than four seconds. Otherwise, the workstation will shut down and you will lose your data.	
Noise or no sound comes out of the speakers or headphones.	<ol style="list-style-type: none"> 1. If using digital speakers that have a stereo jack and want the system to auto-switch to digital, use a stereo-to-mono adapter to properly engage the auto-sense feature or use the multimedia device properties to manually switch the audio signal from analog to digital. 2. If the headphones have a mono jack, use the multimedia device properties to switch the system to analog out. 	



NOTE If you set digital as the **Output Mode**, the internal speaker and external analog speakers will no longer output audio until you switch back to an auto-sense or analog mode.

If you set analog as the **Output Mode**, external digital speakers will not function until you change the output mode back to an auto-sense or digital mode.

Table 5-8 Audio problems (continued)

Problem	Cause	Solution
Sound cuts in and out.	Processor resources are being used by other open applications.	Shut down open processor-intensive applications.
Workstation appears to be locked up while recording audio.	The hard disk might be full.	<ol style="list-style-type: none"> 1. Before recording, be sure there is enough free space on the hard disk. 2. Try recording the audio file in a compressed format.

Solving printer problems

Table 5-9 Printer problems

Problem	Cause	Solution
Printer does not print. Printer cable loose.	Printer is not turned on and online.	Turn the printer on and be sure it is online.
	The correct printer driver for the application are not installed.	<ol style="list-style-type: none"> 1. Install the correct printer driver for the application. 2. Try printing using the DOS command: <code>DIR C:\> [printer port]</code> where [printer port] is the address of the printer being used. If the printer works, reload the printer driver.
	If you are on a network, you might not have made the connection to the printer.	Make the proper network connections to the printer.
	Printer might have failed.	Run printer self-test.
	Printer is out of ink/toner.	Replenish ink/toner.
	Printer cable loose.	Check printer cable connection to non-networked, local printer.
Printer does not turn on.	The cables might not be connected properly.	Reconnect all cables.
Printer prints garbled information.	The correct printer driver is not installed.	Install the correct printer driver for the application.
	The cables might not be connected properly.	Reconnect all cables.
	Printer memory might be overloaded.	Reset the printer by turning it off for one minute, then turn it back on.
Printer is offline.	The printer might be out of paper.	<ol style="list-style-type: none"> 1. Check the paper tray and refill it if it is empty. 2. Select online.

Solving keyboard and mouse problems

Table 5-10 Keyboard and mouse problems

Problem	Cause	Solution	
Keyboard commands and typing are not recognized by the workstation.	Keyboard connector is not properly connected.	<ol style="list-style-type: none"> 1. Power off the workstation. 2. Reconnect the keyboard to the workstation and restart the workstation. 	
	Program in use has stopped responding to commands.	Shut down the workstation using the mouse and then restart the workstation.	
	Keyboard needs repairs.	Replace the keyboard.	
	Keyboard key is stuck down.	Remove any debris from the keyboard.	
	Workstation is in Standby mode and the system LED is flashing.	Press the power button to resume from Standby mode.  CAUTION When attempting to resume from Standby mode, do not hold down the power button for more than four seconds. Otherwise, the workstation will shut down and you will lose your data.	
Cursor will not move using the arrow keys on the keypad.	The Num Lock key might be on.	Press the Num Lock key. The Num Lock light should not be on if you want to use the arrow keys. The Num Lock key can be disabled (or enabled) in Computer Setup.	
Mouse does not respond to movement or is too slow.	Mouse connector is not properly plugged into the back of the workstation.	<ol style="list-style-type: none"> 1. Shut down the workstation using the keyboard. 2. Plug the mouse connector into the PS/2 or USB mouse connector in the workstation and restart the workstation. 	
	You need to increase mouse acceleration.	<ol style="list-style-type: none"> 1. In Windows, click Start>Control Panel and double-click Mouse. 2. Select the Motion tab and adjust the speed. 	
	Program in use has stopped responding to commands.	Shut down the workstation using the keyboard and then restart the workstation.	
	Mouse needs repairs.	Replace the mouse.	
	Workstation is in Standby mode and system LED is flashing.	Press the power button to resume from Stand By mode.  CAUTION When attempting to resume from Standby mode, do not hold down the power button for more than four seconds. Otherwise, the workstation will shut down and you will lose your data.	
	Mouse will only move vertically or horizontally, or movement is jerky.	Mouse roller ball is dirty.	Remove roller ball cover from the bottom of the mouse and clean it.

Solving front panel component problems

If you are experiencing problems with one of the front panel ports, you might be able to try your device in the corresponding port on the back side of the computer. If this does not fix the problem, or you must use the front panel ports, continue troubleshooting.

Some problems in this section are also discussed in other troubleshooting suggestions in this chapter.

Table 5-11 Front panel component problems

Problem	Cause	Solution
If a USB device, headphone, or microphone is not recognized by the workstation.	It is not properly connected.	<ol style="list-style-type: none"> 1. Power off the workstation. 2. Reconnect the device to the workstation and restart the workstation.
	The device does not have power.	If the USB device requires AC power, be sure one end is connected to the device and one end is connected to a live outlet.
	The correct device driver is not installed.	<ol style="list-style-type: none"> 1. Install the correct driver for the device. 2. You might need to reboot the workstation.
	The cable from the device to the computer does not work.	<ol style="list-style-type: none"> 1. If possible, replace the cable. 2. Restart the workstation.
	The device is not working.	<ol style="list-style-type: none"> 1. Replace the device. 2. Restart the workstation.
If a USB, audio, and IEEE-1394 devices are not working.	The internal cables might not be connected to the system board or the PCI card.	<ol style="list-style-type: none"> 1. Power off the workstation. 2. Connect the cables correctly.
A device in the IEEE-1394a port is not responsive.	Cables of new external device are loose or power cables are unplugged.	Be sure that all cables are properly and securely connected.
	The power switch on the device is not turned on.	Power off the workstation, and power on the external device, then turn on the workstation to integrate the device with the workstation system.

Solving hardware installation problems

You might need to reconfigure the workstation when you add or remove hardware, such as an additional diskette drive. If you install a PnP (Plug 'n Play) device, Windows XP automatically recognizes the device and configure the workstation. If you install a non-PnP device, you must reconfigure the workstation after completing installation of the new hardware.

Table 5-12 Hardware installation problems

Problem	Cause	Solution
A new device is not recognized as part of the system.	Device is not seated or connected properly.	Be sure that the device is properly and securely connected and that pins in the connector are not bent.
	Cables of new external device are loose or power cables are unplugged.	Be sure that all cables are properly and securely connected and that pins in the cable or connector are not bent.
	Power switch of new external device is not turned on.	Power off the workstation, power on the external device, and power on the workstation to integrate the device with the workstation system.
	When the system advised you of changes to the configuration, you did not accept them.	Reboot the workstation, and follow the instructions for accepting the changes.
	A PnP board might not automatically configure when added if the default configuration conflicts with other devices.	Use the Device Manager to clear the automatic settings for the board and select a basic configuration that does not cause a resource conflict. You can also use Computer Setup to reconfigure or disable devices to resolve the resource conflict.
	Device hardware is not properly jumpered or otherwise configured.	Read the device-specific configuration information and check for incorrect settings or conflicts with other devices already installed in the system.
Workstation will not start.	Wrong memory modules were used in the upgrade or memory modules were installed in the wrong location.	<ol style="list-style-type: none"> 1. Review workstation documentation to determine if you are using the correct memory modules and to verify the proper installation. 2. Observe the beeps and LED lights on the front of the workstation. Refer to POST error messages on page 131 to determine possible causes.
	PCI Express power cable might be plugged into the wrong power connector.	Ensure that the auxiliary PCI Express power cable is correctly connected to the PCI Express card.

Table 5-12 Hardware installation problems (continued)

Problem	Cause	Solution
Power LED flashes red five times, once every second, followed by a two second pause, and the workstation beeps five times.	Memory is installed incorrectly or is bad.	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <ol style="list-style-type: none"> 1. Ensure DIMMs are loaded in the correct slots. 2. Reseat DIMMs. 3. Replace DIMMs one at a time to isolate the faulty module. 4. Replace third-party memory with HP memory. 5. Replace the system board.
Power LED flashes red six times, once every second, followed by a two second pause, and the workstation beeps six times.	Video card is not seated properly or is bad, or system board is bad.	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <ol style="list-style-type: none"> 1. Ensure that auxiliary power cable is connected correctly, if applicable. 2. Reseat the graphics card. 3. Replace the graphics card. 4. Replace the system board.

Solving network problems

These guidelines do not discuss the process of debugging the network cabling.

Table 5-13 Network problems

Problem	Cause	Solution
Wake-on-LAN feature is not functioning.	Wake-on-LAN is not enabled.	Use the Network control application to enable Wake-on-LAN.
Network driver does not detect network controller.	Network controller is disabled.	Run Computer Setup and enable network controller.
	Incorrect network driver.	Check the network controller documentation for the correct driver, or obtain the latest driver from the manufacturer's website.
Network status link light does not turn on or it never flashes.	No active network is detected.	Check cabling and network equipment for proper connection.
The network status light should flash when there is network activity.	Network controller is not set up properly.	Use the network control application to verify that the device is working properly.
	Network driver is not properly loaded.	Reinstall network drivers.
	System cannot auto-sense the network.	Disable auto-sensing capabilities and force the system into the correct operating mode.

Table 5-13 Network problems (continued)

Problem	Cause	Solution
Diagnostics reports a failure.	The cable is not securely connected.	Be sure that both ends of the data cable are securely connected.
	The cable is attached to the incorrect connector.	Be sure that the cable is attached to the correct connector.
	There is a problem with the cable or a device at the other end of the cable.	Be sure that the cable and device at the other end are operating correctly.
	Network controller interrupt is shared with an expansion board.	Under the Computer Setup Advanced menu, change the resource settings for the board.
	The network controller is defective.	 CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.
	Replace the NIC.	
Diagnostics passes, but the workstation does not communicate with the network.	Network drivers are not loaded, or driver parameters do not match current configuration.	<ol style="list-style-type: none"> 1. Be sure the network drivers are loaded and that the driver parameters match the configuration of the network controller. 2. Be sure the correct network client and protocol is installed.
	The network controller is not configured for this workstation.	Select the Network icon in the Control Panel and configure the network controller.
Network controller stopped working when an expansion board was added to the workstation.	Network controller interrupt is shared with an expansion board.	Under the Computer Setup Advanced menu, change the resource settings for the board.
	The network controller requires drivers.	Verify that the drivers were not accidentally deleted when the drivers for a new expansion board were installed.
	The expansion board installed is a Network Interface Card (NIC) and conflicts with the embedded NIC.	Under the Computer Setup Advanced menu, change the resource settings for the board.
Network controller stops working without apparent cause.	The files containing the network drivers are corrupted.	Reinstall the network drivers, using the <i>Restore Plus!</i> CD.
	The cable is not securely connected.	Be sure that both ends of the cable are securely attached to the correct devices.
	The network controller is defective.	 CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.
	Replace the NIC.	
New network card will not boot.	New network card might be defective or might not meet industry-standard specifications.	Install a working, industry-standard NIC, or change the boot sequence to boot from another source.

Table 5-13 Network problems (continued)

Problem	Cause	Solution
Cannot connect to network server when attempting Remote System Installation.	The network controller is not configured properly.	Verify Network Connectivity, that a DHCP Server is present, and that the Remote System Installation Server contains the NIC drivers for your NIC.
System setup utility reports unprogrammed EEPROM.	Unprogrammed EEPROM.	Flash the ROM.

Solving memory problems



CAUTION For those systems that support ECC memory, HP does not support mixing ECC and non-ECC memory. Otherwise, the system will not boot the operating system.

Table 5-14 Memory problems

Problem	Cause	Solution
System will not boot or does not function properly after installing additional memory modules.	Memory module is not the correct type or speed, or the new memory module is not seated properly.	Replace module with the correct industry-standard device for the workstation.
Out of memory error.	Memory configuration might not be set up correctly.	Use the Device Manager to check memory configuration.
	You have run out of memory to run the application.	Check the application documentation to determine the memory requirements, or add more memory.
Memory count during POST is wrong.	The memory modules might not be installed correctly.	Check that the memory modules have been installed correctly and that proper modules are used.
Insufficient memory error during operation.	Too many Terminate and Stay Resident programs (TSRs) are installed.	Delete any TSRs that you do not need.
	You have run out of memory for the application.	Check the memory requirements for the application or add more memory to the workstation.
Power LED flashes red 5 times, once every second, followed by a 2-second pause, and the workstation beeps 5 times.	Memory is installed incorrectly or is bad.	<p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <ol style="list-style-type: none"> 1. Ensure DIMMs are loaded in the correct slots. 2. Reseat DIMMs. 3. Replace DIMMs one at a time to isolate the faulty module. 4. Replace third-party memory with HP memory. 5. Replace the system board.
A total of 4 GB of RAM is installed, yet the 32-bit OS only recognizes ≈ 3 GB.	A 32-bit OS is limited by 4 GB of address space, and some of the space is used by I/O devices.	Use a video card that uses less on-board memory.

Solving processor problems

Table 5-15 Processor problems

Problem	Cause	Solution
Poor performance is experienced.	Processor is hot.	<ol style="list-style-type: none"> 1. Be sure the airflow to the workstation is not blocked. 2. Be sure the fans are connected and working properly (some fans only operate when needed). 3. Be sure the CPU heatsink is installed properly.
Power LED is red and stays on.	Processor is not seated properly or not installed.	<p> CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <ol style="list-style-type: none"> 1. Check to see that the processor is present. 2. Reseat the processor.

Solving CD-ROM and DVD problems

Table 5-16 CD-ROM and DVD problems

Problem	Cause	Solution
System will not boot from CD-ROM or DVD drive.	The CD-ROM or DVD boot is not enabled through the Computer Setup utility.	Run the Computer Setup utility and enable booting to removable media and verify boot order settings.
	Non-bootable CD/DVD in drive.	Place a bootable CD/DVD in the drive.
CD-ROM or DVD devices are not detected or driver is not loaded.	Drive is not connected properly or not properly configured.	<ol style="list-style-type: none"> 1. Reconnect power and data cables to the drive. 2. Install correct device driver.
Movie will not play in the DVD drive.	Movie might be regionalized for a different country.	See the documentation that came with the DVD drive.
	Decoder software is not installed.	Install decoder software.
Cannot eject compact disc (tray-load unit).	Disc not properly seated in the drive.	<ol style="list-style-type: none"> 1. Power off the workstation, and insert a thin metal rod into the emergency eject hole and push firmly. 2. Slowly pull the tray out from the drive until the tray is fully extended, and remove the disc.

Table 5-16 CD-ROM and DVD problems (continued)

Problem	Cause	Solution
CD-ROM, CD-RW, DVD-ROM, or DVD-R/RW drive cannot read a disc or takes too long to start.	Disc has been inserted upside down.	Reinsert the disc with the label facing up.
	The DVD-ROM drive takes longer to start because it has to determine the type of media played, such as audio or video.	Wait at least 30 seconds to let the DVD-ROM drive determine the type of media being played. If the disc still does not start, read the other solutions listed for this topic.
	CD or DVD disc is dirty.	Clean CD or DVD with a CD cleaning kit.
	Windows does not detect the CD-ROM or DVD-ROM drive.	<ol style="list-style-type: none">1. Use Device Manager to remove or uninstall the device in question.2. Restart the workstation and allow Windows to detect the device.
Recording audio CDs is difficult or impossible.	Wrong or poor quality media type.	<ol style="list-style-type: none">1. Try using a slower recording speed.2. Verify that you are using the correct media for the drive.3. Try a different brand of media. Quality varies widely between manufacturers.

Solving Internet access problems

Table 5-17 Internet access problems

Problem	Cause	Solution
Unable to connect to the Internet.	Internet Service Provider (ISP) account is not set up properly.	Verify Internet settings or contact the ISP for assistance.
	Modem is not set up properly.	Reconnect the modem. Verify the connections are correct using the quick setup documentation.
	Web browser is not set up properly.	Verify that the web browser is installed and set up to work with your ISP.
	Cable/DSL modem is not plugged in.	Plug in cable/DSL modem. You should see a "power" LED light on the front of the cable/DSL modem.
	The network cable is disconnected.	Connect the network cable between the cable modem and the workstation RJ-45 connector. If the connection works, the PC LED light on the front of the cable/DSL modem will be on.
	Cable/DSL service is not available or has been interrupted due to bad weather.	Try connecting to the Internet at a later time or contact your ISP. (If the cable/DSL service is connected, the "cable" LED light on the front of the cable/DSL modem will be on.)
	The CAT5 10/100/1000 cable is disconnected.	Connect the CAT5 10/100 cable between the cable modem and the workstations's RJ-45 connector. (If the connection is good, the "PC" LED light on the front of the cable/DSL modem will be on.)
	IP address is not configured properly.	Contact the ISP for the correct IP address.
Cookies are corrupted.		<ol style="list-style-type: none"> 1. Select Start>Control Panel. 2. Double-click Internet Options. 3. On the General tab, click Delete Cookies.
Cannot automatically launch Internet programs.	You must log on to the ISP before some programs will start.	Log on to the ISP and launch the desired program.
Internet takes too long to download websites.	Modem is not set up properly.	Verify that the correct modem speed and COM port are selected.
		<ol style="list-style-type: none"> 1. Select Start>Control Panel. 2. Double-click System. 3. Click the Hardware tab. 4. In the Device Manager area, click Device Manager. 5. Double-click Ports (COM & LPT). 6. Right-click the COM port your modem uses, then click Properties. 7. Under Device status, verify that the modem is working properly.

Table 5-17 Internet access problems (continued)

Problem	Cause	Solution
		<ol style="list-style-type: none"><li data-bbox="911 226 1465 254">8. Under Device usage, verify the modem is enabled.<li data-bbox="911 279 1465 323">9. If there are further problems, click Troubleshoot and follow the on-screen instructions.

POST error messages

POST is a program run at startup that initializes and runs some tests on installed hardware. An audible and/or visual message occurs if the POST encounters a problem. POST checks the following items to ensure that the workstation system is functioning properly:

- Keyboard
- Memory modules
- Diskette drives
- All SATA, IDE, and SAS mass storage devices
- Processors
- Controllers



NOTE If the Power-On Password is set, a key icon appears on the screen while POST is running. You must enter the password before continuing.

Table 5-18 POST error messages

Screen Message	Probable Cause	Recommended Action
101–Option ROM Error.	Plug-in card ROM checksum.	Update the ROM on the card.
102–System Board Failure	DMA, timers.	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <ol style="list-style-type: none"> 1. Clear CMOS by pressing the Clear CMOS button on the system board. 2. Remove expansion boards. 3. Replace the system board.
103–System Board Failure	DMA, timers.	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <ol style="list-style-type: none"> 1. Clear CMOS by pressing the Clear CMOS button on the system board. 2. Remove expansion boards. 3. Replace the system board.
110–Out of Memory Space for Option ROMs	Option ROM for a device was unable to run due to memory constraints.	Remove expansion boards and disable unneeded devices from I/O>Onboard Devices or Storage>Storage Options . Run Computer Setup (F10).

Table 5-18 POST error messages (continued)

Screen Message	Probable Cause	Recommended Action
162–System Options Not Set	Your system configuration has changed since your last boot, in which case press F1 . Or, a loss of power to the Real Time clock has occurred.	<ol style="list-style-type: none"> 1. Run Computer Setup (F10). 2. Set the date and time under Windows Control Panel or in the F10 Setup menu. 3. If the problem persists, replace the RTC battery.
163–Time and Date Not Set	<p>Invalid time or date in configuration memory.</p> <p>RTC (real-time clock) battery might need to be replaced.</p>	<ol style="list-style-type: none"> 1. Set the date and time under Control Panel or in F10 Setup, depending on the operating system. 2. If the problem persists, replace the RTC battery.
164–Memory Size Error	The system memory size has changed since the last boot.	<ol style="list-style-type: none"> 1. Pressing F1 will record the configuration. 2. If the problem persists, be sure memory modules (if any) are installed correctly. 3. If third-party memory has been added, test using HP memory only. 4. Verify proper memory module type.
201–Memory Error	The memory test performed during startup failed.	<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;">  CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down. </div> <ol style="list-style-type: none"> 1. Run Computer Setup (F10 Setup) or Windows utilities. 2. Ensure that memory modules are installed correctly. 3. Verify proper memory module type. 4. If third-party memory has been added, test using HP memory only. 5. Remove and replace memory modules one at a time to isolate faulty module. 6. Replace the faulty memory modules. 7. If error persists after replacing memory modules, replace the system board.
207–ECC Corrected Single Bit Errors in DIMM slot(s)	Corrected ECC error(s) detected.	<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;">  CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down. </div> <ol style="list-style-type: none"> 1. Verify proper memory module type. 2. Verify 3rd party/HP memory. 3. Try another memory socket. 4. Replace memory module if problem persists.

Table 5-18 POST error messages (continued)

Screen Message	Probable Cause	Recommended Action
211–Memory warning condition detected	An unknown issue with one of the DIMMs has been detected.	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <ol style="list-style-type: none"> 1. Verify proper memory module type. 2. Try another memory socket. 3. Replace memory module if problem persists.
213–Incompatible ECC Memory Module in memory Socket(s)	The memory modules in the system are either not all ECC, or not all non-ECC. This could also be caused because the DIMM is missing critical SPD information.	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <ol style="list-style-type: none"> 1. Verify that all memory modules are ECC or non-ECC. 2. Replace memory module if problem persists.
214–DIMM Configuration Warning	DIMMs not installed correctly (not paired correctly).	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <p>Refer to Memory on page 69 for the correct memory configurations and reseat the DIMMs accordingly.</p>
215–Cannot Interleave Unequal Memory Nodes	Memory node interleave enabled but memory on CPU0 is unequal with the memory on CPU1.	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <ol style="list-style-type: none"> 1. Reconfigure memory in both nodes equally. 2. Disable memory node interleave.
301–Keyboard Error	Keyboard failure.	<ol style="list-style-type: none"> 1. Reconnect keyboard with workstation powered off. 2. Check the connector for bent or missing pins. 3. Be sure that none of the keys are pressed or stuck. 4. Replace keyboard.

Table 5-18 POST error messages (continued)

Screen Message	Probable Cause	Recommended Action
303–Keyboard Controller Error	I/O board keyboard controller.	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <ol style="list-style-type: none"> 1. Reconnect keyboard with workstation powered off. 2. Replace the system board.
304–Keyboard or System Unit Error	Keyboard failure.	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <ol style="list-style-type: none"> 1. Reconnect the keyboard to the powered-off workstation. 2. Be sure that none of the keys are pressed or stuck. 3. Replace keyboard. 4. Replace system board.
510–Splash Screen Image Corrupted	Splash Screen image has errors.	Restore BIOS.
511–CPU Fan Not Detected	Fan is not connected or it might have malfunctioned.	<ol style="list-style-type: none"> 1. Reseat fan cable. 2. Reseat the fan. 3. Replace the fan.
512–PCI 1 Fan Not Detected	Fan is not connected or it might have malfunctioned.	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <ol style="list-style-type: none"> 1. Reseat PCI fan cable. 2. Replace PC1 fan.
513–Chassis Fan or Memory Fan Not Detected	Memory or system fan is not connected or it might have malfunctioned.	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <ol style="list-style-type: none"> 1. Reseat memory or system fan connector. 2. Replace memory or system fan.
516–Processors Do Not Have the Same Frequency Operating Range	Installed processors operate at different frequencies.	Replace a processor so that both operate at the same frequency.

Table 5-18 POST error messages (continued)

Screen Message	Probable Cause	Recommended Action
516—Processors Do Not Have the Same Frequency Operating Range	Installed processors operate at different frequencies.	Replace a processor so that both operate at the same frequency.
517—Front IEEE 1394 Not Connected	Front IEEE 1394 port is not connected.	 CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down. <ol style="list-style-type: none">1. Connect IEEE 1394 cable to system board.2. Replace system board.
518—Detected invalid MAC address	Workstation has invalid MAC address.	 CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down. <ul style="list-style-type: none">• Verify correct MAC address. If incorrect, replace system board.
601—Diskette Controller Error	Diskette controller circuitry or diskette drive circuitry incorrect.	 CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down. <ol style="list-style-type: none">1. Run Computer Setup (F10 Setup).2. Ensure that cables are connected correctly.3. Check and replace cables.4. Clear CMOS by pressing the Clear CMOS button on the system board.5. Replace diskette drive.6. Replace the system board.
605—Diskette Drive Type Error	Mismatch in drive type.	<ol style="list-style-type: none">1. Check drive cables.2. Run Computer Setup (F10 Setup).3. Disconnect any other diskette controller devices (tape drives).4. Clear CMOS by pressing the Clear CMOS button on the system board.5. Replace diskette drive.
710—NET Watchdog Timer Expired from Last Boot	System hung during last boot.	Press F1 to boot.
912—Computer Cover Has Been Removed Since Last System Start Up	System has been opened since last boot.	No action required.

Table 5-18 POST error messages (continued)

Screen Message	Probable Cause	Recommended Action
914–Hood Lock Coil is not Connected	Hood lock mechanism is missing or not connected.	<ol style="list-style-type: none"> 1. Reconnect or replace the hood locking mechanism. 2. Reseat or replace the hood locking mechanism cable.
915–Fan Power from Power Supply Not Connected	The fan power cable is not connected, or the power supply is bad.	<p> CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <ol style="list-style-type: none"> 1. Verify that all power supply cables are connected. 2. Replace the power supply.
916–Power Button Not Connected	The power button is not connected.	<p> CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <p>Connect the power button.</p>
917–Front Audio Not Connected	The front audio cable is not connected.	<p> CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <p>Connect the front audio cable.</p>
918–Front USB Not Connected	Front USB is not connected.	<p> CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <p>Connect the front USB cable.</p>
921–Device in PCI Express Slot Failed to Initialize	A PCI Express card was detected in one of the slots, but failed to initialize properly.	<p> CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <p>Reseat all PCI Express cards. If this failure occurred after inserting a new card, there could be a problem with that card.</p>
922–Fatal error on slot #	Fatal error occurred in the designated slot.	<p> CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <p>Try moving card to a different slot. If the problem persists, try replacing the card.</p>

Table 5-18 POST error messages (continued)

Screen Message	Probable Cause	Recommended Action
923–Non fatal error on slot #	A PCI or PCIe non-fatal error condition occurred for the device in the designated slot.	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <ol style="list-style-type: none"> 1. Reseat the card. 2. Try moving card to a different slot. 3. If the problem persists, replace the card.
1155–Serial Port Address Conflict Detected.	Both external and internal serial ports are assigned to same IRQ.	<ol style="list-style-type: none"> 1. Remove any COM port expansion cards. 2. Clear CMOS by pressing the Clear CMOS button on the system board. 3. Reconfigure card resources and run Computer Setup (F10 Setup). 4. Run Computer Setup or Windows utilities.
1201–System Audio Address Conflict Detected	Device IRQ address conflicts with another device. (Usually due to an add-in audio card.)	Reset the IRQ.
1720 SMART Hard Drive Detect Imminent Failure	Hard drive is about to fail. (Some hard drives have a firmware patch that will fix an erroneous error message.)	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <ol style="list-style-type: none"> 1. Determine if hard drive is giving correct error message. 2. Run the Drive Protection System test if applicable. 3. Apply firmware patch if applicable (see http://www.hp.com/support). 4. Back up contents and replace hard drive.
1800–Temperature Alert	Internal temperature exceeds specification.	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <ol style="list-style-type: none"> 1. Check that workstation air vents are not blocked and that the cooling fan is running. 2. Verify processor speed selection. 3. Replace the processor. 4. Replace the system board.
1801–Microcode Update Error	Missing or Invalid Processor Microcode Update.	Upgrade BIOS to the current version.

Table 5-18 POST error messages (continued)

Screen Message	Probable Cause	Recommended Action
1802–CPU0 Not Supported	The system board does not support the processor.	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <p>Replace the processor with a compatible one.</p>
1803–CPU1 Not Supported	The system board does not support the processor.	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <p>Replace the processor with a compatible one.</p>
1805–CPU Bypass Board is Missing	Bypass board not detected on single-processor system.	 <p>CAUTION Disconnect AC power from the workstation before reseating or replacing components because there is power to the system board even when the workstation is powered down.</p> <p>Install bypass board or install second processor.</p>
Invalid Electronic Serial Number	Electronic serial number has become corrupted.	<ul style="list-style-type: none"> • Run Computer Setup. Enter the serial number under Security>System IDs, and save the changes.

A SAS devices

Supported SAS RAID configurations

The following RAID configurations are supported on the HP xw9400 Workstation.



NOTE This section does not apply to configuring RAID in the Linux environment. For RAID in the Linux environment, configure SW RAID configurations as provided by Red Hat Enterprise Linux.

- Up to 5 internal or 8 external SAS hard disk drives/JBOD.
- External connections require optional internal-to-external cable
- SAS drives require SATA to SAS data and power converter
- LSI MyStorage Utility for Windows
- RAID 0 (IS) – Striped disk array
 - Two drives minimum
 - Improved I/O performance
 - No fault tolerance
- RAID 1 (IM) — Mirrored disk array
 - Two drives
 - Improved read performance
 - 100% redundancy
 - Can recover from single drive failure
- RAID 1E (IME)
 - Three drives minimum
 - Can be an odd number of drives
 - Can always recover from a single drive failure, and in some cases, recover from two drive failures

SAS RAID 0 (IS) configuration

Follow the steps below to configure an Integrated Striped (IS) volume with the BIOS-based configuration utility. The configuration procedure assumes that the system already has the required disks attached to the SAS/SATA ports.

1. At the BIOS splash screen, press any key to view option ROM messages.
2. Press **Ctrl-C** at the prompt **Press Ctrl-C to Start LSI Logic Configuration Utility** to start the utility.
3. On the Adapter List screen of the LSI Logic Config Utility, use the arrow keys to highlight an adapter (SAS1068e), then press **Enter**.
4. On the Adapter Properties screen use the arrow keys to highlight **RAID Properties**, then press **Enter**.
5. In the Select New Array Type-SAS1068e screen, use the arrow keys to highlight **Create IS Volume**, then press **Enter**.
6. In the Create New Array-SAS1068e screen, use the arrow keys to select the first disk for the Create IS volume. Then use the arrow keys to move to the Raid Disk column for this disk, and press the **SPACE**, **+**, or **-** key to select **Yes** as the value for this column. If there is existing data on the disk, a message displays warning you that data on the disk is lost when the striped volume is created. Press the **M** key to migrate, or the **D** key to delete the data on the drive.



NOTE An xw9400 chassis supports up to 5 internal hard disk drives. Using external cables, up to three additional drives can be connected via individual external drives for a total of eight drives. Up to 128 devices can be supported via connection to a JBOD.

7. Repeat the previous step to select up to four more disks for the striped volume.
8. Press the **C** key to create the array once all drives have been chosen.
9. Use the arrow keys to select **Save Changes then Exit this Menu**, then press **Enter**.
10. Press **Esc-Esc**. Use the arrow keys to highlight **Exit the Configuration Utility and Reboot**, then press **Enter**.
11. If necessary, change the boot order in system BIOS to obtain the correct boot device.

SAS RAID 1 (IM) configuration

Follow the steps below to configure an Integrated Mirroring (IM) volume with the BIOS-based configuration utility. The configuration procedure assumes that the system already has the required disks attached to the SAS/SATA ports.

1. At the BIOS splash screen, press any key to view option ROM messages.
2. Press **Ctrl-C** at the **Press Ctrl-C to Start LSI Logic Configuration Utility** prompt to enter the configuration utility.
3. On the Adapter List screen of the LSI Logic Config Utility, use the arrow keys to highlight an adapter (SAS1068e), then press **Enter**.
4. On the Adapter Properties-SAS1068e screen use the arrow keys to highlight **RAID Properties**, then press **Enter**.
5. On the Select New Array Type screen, use the arrow keys to highlight the **Create Volume IM** volume, then press **Enter**.
6. In the Create New Array-SAS1068e screen, use the arrow keys to select the primary disk for the IM volume (the disk with the data you want to mirror.) Use the arrow keys to move to the Raid Disk column for this disk and use the **Space**, **+**, or **-** key to select **Yes** as the value. If there is existing data on the disk, a message appears warning you that data on the disk is lost when the disk is used in an IM array.

Press the **M** key to keep the existing data and migrate to an IM array. Synchronization of the disk occurs. Press the **D** key to overwrite the existing data and create a new IM array. No synchronization is performed.



CAUTION All data on all disks in the array is deleted if **D** is selected.

After selecting **M** or **D**, the Drive Status changes to **Primary** for the initial drive selected.

7. Use the arrow keys to select the secondary (mirrored) disk for the IM volume. Use the **SPACE**, **+**, or **-** key to select **Yes** as the value for the Array Disk column. When the second drive selected in RAID Disk is set to **Yes**, Drive Status changes to **Secondary**.
 - [Optional] Use the arrow keys to select a hot spare disk for the IM volume. Use **SPACE**, **+**, or **-** to select **Yes** as the value in the Hot Spr column.
8. When you have completed selection of drives and hot spares for the IM array, press **C** to create the array.
9. Use the arrow keys to select **Save Changes then Exit this Menu**, then press **Enter**.
10. Press **Esc-Esc**. Use the arrow keys to highlight **Exit the Configuration Utility and Reboot**, and press **Enter**.
11. If necessary, change the boot order in system BIOS to obtain the correct boot device.

SAS RAID 1E (IME) configuration

Follow the steps below to configure an Integrated Mirroring Extended (IME) volume with the BIOS-based configuration utility. The configuration procedure assumes that the system already has the required disks attached to the SAS/SATA ports.

1. At the BIOS splash screen, press any key to view option ROM messages.
2. Press **Ctrl-C** at the **Press Ctrl-C to Start LSI Logic Configuration Utility** prompt to enter the configuration utility.
3. On the Adapter List screen of the LSI Logic Config Utility, use the arrow keys to highlight an adapter (SAS1068e), then press **Enter**.
4. On the Adapter Properties-SAS1068e screen use the arrow keys to select **RAID Properties**, then press **Enter**.
5. On the Select New Array Type-SAS1068e screen, use the arrow keys to highlight **Create IME Volume**, then press **Enter**.
 - In the Create New Array-SAS1068e screen, use the arrow keys to select the first disk for the IME volume. Use the arrow keys to move to the RAID Disk column for this disk, and use the **SPACE**, **+**, or **-** key to select **Yes** as the value.
6. Use the arrow keys to select the next disk for the IME volume. Use the **SPACE**, **+**, or **-** key to select **Yes** as the value for the RAID Disk column.
7. Repeat the previous steps to select up to four more disks for the IME volume. If you want to configure a hot spare disk for the volume, you can only select up to three more disks.
 - [Optional] Use the arrow keys to select a Hotspare disk for the IME volume. Use **SPACE**, **+**, and **-** to select **Yes** as the value in the Hot Spr column.
8. When you have completed selection of the drives and hot spares for the IME array, press **C** to create the array.
9. Use the arrow keys to highlight **Save Changes Then Exit this Menu**, and press **Enter**.
10. Press **Esc-Esc**. Use the arrow keys to highlight **Exit the Configuration Utility and Reboot**, and press **Enter**.
11. If necessary, change the boot order in system BIOS to obtain the correct boot device.

Changing boot order

If the RAID array will be a data array, the disk drive with the operating system must appear higher in the boot order. If the RAID array will be the operating system drive, it should appear higher in the boot order.

To change the boot order:

1. Press **F10** to call up the BIOS Setup utility when booting the system.
2. If first boot, select the desired language and press **Enter**. English is the default.
3. Use the arrow keys to highlight **Storage>Boot Order**, and press **Enter**.
4. In the Hard Drive section device names are listed in order of boot. Use the arrow keys to move the cursor to the device that you want to move. Press **Enter** to highlight the device.
5. Use the up/down arrow keys to move the device to the desired order location. Press **Enter** to un-highlight the device.
6. Press **F10** to save changes.
7. Use the arrow keys to highlight **File>Save Changes and Exit**. Press **Enter**, then **F10**.

B SATA devices

This appendix describes how to use the NVIDIA MediaShield utility to set up and manage SATA RAID volumes.

The SATA RAID option must be enabled in BIOS and the SATA drives must be attached to the workstation ports to configure them into a RAID array.

Attach the required number of SATA HDDs for the desired RAID level:

- RAID 0—two to six HDDs—data is striped across drives for performance
- RAID 1—two HDDs—data is mirrored on two drives for security
- RAID 5—three to six HDDs—data is striped across drives with parity for performance with security
- RAID 10—four to six HDDs—data is mirrored and striped across all drives for security and some performance

Enable SATA RAID option in BIOS

To enable the SATA RAID option in BIOS:

1. During boot up, press **F10** to enter the Setup menu. **Entering BIOS Setup (Press F10)** appears at the bottom of the screen.
2. If first boot, select the desired language and press **Enter**.
3. Use the arrow keys to highlight **I/O>Device Options** and press **Enter**.
4. Use the up/down arrow keys to place the cursor next to **SATA RAID**. Use the left/right arrow keys to change the State to **Enable**.



NOTE All six ports (0–5) then indicate they are enabled. If the operating system boot drive is a non-RAID SATA drive, this port should have RAID disabled.

5. Use the up/down arrow keys to place the cursor next to the ports that are **not** to be included in the RAID array. Use the left/right arrow keys to change the state of each of them to **Disable**.
6. Press **F10** when all ports have been set to the desired state.
7. Use the arrow keys to highlight **File>Save Changes and Exit**. Press **Enter**, then press **F10** to save changes.

The workstation will reboot after the changes are saved. After the workstation reboots, the BIOS displays the MediaShield copyright message.

Configuring a SATA RAID array

To configure a SATA RAID array:

1. At the BIOS splash screen, press any key to view option ROM messages.
2. Press **F6** to enter the RAID setup utility when **Press F6 to enter RAID setup utility** is displayed.
3. On the Define a New Array screen, **RAID Mode** is highlighted in blue and mirroring is set as the default setting. Press **Enter** to show the RAID modes. This mode enables control of mirroring, striping, stripe mirroring, spanning, and RAID 5.
4. Use the up/down arrow keys to highlight in red the desired RAID type, then press **Enter**. **The desired RAID mode will be highlighted in blue.**
5. Press the **Tab** key to move the blue highlight to **Striping Block**.
6. Use the up/down arrow keys to highlight in red the desired striping block size (4K, 8K, 16K 32K, 64K, 128K or Optimal). Press **Enter** to select the desired size.



NOTE Optimal is the default and is generally selected. It is determined by the RAID controller for best fit.

7. Press the **Tab** key to move the blue highlight to the **Free Disks** section.



NOTE All drives available for RAID are listed and the first drive is highlighted in red.

8. Use the up/down arrow keys to highlight in red the drives to be included in the RAID array.
9. Use the right arrow key to move the drive to the **Array Disks** section.



NOTE The left arrow key moves the red highlighted drive in the Array Disks section to the Free Disks section.

10. Press **F7** to finish when all desired drives selected for the array are in the Array Disks section.
11. To clear disk data press **Y**, or to save disk data in the array press **N**.

The Array List window appears showing the created array. It contains Status, Bootable, Vendor, and Array Model Name information.

12. Press **Ctrl-X** to exit the utility.

Changing boot order

If the RAID array will be a data array, the disk drive with the operating system must appear higher in the boot order. If the RAID array will be the operating system drive, it should appear higher in the boot order.

To change the boot order:

1. Press **F10** to call up the BIOS Setup utility when booting the system.
2. If first boot, select the desired language and press **Enter**. English is the default.
3. Use the arrow keys to highlight **Storage>Boot Order**, and press **Enter**.
4. In the Hard Drive section device names are listed in order of boot. Use the arrow keys to move the cursor to the device that you want to move. Press **Enter** to highlight the device.
5. Use the up/down arrow keys to move the device to the desired order location. Press **Enter** to un-highlight the device.
6. Press **F10** to save changes.
7. Use the arrow keys to highlight **File>Save Changes and Exit**. Press **Enter**, then **F10**.

Deleting RAID volumes


Use the NVIDIA MediaShield utility to delete RAID volumes.

1. Press **F6** to enter the RAID setup utility when **Press F6 to enter RAID setup utility** is displayed. The MediaShield Utility displays the array list. One of the arrays listed is highlighted in red.
2. Use the up/down arrow keys to highlight RAID volume to be deleted.
3. Press **Enter** to enter the array details. The Array Details screen shows the array details. Press **D** to delete, then **Y** to confirm the delete.

The screen then returns to either Array List or Define a New Array.

C Connector pins


Connector pin descriptions

Ethernet connector	Pin	Signal
	1	(+) Transmit Data
	2	(-) Transmit Data
	3	(+) Receive Data
	4	Unused
	5	Unused
	6	(-) Receive Data
	7	Unused
	8	Unused

Serial connector	Pin	Signal
	1	Carrier Detect
	2	Receive Data
	3	Transmit Data
	4	Data Terminal Ready Signal
	5	Ground
	6	Data Set Ready
	7	Request to Send
	8	Clear to Send
	9	Ring Indicator


USB connector	Pin	Signal
	1	+5 VDC
	2	- Data
	3	+ Data
	4	GND

IEEE 1394 connector	Pin	Signal
---------------------	-----	--------




1	power
2	gnd
3	tpb-
4	tpb+
5	tpa-
6	tpa+

Microphone connector (1/8 inch)




Pin	Signal
1 (Tip)	Audio
2 (Ring)	Power
3 (Shield)	Ground

Headphone connector (1/8 inch)




Pin	Signal
1 (Tip)	Audio_Left
2 (Ring)	Audio_Right
3 (Shield)	Ground

Line-in audio connector (1/8 inch)



Pin	Signal
1 (Tip)	Audio_In_Left
2 (Ring)	Audio_In_Right
3 (Shield)	Ground

Line-out audio connector (1/8 inch)




Pin	Signal
1 (Tip)	Audio_Out_Left
2 (Ring)	Audio_Out_Right
3 (Shield)	Ground

SPDIF OUT connector




Pin	Signal
1	+VDC
2	Ground

SPDIF OUT internal header	Pin	Signal
	1	+VDC
	2	Ground



NOTE The SPDIF Out internal header is used in parallel with the SPDIF OUT connector. Only one should be used at a time.

SATA connector




Pin	Signal	Pin	Signal	Pin	Signal
Data Cable		Power Cable		Power Cable	
S-1	Ground	P-1	3.3-V power	P-8	5-V power
S-2*	A+	P-2	3.3-V power	P-9	5-V power
S-3*	A-	P-3	3.3-V power	P-10	Ground
S-4	Ground	P-4	Ground	P-11	Reserved
S-5**	B-	P-5	Ground	P-12	Ground
S-6**	B+	P-6	Ground	P-13	12-V power
S-7	Ground	P-7	5-V power	P-14	12-V power
				P-15	12-V power

* S2 and S3 differential signal pair


**S5 and S6 differential signal pair

SAS connector




Segment	Pin	Backplane receptacle	Plug and cable receptacles
Primary signal segment	S1	SIGNAL GROUND	
	S2	TP+	RP+
	S3	TP-	RP-
	S4	SIGNAL GROUND	
	S5	RP-	TP-
	S6	RP+	TP+
	S7	SIGNAL GROUND	
Secondary signal segment	S8	SIGNAL GROUND	
	S9	TS+	RS+
	S10	TS-	RS-
	S11	SIGNAL GROUND	
	S12	RS-	TS-
	S13	RS+	TS+
	S14	SIGNAL GROUND	
Power segment	P1	V_{33}^c	
	P2	V_{33}^c	
	P3	V_{33}^c precharge ^c	
	P4	GROUND	
	P5	GROUND	
	P6	GROUND	
	P7	V_5^c precharge ^c	
	P8	V_5^c	
	P9	V_5^c	
	P10	GROUND	
	P11	READY LED ^d	
	P12	GROUND	
	P13	V_{12}^c precharge ^c	
	P14	V_{12}^c	
	P15	V_{12}^c	

VGA connector




Pin	Signal	Pin	Signal	Pin	Signal
1	Red Analog	6	GND	11	Monitor ID
2	Green Analog	7	GND	12	DDC Serial Data
3	Blue Analog	8	GND	13	Horizontal Sync
4	Monitor ID	9	+5V DC	14	Vertical Sync
5	GND	10	GND	15	DDC Serial Clock

DVI connector




Pin	Signal	Pin	Signal
1	T.M.D.S DATA 2-	16	HOT PLUG DETECT
2	T.M.D.S DATA 2+	17	T.M.D.S DATA 0-
3	T.M.D.S DATA 2/4 SHIELD	18	T.M.D.S DATA 0+
4	T.M.D.S DATA 4-	19	T.M.D.S DATA 0/5 SHIELD
5	T.M.D.S DATA 4+ 2	0	T.M.D.S DATA 5-
6	DDC CLOCK	21	T.M.D.S DATA 5+
7	DDC DATA	22	T.M.D.S CLOCK SHIELD
8	ANALOG VERT. SYNC	23	T.M.D.S CLOCK+
9	T.M.D.S DATA 1-	24	T.M.D.S CLOCK-
10	T.M.D.S DATA 1+		
11	T.M.D.S DATA 1/3 SHIELD	C1	ANALOG RED
12	T.M.D.S DATA 3-	C2	ANALOG GREEN
13	T.M.D.S DATA 3+	C3	ANALOG BLUE
14	+5V POWER	C4	ANALOG HORZ SYNC
15	GND	C5	ANALOG GROUND

ATA/ATAPI (IDE) standard drive cable connector




Pin	Signal	Pin	Signal	Pin	Signal
1	Reset	15	DD1	29	DMAK
2	GND	16	DD14	30	GND
3	DD7	17	DD0	31	INTRQ
4	DD8	18	DD15	32	IOCS16
5	DD6	19	GND	33	DA1
6	DD9	20	(Key)	34	PDIAG (cable detect)
7	DD5	21	DMARQ	35	DA0
8	DD10	22	GND	36	DA2
9	DD4	23	DIOW	37	CS1FX
10	DD11	24	GND	38	CS3FX
11	DD3	25	DIOR	39	DASP
12	D12	26	GND	40	GND
13	D2	27	IORDY		
14	D13	28	CSEL		

24-Pin Main power connector




1	+3.3 V	8	POK	14	-12 V	21	+5 V
2	+3.3 V	9	+5 Vaux	15	GND	22	+5 V/+5 V-Rsense
3	GND	10	+12V-B	16	PS_ON_L	23	+5 V
4	+5 V	11	+12V-B	17	GND	24	GND
5	GND	12	+3.3 V	18	GND		
6	+5 V	13	+3.3 V/+3.3 V-Rsense	19	GND		
7	GND			20			


4-Pin power (memory system board) connector	Pin	Color	Signal
	1	BLK	GND
	2	BLK	GND
	3	BLK w/YEL stripe	+12V-M
	4	BLK w/YEL stripe	+12V-M


8-Pin power (for CPUs and onboard regulators) connector	Pin	Color	Signal
	1	BLK	GND
	2	BLK	GND
	3	BLK	GND
	4	BLK	GND
	5	Gray	+12 V CPU0 Rsense
	6	BLK w/WHT stripe	+12 V CPU0
	7	BLK w/light blue stripe	+12V CPU1
	8	BLK w/light blue stripe	+12V CPU1



NOTE The 6-pin power (auxiliary PCI Express) is only required with high-powered graphics cards.

6-Pin power (auxiliary PCI Express)	Pin	Color	Signal
	1	BLK w/YEL stripe	+12V-G
	2	BLK w/YEL stripe	+12V-G
	3	BLK w/YEL stripe	+12V-G
	4	BLK	GND
	5	BLK	GND
	6	BLK	GND

Keyboard connector		Pin	Signal
 	1	Data	
	2	Unused	
	3	Ground	
	4	+5 VDC	
	5	Clock	
	6	Unused	

Mouse connector		Pin	Signal
 	1	Data	
	2	Unused	
	3	Ground	
	4	+5 VDC	
	5	Clock	
	6	Unused	

D System board designators

This appendix lists the system board designators for this system.

Designator	Silkscreen	Component
BAT1	BAT1	Battery retainer
E15	CRISIS RECOVERY	Boot Block recovery jumper
E49	CLR PSWD	Clear password jumper
J9	None	Stacked RJ45/dual USB
J12	FRNT 1394	Front panel 1394a header
J14		SPDIF OUT connector
J15	None	Stacked RJ45/dual USB
J20	SLOT3 PCI32/33	PCI 32-bit slot
J25	SLOT6 PCI-X x100	PCI-X slot
J26	SLOT7 PCI-X x100/133	PCI-X slot
J31	SLOT1 PCI-E x8	PCIe x8 slot
J32	SLOT5 PCI-E x16	PCIe x16 slot
J33	SLOT4 PCI-E x8	PCIe x8 slot
J34	FRNT-P	Front panel connector
J41	SLOT2 PCI-E x16	PCI Express x16 slot for graphics
J68	None	Stacked keyboard/mouse connector
J83		Triple stacked audio jack
J84	1394/USB	IEEE 1394a/dual USB stacked connector
JP13	1-2 FORCE TO100 MHz 2-3 100/133 MHz (DEFAULT)	PCI-X bus speed select jumper*
JP16	HBA HDD LED ACTIVITY	HBA HDD LED activity header
JP30	FAN DET OVR	Fan detection override jumper
P1	PWR	Main power connector (24-pin)
P2	PWR2	Memory power connector (4-pin)
P3	PWRCPU	Processor power connector (8-pin)

Designator	Silkscreen	Component
P7	CD	CD analog audio connector
P8	CHASSIS FAN	Primary chassis fan header
P10	FLPY	Floppy connector
P11	AUX	Auxiliary audio connector
P19	SPDIF OUT	SPDIF OUT header
P20	PRIMARY IDE	Primary IDE connector
P23	FRNT AUD	Front panel audio header
P24	FRNTUSB2-3	Front panel USB header
P25	IUSB1	Internal USB header
P26	IUSB0	Internal USB header (Requires AMO kit with USB cable)
P54	None	Serial port connector
P60-63, P66-67	SATA0-SATA5	SATA Connectors
P70	CPUFAN0	CPU0 fan header
P71	CPUFAN1	CPU1 fan header
P80-87	SAS/SATA0-SAS/SATA7	SAS Connectors
P91	LIQUID COOLING FAN	Liquid cooling fan connector
P92	PCI FAN	PCI fan header
P93	MEMORY FAN	Memory fan header
P94	12V FAN	12-V fan header
P95	12V FAN	12-V fan header
SW50	CMOS	Clear CMOS switch/push button
U15	ROM	ROM socket
XMM1	DIMM3b	Memory slot
XMM2	DIMM3a	Memory slot
XMM3	DIMM1b	Memory slot
XMM4	DIMM1a	Memory slot
XMM5	DIMM4b	Memory slot
XMM6	DIMM4a	Memory slot
XMM7	DIMM2b	Memory slot
XMM8	DIMM2a	Memory slot
XU1	CPU0	Primary processor socket
XU2	CPU1	Secondary processor socket

* With the jumper on pins 1 and 2, the PCI-X bus speed is 100 MHz, regardless of the card configuration in slots 6 and 7. With the jumper on pins 2 and 3 (default), the following PCI-X bus speed/card configuration applies:

Card configuration	Max PCI-X bus speed achieved*
One card in slot 7 only	133 MHz
One card in slot 6 only	100 MHz
Two cards, one in each slot	100 MHz

* Dependent upon card capability.

E Power cord set requirements

The power cord set (flexible cord or wall plug) received with this product meets the requirements for use in the country where you purchased the equipment.

If you must obtain a power cord for a different country, purchase a power cord that is approved for use in that country.

The power cord must be rated for the product and for the voltage and current marked on the product's electrical ratings label. The voltage and current rating of the cord should be greater than the voltage and current rating marked on the product. The length of the cord must be between 1.8 m (6 feet) and 3.6 m (12 feet). If you have questions about the type of power cord to use, contact an HP authorized service provider.

Route the power cord so that it is not likely to be walked on or pinched by items placed on it or against it. Pay particular attention to the plug, electrical outlet, and the point where the cord exits from the product.



NOTE Use a 15 A-capable (minimum) power cord with a 110V power source. Use a 10 A-capable (minimum) power cord with a 220V power source.

F Routine care

General cleaning safety precautions

- Never use solvents or flammable solutions to clean the workstation.
- Never immerse any component in water or cleaning solutions; apply any liquids to a clean cloth and then use the cloth on the component.
- Always unplug the workstation before cleaning the keyboard, mouse, or air vents.
- Disconnect the keyboard before cleaning it.
- Wear safety glasses equipped with side shields when cleaning the keyboard.

Maximizing the airflow

- Keep your workstation in an area where the airflow to the front and rear of the system is not obstructed.
- If possible, keep the unit off of surfaces where dust can gather.
- Keep the back of the unit at least 0.15 m (6 in.) away from a wall or other obstruction.
- Keep the front of the unit clear of any obstruction that keeps air from entering the front of the system.
- Remove any dust on the front panel (vent area) and the rear fans with a small vacuum, compressed air, or dust rag.

Cleaning the workstation case

- Follow the safety precautions presented in [Service considerations on page 50](#) before cleaning the workstation.
- To remove light stains or dirt, use plain water with a clean, lint-free cloth or swab.
- For stronger stains, use a mild dish-washing liquid diluted with water. Rinse well by wiping it with a cloth or swab dampened with clear water.
- For stubborn stains, use isopropyl (rubbing) alcohol. No rinsing is needed because the alcohol will evaporate quickly and not leave a residue.
- After cleaning, always wipe the unit with a clean, lint-free cloth.
- Occasionally clean the air vents on the workstation. Lint and other foreign matter can block the vents and limit the airflow.

Cleaning the keyboard



CAUTION Use safety glasses equipped with side shields before attempting to clean debris from under the keys.

- Follow the safety precautions presented in [Service considerations on page 50](#) before cleaning the keyboard.
- Visible debris underneath or between the keys can be removed by vacuuming or shaking.
- Canned, pressurized air can be used to clean debris from under the keys. Use caution because too much air pressure can dislodge lubricants applied under the wide keys.
- If you remove a key, use a specially designed key puller to prevent damage to the keys. This tool is available through many electronic supply outlets.



CAUTION Never remove a wide leveled key (like the space bar) from the keyboard. If these keys are improperly removed or installed, the keyboard might not function properly.

- Clean under a key with a swab moistened with isopropyl alcohol and squeezed out. Be careful not to wipe away lubricants necessary for proper key functions. Allow the parts to air dry before reassembly.
- Use tweezers to remove any fibers or dirt in confined areas.

Cleaning the monitor

- Follow the safety precautions presented in [Service considerations on page 50](#) before cleaning the monitor.
- To clean the monitor, wipe the monitor screen with a towelette designed for cleaning monitors or a clean cloth moistened with water.



CAUTION Do not use sprays or aerosols directly on the screen—the liquid might seep into the housing and damage a component.

Never use solvents or flammable liquids on the monitor because display or housing damage may result.

Cleaning the mouse

1. Follow the safety precautions presented in [Service considerations on page 50](#) before cleaning the mouse.
2. Remove the mouse ball from the housing by removing the retaining plate.
3. Clean the mouse ball.
4. Pull out any debris from the ball socket, and wipe the ball with a clean, dry cloth.
5. Reassemble the mouse.

G Additional password security and resetting CMOS

This workstation supports the following security password features, which can be established through the Computer Setup Utility menu:

- Setup password
- Power-on password

If only a power-on password is established, it must be entered to boot the workstation.

If only a setup password is established, it must be entered to access the setup menu. Power cycling is required for the setup password to take effect.

If both passwords are set, either password can be entered to boot, but the setup password must still be entered to access the Computer Setup Utility menu.

If you forget the password for the computer, remove the Clear Password jumper on the system board.

Resetting the password jumper

To disable the power-on or setup password features and clear the power-on and setup passwords:

1. Shut down the operating system, and power off the workstation and any external devices. Disconnect the power cord of the workstation and any external devices from the power outlets.



WARNING! To reduce the risk of personal injury from electrical shock and hot surfaces, be sure to disconnect the power cord from the wall outlet and allow the internal system components to cool before touching.



CAUTION When the workstation is plugged in, the power supply always applies voltage to the system board—even when the unit is turned off. Failure to disconnect the power cord can result in damage to the system.

CAUTION Static electricity can damage the electronic components of the workstation or optional equipment. Before beginning these procedures, be sure that you are discharged of static electricity by briefly touching a grounded metal object.

2. Remove the access panel.
3. Locate the password header and jumper. The password header is E49. For assistance locating the password jumper and other system board components, refer to the service label on the workstation access panel.
4. Remove the jumper.
5. Replace the access panel.
6. Plug in and power on the workstation. Allow the operating system to start. This process clears the current passwords and disables the password features.
7. To establish new passwords, repeat steps 1 through 3, replace the password jumper on both pins 1 and 2, and repeat steps 5 through 6. Establish the new passwords in the Computer Setup Utility.

Clearing and resetting the CMOS

The CMOS of the workstation stores password information and information about the workstation configuration. This section describes the steps to successfully clear and reset the CMOS.

Using the CMOS button

1. Shut down the operating system, and power off the workstation and any external devices. Disconnect the power cord of the workstation and any external devices from the power outlets.



WARNING! To reduce the risk of personal injury from electrical shock and hot surfaces, be sure to disconnect the power cord from the wall outlet and allow the internal system components to cool before touching.



CAUTION When the workstation is plugged in, the power supply always applies voltage to the system board—even when the unit is turned off. Failure to disconnect the power cord can result in damage to the system.

CAUTION Static electricity can damage the electronic components of the workstation or optional equipment. Before beginning these procedures, be sure that you are discharged of static electricity by briefly touching a grounded metal object.

2. Remove the access panel.
3. Locate and press the clear CMOS button.



CAUTION Pushing the clear CMOS button resets CMOS values to factory defaults and erases some customized information. It is important to back up the workstation CMOS settings before resetting them in case they are needed later. To back up the CMOS settings, use the Replicated Setup option in the Computer Setup Utility menu.

For assistance locating the clear CMOS button and other system board components, refer to the service label on the workstation access panel.



NOTE AC power does not need to be disconnected for the clear CMOS button to work.

The clear CMOS button does not clear the workstation passwords.

4. Replace the access panel.
5. Plug in and power on the workstation.



NOTE Any special configurations will have to be reset.

Using the Computer Setup Utility to reset CMOS

To reset CMOS to factory defaults:

1. Enter the Computer Setup Utility menu by pressing **F10** when the **F10=Setup** prompt displays on the screen during bootup. The word **Setup** displays in the lower right corner of the screen. If a setup password has been set, a password prompt displays on the screen.



NOTE If you do not press the F10 key while the message is displayed, the workstation must be powered off, then on again, to access the utility.

2. Select **File>Default Setup>Restore Factory Settings as Default**, and press **F10**. Press any key at the prompt that then displays.



NOTE This procedure does not reset the date and time.

3. Select **File>Apply Defaults and Exit**. Press **F10** at the prompt that then displays.

H Quick troubleshooting flowcharts


This appendix presents some quick troubleshooting flowcharts for the following issues:

- Initial troubleshooting
- No power
- No video
- Error messages
- No OS loading
- No OS loading from hard drive
- No OS loading from diskette drive
- No OS loading from optical drive
- No OS loading from network
- Non-functioning device




NOTE The flowcharts presented are for general troubleshooting purposes only and they might not apply to your specific workstation.

Initial troubleshooting




No power

No power, part 1




Caution: Power is continuous to the system board and power supply even when the power switch is off. To prevent damage to the unit, disconnect the power cord from the workstation before beginning disassembly procedure.

No power, part 2



No power, part 3


No power Part 3



No video


No video, part 1

No video Part 1




No video, part 2

No video Part 2




No video, part 3




Error messages

Error messages, part 1



Error messages, part 2


Error messages Part 2



Notes: Short (S) and long (L) beeps will only be heard if the system has a speaker.
LEDs will only function on PS/2 keyboards, not USB.
x = Numbers 1 - 9

Error messages, part 3


Error Messages Part 3



Notes: Short (S) and long (L) beeps will only be heard if the system has a speaker.
LEDs will only function on PS/2 keyboards, not USB.
x = Numbers 1 - 9

No operating system loading

No OS loading




Factory recommended booting priority

1. Optical drive
2. Diskette drive
3. Hard drive
4. Network


NOTE: Before beginning, always check drive jumpers, cable connections, cable ends, and drives for bent or damaged pins.

No operating system loading from hard drive


No operating loading from hard drive, part 1




No operating system loading from hard drive, part 2




No operating system loading from hard drive, part 3




No operating system loading from diskette drive



No operating system loading from optical drive




No operating system loading from network



Non-functioning device

Non-functioning device

Caution: Power is continuous to the system board and power supply even when the power switch is off. To prevent damage to the unit, disconnect the power cord from the power source or the unit before beginning disassembly procedures.



I PCI bus layout

PCI bus layout and device list

The following illustration shows the HP xw9400 Workstation PCI bus layout. It is followed by a PCI device list description.




Figure I-1 PCI bus layout

Table I-1 PCI device list

Device	Bus#	Dev#	Fn#
MCP55ProPro HT Config	0	0	0
MCP55ProPro LPC	0	1	0

Table I-1 PCI device list (continued)

Device	Bus#	Dev#	Fn#
MCP55Pro SMBUS	0	1	1
MCP55Pro Trim	0	1	2
MCP55Pro ASF SMU	0	1	3
MCP55Pro USB OHCI	0	2	0
MCP55Pro USB EHCI	0	2	1
MCP55Pro IDE	0	4	0
MCP55Pro SATA0	0	5	0
MCP55Pro SATA1	0	5	1
MCP55Pro SATA2	0	5	2
MCP55Pro P2P Bridge (Bridge to Slot 3)	0	6	0
MCP55Pro High Definition Audio Controller	0	6	1
MCP55Pro LOM 0	0	8	0
MCP55Pro LOM 1	0	9	0
MCP55Pro PCIE Root Port 0 (Port to Slot 2)	0	F	0
MCP55Pro PCIE Root Port 2 (Port to NEC Bridge)	0	D	0
MCP55Pro PCIE Root Port 5 (Port to Slot 1)	0	A	0
IO55 HT Config	40h	0	0
IOP55 LPC	40h	1	0
IOP55 SMBUS	40h	1	1
IOP55 Trim	40h	1	2
IO55 PCIE Root Port 0 (Port to Slot 5)	40h	F	0
IO55 PCIE Root Port 2 (Port to SAS)	40h	D	0
IO55 PCIE Root Port 5(Port to Slot 4)	40h	A	0
Slot 1 (PCIEx8)	5h	0	0
Slot 2 (PCIEx16)	18h	0	0
Slot 3 (32 bit PCI)	1h	4	0
Slot 4 (PCIEx8)	45h	0	0
Slot 5 (PCIEx16)	58h	0	0
Slot 6 (PCIX 100)	2Ch	4	0
Slot 7 (PCIX 100/133)	2Ch	9	0
1394 Controller	1h	5	0
NEC PCIX Bridge Controller	2Bh	0	0
NEC PCIX Bridge Controller (No Physical Slot Connections)	2Bh	0	1
LSI SAS Controller	6Bh	0	0

